Ricoh 820073

Ricoh SP C400 Yellow Toner Cartridge User Manual

Model: 820073

Introduction

This user manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of your Ricoh 820073 SP C400 Yellow Toner Cartridge. Designed for optimal performance, this genuine Ricoh toner cartridge ensures precise and high-quality prints, protecting your investment.

Product Overview

The Ricoh 820073 SP C400 Yellow Toner Cartridge is a genuine Ricoh supply designed for use with the SP C400DN printer. It provides an approximate yield of 6,000 pages, ensuring long-lasting and consistent yellow color output for your printing needs.



Image: The Ricoh SP C400 Yellow Toner Cartridge, showing the yellow toner unit alongside its cardboard packaging. The packaging displays 'RICOH PRINT CARTRIDGE YELLOW SP C400', 'Color YELLOW', 'Net Weight 145g/5.11oz', 'EDP CODE 820073', and 'PRINTED WITH SOY INK'. The toner unit itself is yellow with a green end cap, labeled 'Yellow/ '.

Setup and Installation

Follow these steps to properly install your new toner cartridge:

1. **Unpack the Cartridge:** Carefully remove the new Ricoh 820073 Yellow Toner Cartridge from its packaging. Avoid touching the drum or electrical contacts.
2. **Shake Gently:** Gently shake the cartridge horizontally 5-6 times to distribute the toner evenly inside.
3. **Remove Protective Materials:** Remove any protective tapes, seals, or covers from the cartridge as indicated in your printer's specific manual.
4. **Open Printer Access:** Open the front cover or toner access door of your Ricoh SP C400DN printer.
5. **Remove Old Cartridge:** Grasp the handle of the old toner cartridge and pull it straight out of the printer. Place it in the plastic bag from the new cartridge for proper disposal.
6. **Insert New Cartridge:** Align the new cartridge with the slot in the printer and push it firmly until it clicks into place. Ensure it is securely seated.
7. **Close Printer Access:** Close the front cover or toner access door. The printer will typically begin initializing the new cartridge.

Refer to your specific printer model's manual for detailed visual instructions if needed.

Operating Instructions

Once the Ricoh 820073 SP C400 Yellow Toner Cartridge is installed, your printer is ready for operation. The printer will automatically detect the new cartridge and adjust settings for optimal yellow color printing.

- **Printing:** Proceed with your normal printing tasks. The printer will utilize the yellow toner as required for color documents and images.
- **Toner Level Monitoring:** Monitor the toner level through your printer's control panel or associated software to anticipate when a replacement cartridge will be needed.
- **Print Quality:** For best print quality, use genuine Ricoh paper and ensure your printer drivers are up to date.

Maintenance

Toner cartridges generally require minimal maintenance. To ensure the longevity and quality of your Ricoh 820073 SP C400 Yellow Toner Cartridge:

- **Storage:** Store unused cartridges in their original, sealed packaging in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle cartridges carefully to avoid dropping them or exposing them to excessive vibration, which could damage internal components.
- **Cleaning:** Do not attempt to clean the toner cartridge itself. If toner spills, use a dry cloth to wipe it up. Do not use water or solvents.

Troubleshooting

If you encounter issues with your Ricoh 820073 SP C400 Yellow Toner Cartridge, consider the following common problems and solutions:

Problem	Possible Cause	Solution
Faded or Light Prints	Low toner level; uneven toner distribution.	Gently shake the cartridge to redistribute toner. Replace the cartridge if the issue persists.
Streaks or Lines on Prints	Damaged drum unit (integrated with cartridge); foreign object in printer.	Ensure cartridge is properly seated. If issue continues, replace cartridge. Consult printer manual for cleaning procedures.
Printer Not Recognizing Cartridge	Cartridge not installed correctly; faulty chip; non-genuine cartridge.	Remove and reinsert the cartridge. Ensure it is a genuine Ricoh cartridge. Restart the printer.
Toner Leakage	Damaged cartridge; improper handling.	Carefully remove the cartridge and dispose of it. Install a new cartridge. Avoid shaking vigorously.

For more complex issues, refer to your Ricoh printer's comprehensive troubleshooting guide or contact Ricoh support.

Specifications

Feature	Detail
Product Name	Ricoh SP C400 Yellow Toner Cartridge
Model Number	820073
Color	Yellow
Approximate Page Yield	6,000 pages
Compatible Devices	Ricoh SP C400DN Printer
Item Weight	5.1 ounces (145g)
Product Dimensions (LxWxH)	3.5 x 13.5 x 3.5 inches
Manufacturer	Ricoh Innovations Corporation

Warranty and Support

Genuine Ricoh products are manufactured to high standards and are typically covered by a manufacturer's warranty against defects in materials and workmanship. For specific warranty terms and conditions, please refer to the documentation included with your printer or visit the official Ricoh website.

For technical assistance, product inquiries, or support, please contact Ricoh customer service or visit their official support portal. Contact information can usually be found on the Ricoh website or in your printer's documentation.

Online Resources:

- Ricoh Official Website: www.ricoh.com
- Ricoh Support: www.ricoh.com/support

© 2023 Ricoh. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question