BLACK+DECKER JW275

BLACK+DECKER Lids Off Jar Opener JW275 Instruction Manual

Model: **JW275** | Brand: **BLACK+DECKER**

Introduction

The BLACK+DECKER Lids Off Jar Opener JW275 is an electric, automatic jar opener designed to effortlessly open a wide variety of jars. This device is particularly beneficial for individuals with limited hand strength, such as those with arthritis, or anyone who frequently encounters stubborn jar lids. Its simple, one-touch operation makes opening jars quicker and easier than ever before.
Key features include:

- Opens virtually any size jar in one simple operation.
- Easy to store.
- Compliments any kitchen.



Image: The BLACK+DECKER Lids Off Jar Opener JW275, a white and red electric device designed for easy jar opening.

Important Safety Information

- **DO NOT touch moving parts during operation.**
- Keep hands and loose clothing away from moving parts.
- Ensure the jar opener is placed on a stable, flat surface during use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

Parts Identification

The jar opener consists of several key components:

- **Main Body:** The primary housing for the motor and battery compartment.
- **Operation Button:** A single button to initiate and stop the jar opening process.
- **Jar Grips:** Two sets of grips. The lower grips secure the jar body, and the upper grips secure the jar lid.
- **Battery Compartment:** Located on the underside, requiring 2 AA batteries for power.



Image: A close-up view of the electric jar opener, highlighting the internal gears and dual gripping system for both the jar and its lid.

Setup

1. **Battery Installation:**
    - Locate the battery compartment on the underside of the jar opener.
    - Slide open the battery compartment cover.
    - Insert two (2) AA batteries, ensuring correct polarity (+/-).
    - Slide the cover back into place until it clicks securely.
2. **Initial Check:**
    - Press the operation button briefly. The grips should extend and retract, indicating the device is powered and ready.

Your browser does not support the video tag.

Video: A demonstration of the electric jar opener's internal mechanism and battery installation process.

Operating Instructions

1. **Positioning the Jar:** Place the jar to be opened on a stable, flat surface.
2. **Placing the Opener:** Position the electric jar opener on top of the jar. Ensure the lower grips are aligned with the body of the jar and the upper grips are over the lid.
3. **Initiating Operation:** Press and hold the operation button. The lower grips will automatically adjust to secure the jar, and the upper grips will clamp onto the lid.
4. **Automatic Opening:** Once both sets of grips are secure, the device will automatically twist the lid counter-clockwise until it is loosened.
5. **Release:** After the lid is loosened, the jar opener will automatically release its grip on both the jar and the lid, returning to its open position.
6. **Remove Lid:** Carefully remove the loosened lid from the jar.

Your browser does not support the video tag.

Video: A demonstration of the electric jar opener in action, showing how it automatically grips and opens a jar.

Your browser does not support the video tag.

Video: Another demonstration of the electric jar opener successfully opening a jar, highlighting its ease of use.

Cleaning and Maintenance

The BLACK+DECKER Lids Off Jar Opener is designed for easy cleaning due to its rubber and plastic construction.

- **Cleaning:** Wipe the device with a damp cloth. Do not immerse the unit in water or any other liquid.
- **Storage:** Store the jar opener in a dry place when not in use.
- **Battery Replacement:** Replace batteries when the device's operation becomes sluggish or stops working.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on or operate.	Batteries are dead or incorrectly installed.	Check battery polarity and replace with fresh AA batteries.
Jar is not gripped securely.	Jar size is outside the operating range.	Ensure jar mouth diameter is between 1.2 to 3.5 inches and bottle diameter is between 1.4 to 4.15 inches. Not suitable for plastic cans.
Lid is not opening.	Lid is extremely tight or device is not properly positioned.	Reposition the opener and try again. Ensure the device is held down firmly on the jar.

Specifications

- **Product Dimensions:** 7 x 8.5 x 8 inches
- **Item Weight:** 3.55 pounds
- **Manufacturer:** BLACK+DECKER
- **Item Model Number:** JW275
- **Power Source:** 2 x AA Batteries (not included)
- **Opening Range (Jar Mouth Diameter):** 1.2 - 3.5 inches
- **Opening Range (Bottle Diameter):** 1.4 - 4.15 inches

Warranty and Support

For any issues or support regarding your BLACK+DECKER Lids Off Jar Opener JW275, please refer to the manufacturer's warranty information provided with your product packaging. Some products may offer an additional 12-month warranty upon registration or contacting the seller.
Please contact the seller directly for warranty claims or product support before returning the product to the retailer.