Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hasbro Gaming 14635

Hasbro Gaming Electronic Guess Who? Extra Game Instruction Manual

Model: 14635

Introduction

This manual provides instructions for the Hasbro Gaming Electronic Guess Who? Extra Game. It covers setup, operation, maintenance, and troubleshooting to ensure a fun and engaging experience for players aged 6 and up.



Image: The Electronic Guess Who? Extra Game board, featuring red and blue player sides with character cards.

Components

The Electronic Guess Who? Extra Game includes the following components:

- Portable game case
- 6 double-sided character sheets (3 red and 3 blue)
- 8 guessing pegs (4 red and 4 blue)
- Instruction manual



Image: The product packaging for Electronic Guess Who? Extra Game, highlighting the various character sheets and electronic features.

Setup

1. **Battery Installation:** The game requires 2 x 1.5V AAA batteries (not included). Open the battery compartment on the underside of the game board and insert the batteries, ensuring correct polarity. Close the compartment securely.
2. **Character Sheet Selection:** Choose one of the 6 double-sided character sheets. Each player will use one side of the chosen sheet. Slide the chosen sheet into the designated slots on each player's side of the game board.
3. **Prepare the Board:** Ensure all character doors are open on both sides of the game board.
4. **Select Your Mystery Character:** Each player secretly selects one character from their chosen sheet. This is their mystery character.
5. **Place Guessing Pegs:** Each player takes 4 guessing pegs of their color (red or blue) and places them in the scoring track on their side of the board.

Operating Instructions

The Electronic Guess Who? Extra Game offers multiple ways to play. The core gameplay involves asking yes/no

questions to eliminate characters until you can guess your opponent's mystery character.

Basic Gameplay

1. **Starting the Game:** Decide which player goes first.
2. **Asking Questions:** On your turn, ask your opponent a yes or no question about their mystery character (e.g., "Does your character have a hat?").
3. **Eliminating Characters:** Based on your opponent's answer, close the doors of all characters that do not match the description. For example, if the answer is "No," close all doors of characters that have a hat.
4. **Electronic Feedback:** Use the "Yes" or "No" buttons on the game board to respond to your opponent's questions. The board will provide electronic lights and sounds.
5. **Making a Guess:** When you believe you know your opponent's mystery character, you can make a guess instead of asking a question. If your guess is correct, you win the round. If incorrect, you lose the round.
6. **Winning a Round:** The first player to correctly guess their opponent's mystery character wins the round.

Advanced Play Modes

The game includes 4 ways to play, offering varied challenges:

- **Classic Guess Who:** Standard gameplay as described above.
- **Electronic Timer Mode:** Play with a timer for faster rounds.
- **Two-Character Guess:** Some versions allow players to select two mystery characters, increasing complexity.
- **Silent Mode:** Players use only the electronic "Yes" or "No" buttons to communicate answers, without speaking.

Maintenance

- **Cleaning:** Wipe the game board and character sheets with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** Store all components in the portable game case when not in use to prevent loss or damage. Keep the game in a cool, dry place away from direct sunlight.
- **Battery Care:** Remove batteries if the game will not be used for an extended period to prevent leakage. Dispose of used batteries responsibly.

Troubleshooting

Problem	Solution
Game does not turn on or has no sound.	◦ Check if batteries are inserted correctly. ◦ Replace old batteries with new 1.5V AAA batteries. ◦ Ensure the power switch is in the "ON" position.
Character doors are not staying open/closed.	◦ Ensure character sheets are properly seated in their slots. ◦ Inspect for any debris or damage preventing smooth operation.
Electronic buttons are unresponsive.	◦ Check battery power. ◦ Clean the button area to remove any obstructions.

Specifications

- **Brand:** Hasbro Gaming
- **Model Number:** 14635
- **Number of Players:** 2
- **Recommended Age:** 6+ years (Manufacturer Minimum Age: 96 months)
- **Power Source:** Battery Powered
- **Battery Type:** 2 x 1.5V AAA batteries (not included)
- **Material:** Plastic
- **Item Weight:** 3.05 Pounds
- **Item Dimensions:** 2.01 x 15.98 x 10.63 inches
- **CPSIA Cautionary Statement:** Choking Hazard - Small Parts

Warranty and Support

For warranty information or product support, please refer to the official Hasbro Gaming website or contact their customer service department. Keep your purchase receipt as proof of purchase.
Note: Specific warranty terms may vary by region.

© 2026 Hasbro Gaming. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0013WKAG8

More documents and user manuals: **https://manuals.plus/**