Schick Silk Effects Plus

Schick Silk Effects Plus Razor User Manual

Model: Silk Effects Plus

Introduction

The Schick Silk Effects Plus Women's Razor is designed to provide a smooth and worry-free shaving experience. It features two microfine wire-wrapped blades engineered to help prevent nicks and cuts, along with an Ultra Glide strip enriched with Aloe and Vitamin E for enhanced glide and skin comfort.

Package Contents

- 1 Schick Silk Effects Plus Razor Handle
- 2 Schick Silk Effects Plus Cartridges



Image: Front view of the Schick Silk Effects Plus Razor in its retail packaging, showing the razor handle and two cartridges.

Setup

Attaching a New Cartridge

1. Remove the new cartridge from its protective packaging.
2. Align the cartridge with the razor handle.
3. Press the cartridge firmly onto the handle until it clicks into place.

Replacing a Used Cartridge

1. Locate the release button or mechanism on the razor handle.
2. Press the release button to detach the used cartridge.
3. Carefully dispose of the used cartridge.
4. Attach a new cartridge following the steps above.

Image: Back of the Schick Silk Effects Plus Razor packaging, illustrating the three steps for replacing a razor cartridge: 1) Pressing the button to release the old cartridge, 2) Sliding the handle into a new cartridge, and 3) Clicking the new cartridge into place.

Operating Instructions

1. **Prepare Skin:** Wet the skin and apply a shaving cream or gel to create a lather.
2. **Shave:** Hold the razor handle firmly and shave in the direction of hair growth using light, even strokes. The pivoting head will adjust to the contours of your body.
3. **Rinse:** Rinse the razor head frequently under running water during shaving to clear away hair and shaving cream.
4. **Finish:** After shaving, rinse your skin thoroughly and apply a moisturizer if desired.

The microfine wire-wrapped blades are designed to minimize nicks and cuts, providing a safe and smooth shave. The Ultra Glide strip, enriched with Aloe and Vitamin E, helps the blade glide effortlessly over your skin.

Maintenance

- **Cleaning:** After each use, rinse the razor head thoroughly under warm running water to remove all hair and shaving cream. Do not tap the razor against a hard surface, as this can damage the blades.
- **Storage:** Store the razor in a well-drained and dry area of your shower or bathroom to prevent water buildup and maintain hygiene. Placing it upside down in a rack can aid drying.
- **Blade Replacement:** Replace the razor cartridge when the blades feel dull or when the lubricating strip fades, typically after 5-7 shaves, depending on hair type and shaving frequency.
- **Sanitization (Optional):** For additional sanitization, you may occasionally place the razor head in boiling water between blade changes, ensuring the plastic components are not exposed to excessive heat for prolonged periods.

Troubleshooting

- **Nicks or Cuts:** Ensure you are using a fresh blade. Apply sufficient shaving cream or gel. Shave with light pressure and in the direction of hair growth.
- **Dull Blades:** If the shave is not smooth or effective, the blade may be dull. Replace the cartridge with a new one.
- **Razor Dragging:** This can indicate a dull blade or insufficient lubrication. Ensure you are using a fresh cartridge and plenty of shaving cream or gel.

Specifications

Brand	Schick
Model Name	Silk Effects Plus
Model Number	841058011002
Number of Blades	2 (Microfine wire-wrapped)
Special Feature	Ergonomic handle, Ultra Glide strip with Aloe & Vitamin E
Product Dimensions	7.5 x 3.7 x 1.9 inches
Item Weight	1.6 ounces
UPC	841058011002

Warranty Information

PERFORMANCE GUARANTEE: SCHICK® SILK EFFECTS® PLUS is guaranteed to give you the best shave. If you are not satisfied, return the razor and unused cartridge to Schick for exchange or refund your full purchase price.

Support

For questions or further assistance, please contact Schick customer support:

- **Phone:** 1-800-SHAVING
- **Website:** www.shaving.com
- **Brand Store:** Visit the official Schick Store on Amazon for more products and information.

© 2026 Schick. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question