Travel Blue 631

Travel Blue De-Lux Waist Pouch Model 631 Instruction Manual

Model: 631 | Brand: Travel Blue

1. Product Overview

The Travel Blue De-Lux Waist Pouch Model 631 is designed for secure and convenient storage of essential items during travel or daily activities. Constructed from durable materials, it offers a hands-free solution for carrying your passport, mobile phone, wallet, and other small valuables.

Key Features:

- **Spacious 3-Zip Compartment Design:** Features three secure zippered compartments for organized storage of passport, wallet, mobile phone, cash, keys, and tickets.
- **Hands-Free Travel Convenience:** Designed for comfortable wear around the waist, keeping belongings accessible while allowing freedom of movement.
- **Durable & Lightweight Construction:** Made from high-quality nylon with a polyester lining for durability and lightweight comfort.
- **Adjustable Waist Belt:** Equipped with a robust quick-release buckle and an adjustable strap, fitting waist sizes up to 125 cm (49 inches).
- **Versatile Use:** Ideal for airports, vacations, hiking, walking, festivals, shopping, and everyday use.



Figure 1: Front view of the Travel Blue De-Lux Waist Pouch.

2. Setup and Adjustment

Before using your waist pouch, ensure it is properly adjusted for comfort and security.

1. **Unpack the Pouch:** Remove the waist pouch from its packaging.
2. **Locate the Waist Belt:** The pouch features an integrated adjustable waist belt with a quick-release buckle.
3. **Adjust the Belt Length:**
    - Unclip the quick-release buckle.
    - Slide the adjustable strap through the buckle mechanism to lengthen or shorten the belt until it comfortably fits around your waist.
    - Ensure the pouch sits securely without being too tight or too loose. The belt can be adjusted for waist sizes up to 125 cm (49 inches).
4. **Secure the Buckle:** Once adjusted, snap the quick-release buckle together until you hear a click, indicating it is securely fastened.



Figure 2: Back view illustrating the adjustable waist belt and quick-release buckle.

3. Operating Instructions

The De-Lux Waist Pouch is designed for easy access and organization of your essentials.

1. **Main Compartment:** The largest zippered compartment is suitable for items such as a passport, mobile phone, or a small wallet.
2. **Front Zippered Pocket:** A smaller zippered pocket on the front is ideal for quick-access items like keys, coins, or tickets.
3. **Rear Zippered Pocket:** A flat zippered compartment located on the back of the pouch, designed to rest against your body, offers additional security for sensitive documents or cash.
4. **Loading Items:** Open the desired compartment zipper, place your items inside, and securely close the zipper. Ensure all zippers are fully closed to prevent items from falling out.
5. **Wearing the Pouch:** Wear the pouch around your waist, positioning it comfortably at the front, side, or back, depending on your preference and activity.



Figure 3: View of the pouch with its three zippered compartments open.

4. Maintenance and Care

Proper care will extend the life and appearance of your Travel Blue De-Lux Waist Pouch.

- **Cleaning:** The pouch should be **hand washed only**. Use mild soap and cool water. Do not machine wash, bleach, tumble dry, or iron.
- **Drying:** Air dry the pouch completely before storing or reusing it. Avoid direct sunlight or high heat, which can damage the material.
- **Storage:** Store the pouch in a cool, dry place when not in use.
- **Zipper Care:** Keep zippers free from dirt and debris. If a zipper becomes stiff, a small amount of zipper lubricant can be applied.

5. Troubleshooting

If you encounter any issues with your waist pouch, refer to the following common solutions:

Problem	Possible Cause	Solution
Zipper sticking or difficult to close.	Dirt, debris, or lack of lubrication.	Clean the zipper teeth with a small brush. Apply a small amount of zipper lubricant or a graphite pencil to the teeth. Avoid forcing the zipper.
Waist belt feels too loose or too tight.	Incorrect belt adjustment.	Refer to Section 2, "Setup and Adjustment," to correctly adjust the belt length for a comfortable and secure fit.
Pouch appears dirty or stained.	Accumulated dirt from use.	Hand wash the pouch using mild soap and cool water. Air dry thoroughly. Do not use harsh chemicals or machine wash.

6. Specifications

Brand	Travel Blue
Model Number	631
Item Type	Waist Pouch
Material	High-quality Nylon with Polyester Lining
Color	Black
Item Weight	171 Grams
Closure Type	Zipper
Water Resistance	Water Resistant
Waist Belt Adjustment	Up to 125 cm (49 inches)
Compartments	3 Zippered Compartments
Included Components	1 Travel Pouch
Country of Origin	China
GTIN (Global Trade Identification Number)	05018404006318

Figure 4: Product packaging with GTIN for identification.

7. Warranty Information

The Travel Blue De-Lux Waist Pouch Model 631 comes with a global warranty.

- **Warranty Period:** 24 Months Global Warranty from the date of purchase.
- **Coverage:** A free replacement will be provided if any manufacturing defect appears within the 24-month warranty period.
- **Claim Process:** For warranty claims, please retain your proof of purchase and contact Travel Blue customer support.

Figure 5: Travel Blue 24 Months Global Warranty details.

8. Customer Support

For further assistance, product inquiries, or warranty claims, please contact Travel Blue customer support or visit their official store.

- **Manufacturer:** Travel Blue
- **Online Store:** Visit the Travel Blue Store on Amazon
- **General Inquiries:** Refer to the contact information provided on the official Travel Blue website or product packaging.

© 2023 Travel Blue. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.