Mattel Triple Decker Bus B0016GD63K

Polly Pocket Polly-Tastic Adventure Triple Decker Bus Instruction Manual

Model: Triple Decker Bus B0016GD63K
Brand: Mattel

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Polly Pocket Polly-Tastic Adventure Triple Decker Bus. Please read this manual thoroughly before use to ensure proper functionality and longevity of the product.



Image: The Polly Pocket Triple Decker Bus in its expanded form, showcasing the multiple levels and included accessories like a bed, vanity, and a Polly Pocket doll.

Setup and Assembly

Follow these steps to assemble your Triple Decker Bus:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the packaging contents are present.
2. **Expand the Bus:** The bus is designed to transform. Gently pull the top section upwards to reveal the second and third levels. The side panels will also swing open to reveal additional play areas.
3. **Attach Side Modules:** The bus features hinged side compartments. Ensure these are fully extended and stable. One side typically reveals a dressing room, and the other a lounge area.
4. **Position Accessories:** Place the included accessories, such as the bed, vanity, and seating, within the designated areas of the bus. The bed can be placed in the bedroom area, and the vanity in the dressing room.
5. **Elevator Operation:** The bus includes an elevator. Ensure it slides smoothly between levels. Test its movement by gently pushing it up and down.



Image: A detailed view of the bus's interior, showing the dressing room with clothes hangers and a mirror, and the clear elevator shaft on the left side.

Operating Instructions

The Polly Pocket Triple Decker Bus offers multiple play configurations:

- **Bus Mode:** To use as a compact bus, fold down the top levels and close the side panels. Ensure all accessories are securely stored inside before closing.
- **Expanded Play Mode:** To access all play areas, expand the bus as described in the Setup section. This reveals the bedroom, dressing room, and lounge areas.
- **Elevator Use:** Place a Polly Pocket doll or similar small figure into the elevator. Gently slide the elevator up or down to transport figures between the different levels of the bus.
- **Accessory Placement:** Utilize the various hooks, shelves, and designated spots for the included accessories and other Polly Pocket items.

Maintenance and Care

Proper care will extend the life of your product:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners, as these may damage the plastic.
- **Storage:** When not in use, fold the bus back into its compact form to protect internal components and accessories. Store in a cool, dry place away from direct sunlight.
- **Handling:** Handle all moving parts, especially the elevator and hinged sections, with care to prevent breakage. Avoid excessive force when expanding or collapsing the bus.

Troubleshooting

Problem	Possible Cause	Solution
Bus does not expand or collapse smoothly.	Parts may be misaligned or obstructed.	Gently check for any obstructions. Ensure all hinged sections are properly aligned before attempting to expand or collapse. Do not force.
Elevator is stuck or not moving.	Obstruction in the elevator shaft or misalignment.	Inspect the elevator shaft for any small objects. Ensure the elevator is correctly seated on its track.
Accessories do not stay in place.	Incorrect placement or loose fit.	Refer to the product images for correct accessory placement. Some accessories are designed for specific slots.

Specifications

Product Name: Polly Pocket Polly-Tastic Adventure Triple Decker Bus

Brand: Mattel

Model: Triple Decker Bus (B0016GD63K)

Dimensions (Package): 12 x 11 x 4.6 inches (approximate)

Item Weight: 2.25 pounds (approximate)

Material: Durable Plastic

Recommended Age: Consult product packaging for age recommendations.

Warranty and Support

For information regarding product warranty or to contact customer support, please refer to the contact details provided on

the product packaging or visit the official Mattel website. Keep your proof of purchase for any warranty claims.
Mattel Official Website: www.mattel.com

© 2024 Mattel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question