Fischer & Honsel 85993

Honsel 85993 Ceiling Lamp User Manual

Model: 85993 | Brand: Fischer & Honsel

1. Introduction

This manual provides essential information for the safe installation, operation, and maintenance of your Honsel 85993 Ceiling Lamp. Please read these instructions carefully before installation and retain them for future reference. Incorrect installation or use may result in electric shock, fire, or other hazards.

2. Safety Instructions

- **Electrical Safety:** Installation must be performed by a qualified electrician in accordance with all local and national electrical codes. Always disconnect power at the main circuit breaker before installation, maintenance, or bulb replacement.
- **Voltage:** Ensure the supply voltage matches the lamp's requirements (230V).
- **Wattage:** Do not exceed the maximum wattage per bulb (25W). Use E27 base bulbs only.
- **Environment:** This lamp is designed for indoor use only, specifically in enclosed rooms. Do not install in damp or wet locations.
- **Handling:** Handle glass components with care to prevent breakage.

3. Package Contents

Verify that all components are present before beginning installation. If any parts are missing or damaged, do not proceed with installation and contact your retailer.

- Ceiling lamp fixture (metal base, glass shade)
- Mounting hardware (screws, wall plugs)
- Instruction manual

Note: Light bulbs are typically not included and must be purchased separately.

4. Setup and Installation

Professional installation is recommended for this product.

4.1 Pre-Installation

1. Turn off the main power supply at the circuit breaker.
2. Unpack all components and inspect for any damage.
3. Identify the desired mounting location on the ceiling. Ensure there are no hidden electrical wires or pipes.

4.2 Mounting the Fixture

1. Carefully detach the glass shade from the metal base, if pre-assembled.
2. Hold the metal base against the ceiling at the desired location and mark the drilling points for the mounting screws.
3. Drill holes at the marked points and insert appropriate wall plugs (if necessary).
4. Secure the metal base to the ceiling using the provided screws.

4.3 Wiring

1. Connect the household electrical wires to the corresponding terminals on the lamp's metal base. Typically:
    - Brown/Black wire (Live) to 'L' terminal.
    - Blue wire (Neutral) to 'N' terminal.
    - Green/Yellow wire (Earth) to the earth symbol terminal (⚡).
2. Ensure all connections are secure and properly insulated.

4.4 Bulb and Shade Installation

1. Screw three E27 base bulbs (max 25W each) into the lamp holders.
2. Carefully reattach the glass shade to the metal base, ensuring it is securely fastened.



Image 1: The Honsel 85993 Ceiling Lamp featuring a frosted glass shade and chrome accents.



Image 2: The Honsel 85993 Ceiling Lamp installed in a living room, demonstrating its aesthetic appeal and light distribution.

5. Operating Instructions

Once installed, the Honsel 85993 Ceiling Lamp operates like any standard light fixture. Use a wall switch connected to the lamp's circuit to turn it on and off. Ensure the light bulbs are securely screwed in for proper contact.

6. Maintenance

6.1 Cleaning

- Always disconnect power before cleaning.
- Wipe the metal parts with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- Clean the glass shade with a soft, damp cloth and mild detergent if necessary. Dry thoroughly with a clean, dry cloth.

6.2 Bulb Replacement

- Ensure the lamp is turned off and has cooled down completely before attempting to replace bulbs.
- Carefully remove the glass shade.
- Unscrew the old E27 bulb counter-clockwise.
- Screw in a new E27 bulb (max 25W) clockwise until snug.
- Reattach the glass shade securely.

7. Troubleshooting

Problem	Possible Cause	Solution
Lamp does not light up	No power supply Loose wiring Faulty bulb	Check circuit breaker and wall switch Verify all wire connections (power off first) Replace bulb with a new one
Light flickers	Loose bulb Incorrect bulb type Loose wiring	Tighten bulb Ensure E27 base and max 25W Check wiring connections (power off first)
Glass shade is loose	Improperly secured	Ensure all fastening mechanisms for the shade are tightened

8. Specifications

Feature	Detail
Brand	Fischer & Honsel
Model Number	85993
Color	Metallic (Chrome)
Material	Glass, Metal
Style	Classic
Room Type	Living Room (for use in enclosed rooms only)
Power Source	Mains Powered
Light Source Type	Incandescent (E27 base)
Number of Light Sources	3
Voltage	230V
Max Wattage per Bulb	25W
Mounting Type	Ceiling Mounting
Assembly Required	Yes
Item Weight	2.23 Pounds (approx. 1.01 kg)

9. Warranty Information

Fischer & Honsel products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the documentation provided at the point of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

10. Support

If you encounter any issues not covered in this manual or require further assistance, please contact your retailer or

the manufacturer directly. Ensure you have your product model number (85993) and proof of purchase available when seeking support.

© 2026 Fischer & Honsel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question