Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gold N Hot GH9271

Gold N Hot Professional 1200W Full Hood Hair Dryer

Model: GH9271 | Brand: Gold N Hot

1. Product Overview

The Gold 'N Hot Professional 1200-Watt Hair Dryer is designed for efficient hair drying and conditioning treatments. Its full-sized hood accommodates various roller sizes, and the adjustable column allows for comfortable use at different heights. With 1200 watts of power and three heat/speed combinations, it provides consistent and even airflow, making it ideal for all hair types, especially textured, delicate, or fine hair.

Key Features:

- **Hooded Design:** Features double vents under the hood for even airflow, accommodating the largest hair rollers.
- **Height Adjustable:** Easily adjusts to your preferred height for comfortable styling.
- **Heat Settings:** Offers 3 Heat/Speed settings with easy-to-reach and read controls.
- **Large Rollers Accommodation:** Extra-large hood designed to fit large rollers.
- **Portability & Storage:** Easy fold-up design with built-in cord storage and an attached handle for convenient clean-up and portability.
- **Designed for Ethnic Hair:** Excellent for reforming and retexturizing curls of very curly, coiled, and natural curly hair types.



Figure 1: Gold N Hot Professional 1200W Full Hood Hair Dryer in its assembled state.

2. Important Safety Information

WARNING: To reduce the risk of burns, electrocution, fire, or injury to persons:

- Always unplug the appliance immediately after using.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Close supervision is necessary when this appliance is used by, on, or near children or invalids.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended

by the manufacturer.

- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not direct hot air towards eyes or other heat-sensitive areas.
- Attachments may be hot during use. Allow them to cool before handling.
- Do not place appliance on any surface while it is operating.

3. Setup and Assembly

Your Gold N Hot Full Hood Hair Dryer is designed for easy assembly and portability. Follow these steps to set up your dryer:

1. **Unpack the Dryer:** Carefully remove all components from the packaging. Ensure all parts are present: the main base unit, the adjustable column, and the hood.
2. **Extend the Column:** Locate the adjustable column. Gently pull it upwards from the base until it locks into place at your desired height. The column is designed to extend to accommodate various user heights.
3. **Attach the Hood:** Securely attach the hood to the top of the adjustable column. Ensure it clicks firmly into position to prevent wobbling during use.
4. **Position the Dryer:** Place the assembled dryer on a stable, flat, and heat-resistant surface. Ensure there is adequate space around the unit for proper ventilation.
5. **Unwind the Power Cord:** Pull the power cord from its built-in storage compartment at the base of the unit. Fully extend the cord before plugging it into an electrical outlet.



Figure 2: The adjustable column allows for height variations.



Figure 3: Collapsible design for easy storage.

4. Operating Instructions

This section guides you through the proper use of your Gold N Hot Professional 1200W Full Hood Hair Dryer for optimal results.

4.1 Preparing Your Hair

- Wash and condition your hair as usual.
- For roller sets, apply setting lotion or foam and place rollers as desired. Ensure rollers fit comfortably under the hood.
- For deep conditioning treatments, apply your preferred conditioning mask evenly to your hair.

4.2 Using the Dryer

1. **Plug In:** Plug the dryer into a standard electrical outlet.
2. **Position Yourself:** Sit comfortably with your head positioned directly under the hood. Adjust the height of the column as needed for a comfortable fit, ensuring the hood fully covers your rollers or hair.
3. **Select Heat/Speed Setting:** Use the controls located on the base of the unit to select your desired heat and speed combination. The dryer offers three settings: LOW, MEDIUM, and HIGH.
    - **LOW:** Gentle drying, suitable for delicate hair or light conditioning.
    - **MEDIUM:** Standard drying, good for most hair types and general use.
    - **HIGH:** Fast drying, ideal for thick or very wet hair, or intense conditioning.
4. **Drying Time:** Drying time will vary based on hair thickness, length, and the chosen heat setting. Periodically check your hair to monitor dryness.
5. **Even Airflow:** The double vents under the hood ensure even heat distribution, promoting consistent drying and conditioning.
6. **Finish:** Once your hair is dry or your conditioning treatment is complete, switch the dryer to the "OFF" position and unplug it from the outlet.



Figure 4: Easy-to-reach and read controls for heat/speed settings.



Figure 5: Double vents under the hood for even airflow.

4.3 Product Demonstration Video

Your browser does not support the video tag.

Video 1: Official Gold N Hot Brand Video showcasing various products, including the hair dryer, and their use.

5. Care and Maintenance

Proper care ensures the longevity and optimal performance of your hair dryer.

- **Cleaning:** Ensure the dryer is unplugged and completely cool before cleaning. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Air Intake Filter:** Regularly check the air intake filter (if accessible) for lint and dust buildup. Clean as necessary to

maintain proper airflow and prevent overheating.

- **Storage:** After use, allow the unit to cool down. Utilize the built-in cord storage for neat organization. Collapse the adjustable column and fold the unit for compact storage. Store in a cool, dry place away from moisture.



Figure 6: Built-in cord storage for convenient clean-up.

6. Troubleshooting

If you encounter issues with your hair dryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Dryer does not turn on.	No power, faulty outlet, or tripped circuit breaker.	Check if the dryer is properly plugged in. Test the outlet with another appliance. Reset the circuit breaker if necessary.
Weak airflow or overheating.	Blocked air intake filter or vents.	Unplug the dryer and allow it to cool. Clean any lint or debris from the air intake filter and vents.
Hood does not stay up.	Column not fully extended or locked, or mechanism issue.	Ensure the adjustable column is fully extended and securely locked into place. If the issue persists, contact customer support.
Unusual noise during operation.	Debris in the fan, or internal component issue.	Unplug the dryer and inspect for any visible obstructions. If the noise continues, discontinue use and contact customer support.

If the problem persists after trying these solutions, please contact Gold N Hot Customer Support for further assistance.

7. Product Specifications

Feature	Detail
Model Number	GH9271
Brand	Gold N Hot
Wattage	1200 watts
Power Source	Corded Electric
Product Dimensions	12.5 x 14.2 x 14.2 inches
Weight	5 Pounds
Color	Gold
Material	Plastic
UPC	810667011703
Manufacturer	Helen of Troy

8. Warranty and Support

For warranty information, technical support, or service inquiries, please contact the manufacturer, Helen of Troy, directly or refer to the official product website.

Keep your purchase receipt as proof of purchase for any warranty claims.

You can also refer to the official User Manual (PDF) available for download:Download User Manual (PDF)

© 2024 Gold N Hot. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00176QPNM

More documents and user manuals: **https://manuals.plus/**