Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Memorex Mi1111-BLK

Memorex Home Audio System User Manual

Model: Mi1111-BLK

Introduction

Thank you for purchasing the Memorex Home Audio System. This system combines a top-loading CD player, digital AM/FM radio, and an iPod dock, offering versatile audio playback options. Designed for ease of use and quality sound, this manual provides essential information for setup, operation, and maintenance to ensure optimal performance.



Figure 1: Front view of the Memorex Home Audio System (Model Mi1111-BLK) with an iPod connected to the central dock. The system features two main speaker grilles on either side of the central unit, which houses the iPod dock, a digital display, and controls. The base of

the unit emits a subtle blue glow.

Setup Guide

Unpacking and Placement

- Carefully remove all components from the packaging.
- Place the unit on a stable, flat surface away from direct sunlight, heat sources, and moisture.
- Ensure adequate ventilation around the unit.

Power Connection

1. Connect the AC power cord to the AC IN jack on the back of the unit.
2. Plug the other end of the power cord into a standard wall outlet (120V AC, 60Hz).

Antenna Connection (for Radio)

- For FM reception, extend the FM wire antenna fully. For optimal reception, try different positions.
- For AM reception, rotate the unit for the best signal, as the AM antenna is built-in.

Operating Instructions

General Operation

- **Power On/Off:** Press the **POWER** button to turn the unit on or off.
- **Volume Control:** Use the **VOLUME +/-** buttons on the unit or remote control to adjust the sound level.
- **Mode Selection:** Press the **MODE** button to switch between CD, iPod, FM, AM, and AUX modes.

CD Player Operation

1. Press the **OPEN/CLOSE** button to open the CD compartment.
2. Place a CD (label side up) into the compartment and close it.
3. Select CD mode using the **MODE** button.
4. Press the **PLAY/PAUSE** button to start playback.
5. Use the **SKIP** buttons (*forward/backward*) to navigate tracks.

iPod Dock Operation

1. Carefully dock your iPod into the connector on the unit. Ensure it is seated properly.
2. Select iPod mode using the **MODE** button.
3. Playback will typically begin automatically. Use the unit's controls or your iPod's controls for navigation.
4. The iPod will charge while docked and the unit is powered on.

Radio Operation (AM/FM)

1. Select FM or AM mode using the **MODE** button.
2. Press the **TUNE +/-** buttons to manually tune to a station.
3. Press and hold **TUNE +/-** to auto-scan for the next available station.
4. **Preset Stations:** To save a station, tune to it, then press **PROGRAM**. Use **PRESET +/-** to select a preset number, then press **PROGRAM** again to confirm.

Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the unit. Do not use abrasive cleaners or solvents.
- **CD Care:** Handle CDs by their edges. Clean dirty CDs with a soft, lint-free cloth, wiping from the center outwards.
- **Ventilation:** Keep ventilation openings clear of dust and debris to prevent overheating.
- **Storage:** If storing the unit for an extended period, disconnect it from the power outlet.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not securely connected.	Check power cord connection to unit and wall outlet.
No sound	Volume too low; incorrect mode selected.	Increase volume; press MODE button to select correct source.
CD not playing	CD inserted incorrectly; dirty or scratched CD.	Reinsert CD label side up; clean or replace CD.
iPod not playing/charging	iPod not properly docked; incompatible iPod model.	Ensure iPod is firmly seated; refer to iPod compatibility list (if available).
Poor radio reception	Antenna not extended/positioned correctly.	Adjust FM wire antenna; rotate unit for AM reception.

Specifications

Model: Mi1111-BLK

Power Output: 25 Watts

Functions: CD Player, iPod Dock, AM/FM Radio

Dimensions (L x W x H): 15 x 10.5 x 8 inches

Weight: 10.1 pounds

Color: Black

Connectivity: Infrared (for remote control)

Power Source: AC 120V ~ 60Hz

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Memorex website. Keep your purchase receipt as proof of purchase for any warranty claims.
Legal Disclaimer: This product ships to continental USA only.

© 2024 Memorex. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0017Q6HBW

More documents and user manuals: **https://manuals.plus/**