Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BURG-WÄCHTER Combi 90 20 CHROMO SB

BURG-WÄCHTER Combi 90 20 Chromo SB 3-Digit Combination Lock User Manual

1. Introduction

1.1 Product Overview

The BURG-WÄCHTER Combi 90 20 Chromo SB is a robust 3-digit combination lock designed for securing luggage, lockers, bicycles, and other small items. Its durable aluminum body and hardened shackle provide reliable protection. This manual provides instructions for setting your personal combination, operating the lock, and general maintenance.



Image 1: BURG-WÄCHTER Combi 90 20 Chromo SB Combination Lock. This image shows the silver-colored lock with its shackle in the closed position, displaying the three number wheels.

1.2 Package Contents

- 1 x BURG-WÄCHTER Combi 90 20 Chromo SB Combination Lock

2. Safety Information

- Keep out of reach of children.
- Do not attempt to force the lock open as this may damage the mechanism.
- Ensure the combination is correctly aligned before attempting to open or close the lock.
- This lock is designed for general security and deterrence. For high-security applications, consider additional security measures.

3. Setup: Setting Your Personal Combination

Your lock is factory-set to open at**0-0-0**. To set your personal 3-digit combination, follow these steps:

1. Ensure the lock is set to the default combination (0-0-0) and open the shackle by pulling it upwards.
2. Rotate the shackle 90 degrees counter-clockwise from its open position until it aligns with the notch on the lock body.
3. Press the shackle down firmly into the lock body.
4. While holding the shackle down, rotate the number wheels to set your desired 3-digit combination. Make sure the numbers are clearly aligned with the indicator line.
5. Release the shackle. It should pop up slightly.
6. Rotate the shackle back 90 degrees clockwise to its original open position.
7. Scramble the numbers to lock the mechanism. Your new combination is now set.

Important: *Write down your combination and store it in a safe place. If you forget your combination, the lock cannot be reset or opened without it.*

4. Operating the Lock

4.1 Locking

1. Align your set 3-digit combination.
2. Insert the shackle into the lock body.
3. Scramble the numbers on the wheels.

The lock is secure when the shackle cannot be pulled open.

4.2 Unlocking

1. Rotate the number wheels to your personal 3-digit combination. Ensure each number is precisely aligned with the indicator line.
2. Once the correct combination is aligned, pull the shackle upwards to open the lock.

5. Maintenance

The BURG-WÄCHTER Combi 90 20 Chromo SB requires minimal maintenance. To ensure optimal performance and longevity:

- Keep the lock clean and dry. Wipe with a soft, damp cloth if necessary.
- If the number wheels become stiff or difficult to turn, a small amount of graphite lubricant can be applied to the moving parts. Do not use oil-based lubricants as they can attract dirt and dust, potentially hindering the mechanism.
- Avoid exposing the lock to extreme temperatures or corrosive substances.

6. Troubleshooting

- **Lock will not open:**
  - Ensure all three numbers of your combination are perfectly aligned with the indicator line.
  - Try rotating the wheels slightly back and forth to ensure they are not stuck between numbers.
  - If the combination is forgotten, the lock cannot be opened without the correct code.
- **Shackle is stiff or difficult to close:**

- Ensure the combination is correctly set before attempting to close the shackle.
- Check for any obstructions around the shackle or within the lock mechanism.
- Apply a small amount of graphite lubricant if needed (refer to Maintenance section).

7. Specifications

Feature	Detail
Brand	BURG-WÄCHTER
Model	Combi 90 20 CHROMO SB
Lock Type	3-Digit Combination
Material	Aluminum
Shackle Strength	3.2 mm
Horizontal Shackle Length	9 mm
Vertical Shackle Length	22 mm
Total Height	55 mm
Item Dimensions (L x W x H)	2.17 x 0.79 x 0.59 inches
Item Weight	27 g
Color	Silver

8. Warranty and Support

For warranty information and technical support, please contact BURG-WÄCHTER customer service through their official website or your point of purchase. Please have your product model number (Combi 90 20 CHROMO SB) and purchase details available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B001B4OB40

More documents and user manuals: **https://manuals.plus/**