Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool 280159

Whirlpool 280159 Spring User Manual

Model: 280159

1. Introduction

This document provides essential information for the Whirlpool 280159 Spring. This component is a genuine replacement part designed for specific Whirlpool appliance models.

The Whirlpool 280159 Spring is a critical component in various Whirlpool appliances, primarily dryers and washers, where it helps maintain tension or support for moving parts.





Figure 1: The Whirlpool 280159 Spring. This image displays the metallic spring with hooks at both ends, designed for tension or support within an appliance.

2. Safety Information

Important Safety Instructions:

- Always disconnect power to the appliance before attempting any repairs or part replacements.
- Wear appropriate personal protective equipment (PPE), such as gloves and eye protection, when handling appliance components.
- If you are unsure about the installation process, it is recommended to consult a qualified appliance repair technician.
- Keep small parts away from children.
- Ensure the replacement part is correctly installed to prevent damage to the appliance or injury.

3. Compatibility

The Whirlpool 280159 Spring is compatible with the following Whirlpool appliance models:

- Whirlpool WFW8300SW00

- Whirlpool WFW8300SW01
- Whirlpool WFW8300SW02
- Whirlpool WFW9250WL
- Whirlpool WFW9250WW

Please verify your appliance's model number before purchasing or installing this part to ensure proper fit and function.

4. Installation Instructions

This section provides general guidance for replacing a spring in an appliance. Specific installation steps may vary depending on the appliance model and the spring's location.

1. **Preparation:** Disconnect the appliance from its power source. If it's a gas appliance, turn off the gas supply.
2. **Access:** Carefully open or disassemble the necessary panels of your appliance to gain access to the spring that needs replacement. Refer to your appliance's specific service manual for detailed access instructions.
3. **Removal:** Note the orientation and attachment points of the old spring. Use appropriate tools (e.g., pliers, spring puller) to safely remove the old spring. Be cautious as springs can release tension suddenly.
4. **Installation of New Spring:** Position the new Whirlpool 280159 Spring in the same orientation as the old one. Attach one end of the spring first, then carefully stretch and attach the other end to its designated anchor point. Ensure it is securely fastened.
5. **Reassembly:** Reassemble any panels or components that were removed.
6. **Testing:** Reconnect power to the appliance and test its function to ensure the new spring is working correctly and the appliance operates as expected.

Note: *For complex installations, professional assistance is recommended.*

5. Specifications

Attribute	Detail
Part Number	280159
Brand	Whirlpool
Item Weight	11.2 ounces
Product Dimensions	6 x 4 x 6 inches
Color	White
Material	ABS
Country of Origin	United States

Note on Specifications: While the product specifications list 'White' for color and 'ABS' for material, the visual appearance of the spring (as shown in Figure 1) indicates a metallic construction and a gray color, which is typical for appliance springs.

6. Care and Maintenance

The Whirlpool 280159 Spring is designed for durability and requires minimal maintenance once installed correctly.

- Periodically inspect the spring for signs of wear, corrosion, or damage during routine appliance maintenance.

- If the spring appears stretched, broken, or corroded, it should be replaced to ensure proper appliance function.
- Keep the area around the spring clean and free from debris that could impede its movement or cause premature wear.

7. Warranty and Support

For information regarding the warranty of the Whirlpool 280159 Spring, please refer to the original appliance's warranty documentation or contact Whirlpool customer support directly.

Whirlpool Customer Support:

For technical assistance or to locate authorized service centers, visit the officialWhirlpool Owners website.

You may also find helpful resources and FAQs on theWhirlpool Brand Store on Amazon.

This manual is for informational purposes only. Whirlpool is not responsible for any damage or injury resulting from improper installation or use of this product.

© 2025 Whirlpool Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B001DPXWR4

More documents and user manuals: **https://manuals.plus/**