Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gold N Hot GO-GH2274

Gold N Hot Professional 1875-Watt Dryer

MODEL: GO-GH2274

Product Overview

The Gold N Hot Professional 1875-Watt Salon Hair Dryer is engineered to provide a salon-quality drying experience for all hair types. This appliance delivers fast-drying performance while actively helping to reduce over-styling damage, resulting in smooth, shiny hair. It features 1875-watts for powerful airflow and efficient styling. The dryer offers three speed and heat setting combinations, providing full styling versatility. Two handy styling attachments are included: a double pik for gentle detangling and an air concentrator for focused airflow and sleek, consistent results. A cool shot button is integrated to set finished styles for long-lasting hold. The removable end cap facilitates easy maintenance, prolonging the dryer's lifespan. Its universal dual voltage makes it an ideal travel companion.

Key Features

- Fast-drying performance helps reduce over-styling damage.
- Three speed/heat setting combinations provide full styling versatility.
- Includes two styling attachments: double pik and air concentrator for precise styling.
- Cool shot button for long-lasting hold.
- Features universal Dual Voltage ideal for travel.

Important Safety Instructions

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- Always unplug the appliance immediately after using.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended household use as described in this manual. Do not use attachments not

recommended by the manufacturer.

- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces. Do not pull, twist, or wrap cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not direct hot air toward eyes or other heat-sensitive areas.
- Attachments may be hot during use. Allow them to cool before handling.
- Do not place appliance on any surface while it is operating.
- While using the appliance, keep your hair away from the air inlets.

Setup Guide

1. **Unpack the Dryer:** Carefully remove the Gold N Hot Professional 1875-Watt Dryer and all accessories from the packaging.
2. **Inspect Contents:** Verify that all components are present: the hair dryer unit, the double pik attachment, and the air concentrator attachment.
3. **Check for Damage:** Before first use, inspect the dryer and its cord for any visible damage. Do not use if damaged.
4. **Choose an Attachment (Optional):** If desired, attach either the double pik or the air concentrator to the nozzle of the dryer by aligning it and pushing it firmly into place.
5. **Plug In:** Insert the polarized plug into a suitable electrical outlet. Ensure the voltage matches your local power supply (universal dual voltage is supported).



Image: Gold N Hot Professional 1875-Watt Dryer with included styling pik and air concentrator attachments.

Operating Your Hair Dryer

1. **Power On:** Slide the power switch to the desired speed setting (Low or High).
2. **Select Heat Setting:** Adjust the heat switch to your preferred temperature (Cool, Warm, or Hot).
3. **Styling:** Direct the airflow towards your hair, maintaining a safe distance to prevent heat damage. Use the double pik for detangling and lifting, or the air concentrator for precise styling and smoothing.
4. **Cool Shot:** Press and hold the cool shot button to deliver a burst of cool air, which helps to set your style and add shine. Release the button to return to the selected heat setting.
5. **Power Off:** When finished, slide the power switch to the 'OFF' position and unplug the dryer from the electrical outlet.

Care and Maintenance

- **Cleaning the Filter:** Regularly clean the air intake filter at the rear of the dryer. Twist or pull off the removable end cap. Use a soft brush or vacuum cleaner to remove any accumulated lint, dust, or hair. Replace the cap securely. A clean filter ensures optimal performance and extends the life of the dryer.
- **Exterior Cleaning:** Wipe the exterior of the dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the dryer in a cool, dry place. Do not wrap the cord around the dryer, as this can cause damage to the cord. Use the hanging ring for convenient storage.

Troubleshooting Common Issues

Problem	Possible Cause	Solution
Dryer does not turn on.	No power to the outlet; GFCI tripped; damaged cord/plug.	Check power outlet; reset GFCI; inspect cord for damage (do not use if damaged).
Low airflow or overheating.	Blocked air intake filter.	Clean the air intake filter as described in the Maintenance section.
Dryer suddenly stops during use.	Overheating protection activated.	Unplug the dryer and allow it to cool down for several minutes. Check and clean the air filter.

Technical Specifications

Specification	Value
Brand	Gold N Hot
Model Number	GO-GH2274
Wattage	1875 watts
Power Source	Corded Electric
Product Dimensions	10.19 x 10.25 x 4 inches
Item Weight	1 Pound
Color	Gold
Material	Plastic
UPC	810667015763

Specification	Value
Manufacturer	Helen of Troy

Warranty and Customer Support

This Gold N Hot product comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration of coverage. For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact Gold N Hot customer support. Contact information can typically be found on the product packaging or the official Gold N Hot website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question