JVC LP20337-002

JVC Remote Control Unit LP20337-002 Instruction Manual

Model: LP20337-002

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your JVC Remote Control Unit, model LP20337-002. Please read this manual carefully before using the remote control to ensure proper functionality and to maximize its lifespan. This remote is designed for multi-brand compatibility with various JVC and other compatible electronic devices.

Product Overview



Image: Front view of the JVC Multi-Brand Remote Control Unit LP20337-002. The remote is black with white and grey buttons, featuring a standard layout including number keys, channel and volume controls, playback buttons, and dedicated function keys for TV, VCR, and other devices.

The JVC Remote Control Unit LP20337-002 is an infrared (IR) remote designed for ergonomic use. It features a button control interface, allowing for intuitive command over your entertainment system. Key areas include the power and input selection buttons at the top, a numeric keypad for direct channel access, and dedicated sections for programming, playback controls, and menu navigation.

Setup

Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two (2) AAA batteries (not included), ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

Initial Pairing/Programming

This remote control is a multi-brand unit and may require programming to operate your specific devices. Refer to the device's original manual for specific remote codes or follow these general programming steps:

1. **Identify Device Type:** Press the corresponding device button (e.g.,**TV**, **CABLE/DBS**, **TV/VCR**) at the top of the

remote. The indicator light for the selected device should illuminate.

2. **Enter Programming Mode:** Press and hold the **SET** button (if available, or a combination like **SET + Device Button**) until the indicator light stays lit.
3. **Enter Code:** Input the 3 or 4-digit code for your device's brand using the numeric keypad. Codes are typically found in a code list provided with universal remotes.
4. **Test Functionality:** Point the remote at your device and test basic functions like **POWER**, **CHANNEL**, and **VOLUME**. If the device responds, the programming is successful.
5. **Auto Code Search (if manual code fails):** If you cannot find a code or the device does not respond, the remote may have an auto code search function. Typically, this involves holding the **SET** button and repeatedly pressing the **POWER** button until the device turns off.

Operating Instructions

Basic Functions

- **POWER:** Turns the selected device on or off.
- **TV** / **CABLE/DBS** / **TV/VCR:** Selects the device to be controlled.
- **Numeric Keypad (0-9):** Used for direct channel entry or code input during programming.
- **CH +** / **CH -:** Changes channels up or down.
- **VOL +** / **VOL -:** Increases or decreases the volume.
- **MUTE:** Mutes or unmutes the audio.
- **MENU:** Accesses the on-screen menu of the selected device.
- **OK:** Confirms selections within the menu.
- **REW** / **PLAY** / **FF** / **STOP** / **PAUSE** / **REC:** Standard playback controls for VCRs or other media players.

Advanced Functions

- **EXPRESS PROGRAMMING (START, STOP, DATE, CH):** These buttons are typically used for quick timer programming on VCRs or DVRs. Refer to your device's manual for specific instructions on using these features.
- **PROG.** / **PROG. CHECK** / **SP/EP** / **SKIP SEARCH:** These functions are specific to VCR or DVR programming and playback.
- **SHUTTLE PLUS:** This feature allows for variable speed playback (fast forward/rewind) or frame-by-frame advancement on compatible devices.
- **C.RESET** / **CANCEL:** Resets or cancels current operations or settings.
- **AUX:** May be used to control an auxiliary device or for specific programming functions.
- **TIMER:** Activates or sets timer functions on compatible devices.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's range decreases or buttons become unresponsive. Always replace all batteries at the same time with new ones of the same type. Do not mix old and new batteries or different battery types.

- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage.

Troubleshooting

- **Remote not working:**
  - Check battery polarity and ensure batteries are fresh.
  - Ensure there are no obstructions between the remote and the device's IR sensor.
  - Verify the remote is programmed correctly for the device you are trying to control.
- **Only some buttons work:**
  - This may indicate incorrect programming for certain functions or a partial code match. Try reprogramming the remote with a different code for your device.
- **Device not responding to commands:**
  - Ensure the correct device mode (TV, VCR, etc.) is selected on the remote.
  - Check the device itself to ensure it is powered on and functioning correctly.

Specifications

Feature	Detail
Model	LP20337-002
Brand	JVC
Connectivity Technology	Infrared
Controller Type	Button Control
Special Feature	Ergonomic
Item Weight	10.4 ounces
Package Dimensions	7 x 2.2 x 2.2 inches

Warranty and Support

Specific warranty information for the JVC Remote Control Unit LP20337-002 is not provided in this manual. For details regarding warranty coverage, technical support, or to obtain a list of compatible device codes, please refer to the original product packaging or contact JVC customer support directly through their official website or contact channels.
No official product videos from the seller were available for inclusion in this manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question