Nuova Simonelli MAPPI13VOL02ND0001

Nuova Simonelli Appia Vol 2 Group Espresso Machine User Manual

Model: MAPPI13VOL02ND0001

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your Nuova Simonelli Appia Vol 2 Group Espresso Machine. Adhering to these instructions will ensure optimal performance, longevity, and safety of the appliance. Please read this manual thoroughly before using the machine.

The Nuova Simonelli Appia Vol 2 Group Espresso Machine is designed for professional use, offering volumetric dosing for consistent espresso extraction and robust construction for demanding environments.



Image 1.1: Front view of the Nuova Simonelli Appia Vol 2 Group Espresso Machine, showcasing its two group heads, steam wands, and control panel.

2. Safety Information

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- **Electrical Safety:** Ensure the machine is connected to a properly grounded power outlet. Do not operate with a damaged power cord. Disconnect power before cleaning or servicing.
- **Hot Surfaces:** The machine's surfaces, group heads, steam wands, and hot water dispenser become very hot during operation. Avoid direct contact to prevent burns.
- **Water Pressure:** Ensure water supply connections are secure and meet specified pressure requirements.
- **Children and Training:** Keep children away from the machine. Only trained personnel should operate this equipment.
- **Ventilation:** Ensure adequate ventilation around the machine to prevent overheating.

3. Unpacking and Installation

3.1 Unpacking

1. Carefully remove the machine from its packaging. Retain packaging for future transport or storage.
2. Inspect the machine for any signs of damage incurred during transit. Report any damage to your supplier immediately.
3. Remove all protective films and packing materials.

3.2 Placement

Place the espresso machine on a stable, level, and heat-resistant surface capable of supporting its weight (approximately 165 pounds). Ensure there is sufficient clearance around the machine for ventilation and access for maintenance.



Image 3.1: Top view of the espresso machine, showing the cup warming area. Ensure adequate space above for heat dissipation.

3.3 Water Connection

Connect the machine to a potable water supply using the provided flexible hose. It is recommended to install a water filter and softener system to protect the machine from scale buildup and improve coffee quality. Ensure the water pressure is within the manufacturer's specified range (typically 2-4 bar).

3.4 Electrical Connection

Connect the machine to a dedicated, grounded electrical outlet that matches the voltage and amperage requirements specified on the machine's rating plate. Consult a qualified electrician if unsure.

3.5 Initial Startup

1. Ensure water supply is open.
2. Turn on the main power switch. The boiler will automatically begin to fill.
3. Allow the machine to heat up until the pressure gauge indicates optimal operating pressure (typically 0.8-1.2 bar). This may take 15-30 minutes.
4. Purge each group head and steam wand by running a small amount of water/steam to remove any air.

4. Operating Instructions

4.1 Control Panel Overview

The control panel features buttons for each group head, allowing for volumetric dosing. Typically, there are buttons for single espresso, double espresso, and continuous flow, along with a hot water button and steam levers.

4.2 Brewing Espresso

1. Insert the portafilter with ground coffee into the group head and lock it into place.
2. Place your cup(s) under the portafilter spouts.
3. Press the desired volumetric button (e.g., single or double shot). The machine will automatically dispense the programmed amount of espresso and stop.
4. For manual control, press the continuous flow button to start and press it again to stop.

4.3 Steaming Milk

1. Purge the steam wand briefly to remove any condensed water.
2. Immerse the steam wand tip into a pitcher of cold milk.
3. Open the steam valve fully to begin steaming.

4. Once the desired temperature and texture are achieved, close the steam valve.
5. Immediately wipe the steam wand with a damp cloth and purge again to clear any milk residue.

4.4 Hot Water Dispensing

Place a cup under the hot water spout and press the hot water button or open the hot water valve. Close the button/valve when the desired amount of hot water is dispensed.

5. Maintenance

Regular maintenance is crucial for the performance and longevity of your espresso machine.

5.1 Daily Cleaning

- **Group Heads:** Backflush each group head using a blind filter and espresso machine cleaner. Follow the cleaner manufacturer's instructions.
- **Portafilters:** Remove and clean portafilters and baskets thoroughly.
- **Steam Wands:** Wipe immediately after each use and purge. At the end of the day, soak tips in a solution of steam wand cleaner if necessary.
- **Drip Tray and Grids:** Empty and clean the drip tray and grids.
- **Exterior:** Wipe down the exterior with a damp cloth. Do not use abrasive cleaners.

5.2 Weekly/Monthly Cleaning

- **Shower Screens and Gaskets:** Remove and clean the shower screens and group head gaskets. Replace gaskets if they appear worn or cracked.
- **Water Filter:** Check and replace the water filter cartridge as recommended by the filter manufacturer (typically every 3-6 months, depending on water usage and quality).

6. Troubleshooting

This section addresses common issues you might encounter. For problems not listed here, contact qualified service personnel.

Problem	Possible Cause	Solution
No water flow from group head	Water supply off, clogged group head, pump issue	Check water supply, backflush group head, contact service
Machine not heating up	Power issue, heating element failure, low water level in boiler	Check power connection, ensure automatic boiler fill is working, contact service
Weak or no steam	Clogged steam wand, low boiler pressure	Clean steam wand tip, allow machine to reach full pressure
Espresso extracts too fast/slow	Grind size incorrect, tamping pressure inconsistent	Adjust grinder settings, ensure consistent tamping

7. Specifications

- **Model Name:** Nuova Simonelli Appia Vol 2 Group Espresso Machine

- **Model Number:** MAPPI13VOL02ND0001
- **Brand:** Nuova Simonelli
- **Coffee Maker Type:** Espresso Machine
- **Operation Mode:** Fully Automatic (Volumetric)
- **Number of Groups:** 2
- **Boiler Capacity:** 11 litres
- **Special Features:** Volumetric dosing, Automatic boiler fill
- **Exterior Finish:** Stainless Steel
- **Product Dimensions:** 31 x 22 x 21 inches (Length x Width x Height)
- **Item Weight:** 165 pounds
- **Input Type:** Ground Coffee
- **Human Interface Input:** Buttons

8. Warranty and Support

The Nuova Simonelli Appia Vol 2 Group Espresso Machine comes with a**Lifetime Warranty on the Boiler**, ensuring long-term reliability for this critical component. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact your authorized Nuova Simonelli dealer.

For technical support, service, or spare parts, please contact your local Nuova Simonelli distributor or authorized service center. Always provide the model number (MAPPI13VOL02ND0001) and serial number of your machine when seeking assistance.

© 2023 Nuova Simonelli. All rights reserved. Information in this manual is subject to change without notice.