Spinbrush PRO CLEAN 20500999

Spinbrush PRO CLEAN 20500999 Battery Powered Toothbrush Instruction Manual

Model: PRO CLEAN 20500999 | Brand: Spinbrush

Introduction

The Spinbrush PRO CLEAN Battery Powered Toothbrush is designed to provide effective oral hygiene. This manual provides essential information for the proper setup, operation, and maintenance of your new toothbrush.
The dual-action power toothbrush head is clinically proven to remove up to 70% more plaque in hard-to-reach places compared to a manual toothbrush. Its soft bristles are ADA Accepted and help reduce plaque and prevent gingivitis.





Image: Spinbrush PRO CLEAN Battery Powered Toothbrush, showing the product in its retail packaging.

Key Features

- **Dual Action Brush Head:** Features an oscillating circle (spinner) and a sliding plate (scrubber) for comprehensive cleaning.
- **Plaque Removal:** Removes up to 70% more plaque in hard-to-reach areas compared to a manual toothbrush.
- **Soft Bristles:** ADA Accepted soft bristles are clinically proven to help remove plaque and reduce gingivitis.
- **Color-Wear Bristles:** Bristles fade over time to indicate when it's time to replace the brush head.
- **Replaceable Brush Heads:** Designed for cost-effectiveness and reduced plastic waste.
- **Battery Powered:** Operates on 2 AA batteries (included).
- **Ergonomic Design:** Comfortable to hold and use.

- **Soft Switch Power Buttons:** Easier to turn on/off and designed to prevent water from leaking inside the brush.

Setup

Battery Installation

Your Spinbrush PRO CLEAN toothbrush requires two (2) AA batteries for operation. These batteries are included with your purchase.

1. Gently twist the bottom cap of the toothbrush handle counter-clockwise to open the battery compartment.
2. Insert two fresh AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
3. Replace the bottom cap by twisting it clockwise until securely fastened.

For optimal performance, use new AA alkaline batteries.



Image: The Spinbrush PRO CLEAN toothbrush handle with AA batteries, illustrating the battery compartment.

Operating Instructions

To use your Spinbrush PRO CLEAN toothbrush, simply follow these steps:

1. Wet the brush head and apply a small amount of toothpaste.
2. Press the top power button (Soft Switch) to turn the toothbrush on.
3. Gently guide the brush along your teeth and gum line. The dual-action head will do the work, with the oscillating circle spinning and the sliding plate scrubbing.
4. Brush for a dentist-recommended two minutes, ensuring all areas of your mouth are cleaned.
5. Press the bottom power button (Soft Switch) to turn the toothbrush off.
6. Rinse the brush head thoroughly after each use and shake off excess water.



Image: A diagram illustrating the dual-action movement of the brush head, with an oscillating circle and vertical scrubbing motion.

The Spinbrush PRO CLEAN is designed to remove plaque effectively, reaching areas a manual brush might miss.



Image: A graphic representation of the Spinbrush removing plaque from a tooth surface.

Maintenance

Brush Head Replacement

For optimal cleaning and hygiene, it is recommended to replace your brush head every 3 months, or sooner if the bristles appear worn. The Spinbrush PRO CLEAN features Color-Wear bristles that fade over time to help remind you when a replacement is due.

1. To remove the old brush head, firmly grasp the handle and pull the brush head straight up and off.
2. Align the new replacement brush head with the handle and push it down firmly until it clicks into place.

Replacement brush heads are available for purchase separately. Keeping your handle and replacing only the brush head helps save money and plastic.



Image: A visual guide demonstrating the Color-Wear bristles fading to indicate replacement and the process of changing the brush head.



Image: Packaging for Spinbrush PRO CLEAN replacement heads, available in soft and medium bristles.

Safety Information

- For adult use only.
- Keep out of reach of children.
- Replace brush head carefully to avoid injury.
- Do not brush with damaged or loose parts. Failure to change brush head could lead to breakage, generation of small parts, and possible injury.

Specifications

Feature	Detail

Feature	Detail
Model Number	20500999
Power Source	Battery Powered (2 AA batteries included)
Bristle Firmness	Soft
Age Range	Adult
Special Feature	Ergonomic Design
Product Dimensions	2.13 x 1.5 x 9.1 inches
Item Weight	4.5 ounces
UPC	0766878000787

Official Product Video

Watch this video for an overview of Spinbrush products, including the PRO CLEAN, highlighting features and benefits.

Your browser does not support the video tag.

Video: Spinbrush Smart Clean Portfolio video by Church & Dwight, showcasing various Spinbrush products and their features.

Support

For further assistance or inquiries, please contact Spinbrush customer support:

- **Phone:** 1-800-561-0752 (M-F 9am to 5pm ET)
- **Website:** www.spinbrush.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question