Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC KS-U30

JVC KS-U30 USB Video Cable User Manual

Model: KS-U30

Product Overview

The JVC KS-U30 USB Video Cable is designed to connect your iPod or iPhone to select 2008-up JVC receivers. This cable enables both audio and video playback from your device directly through the JVC receiver, while also providing charging capabilities for your iPod/iPhone.



Figure 1: JVC KS-U30 USB Video Cable showing its various connectors.

Key Features

- Enables iPod/iPhone audio and video playback on compatible JVC receivers.
- Provides charging for connected iPod/iPhone devices.
- USB Connection Cable for use with select JVC receivers.
- Features front-panel auxiliary input compatibility.

Setup and Installation

1. **Identify Ports:** Locate the USB port and the auxiliary input (RCA video and audio L/R) on your compatible JVC receiver.
2. **Connect to Receiver:**
    - Plug the USB connector of the KS-U30 cable into the USB port on your JVC receiver.
    - Connect the yellow RCA plug to the video input, and the red and white RCA plugs to the corresponding audio L/R inputs on your receiver.
3. **Connect to iPod/iPhone:** Plug the 30-pin connector of the KS-U30 cable into the dock connector port of your iPod or iPhone.
4. **Power On:** Ensure your JVC receiver is powered on. The connected iPod/iPhone should begin charging and be recognized by the receiver.

Note: For optimal performance, ensure your JVC receiver's firmware is up to date and that your iPod/iPhone is running a compatible iOS version. Refer to your JVC receiver's manual for specific auxiliary input and USB connection settings.

Operating Instructions

Once the JVC KS-U30 cable is properly connected, you can control audio and video playback directly from your JVC receiver's interface. The cable facilitates the transfer of both audio and video signals, allowing you to enjoy content from your iPod/iPhone on your car's display and sound system.

- **Audio Playback:** Navigate through your iPod/iPhone's music library using the JVC receiver's controls. Play, pause, skip tracks, and browse playlists as you would with other connected media.
- **Video Playback:** Select video content from your iPod/iPhone. The video will display on the JVC receiver's screen. Ensure your vehicle is in a safe parking position if watching videos, as some receivers may restrict video playback while driving for safety reasons.
- **Charging:** The connected iPod/iPhone will charge automatically when the JVC receiver is powered on.
- **App Link/Control Mode:** For advanced features like App Link or specific control modes (e.g., "External" control for certain apps like Motion X GPS or streaming services), consult your JVC receiver's user manual for detailed instructions on how to enable and utilize these functions.

Your browser does not support the video tag.

Video 1: An official JVC promotional video showcasing JVC Mobile Entertainment products, including features like iPod/iPhone connectivity and video playback on head units, which the KS-U30 cable facilitates.

Maintenance

Proper maintenance of your JVC KS-U30 cable will ensure its longevity and reliable performance.

- **Storage:** When not in use, store the cable in a clean, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or kinking the cable, as this can damage the internal wires.
- **Cleaning:** Gently wipe the cable and connectors with a soft, dry cloth to remove dust or debris. Do not use liquid cleaners or abrasive materials.
- **Handling:** Always grasp the connector ends when plugging or unplugging the cable. Avoid pulling on the cable itself, as this can strain the connections and lead to damage.

Troubleshooting

Problem	Possible Cause	Solution
No audio or video output.	Incorrect connection; incompatible JVC receiver; incorrect source selection on receiver; damaged cable.	Ensure all connectors are securely plugged in. Verify your JVC receiver model is compatible with the KS-U30. Select the correct auxiliary or USB input source on your receiver. Inspect the cable for visible damage; replace if necessary.
iPod/iPhone not charging.	Receiver not powered on; loose USB connection; device not recognized.	Confirm the JVC receiver is powered on. Re-seat the USB connector firmly. Try disconnecting and reconnecting the iPod/iPhone.
Video playback issues (e.g., distorted, no picture).	Loose RCA video connection; incompatible video format; safety lockout.	Check the yellow RCA video connection. Ensure the video format on your device is supported by the receiver. Note that video playback may be restricted while the vehicle is in motion.
Intermittent connection.	Damaged cable; dirty connectors; loose connection.	Inspect the cable for internal breaks or frayed wires. Clean connectors gently. Ensure all connections are tight.

Specifications

Brand: JVC

Model: KS-U30

Connector Type: USB, RCA (Video, Audio L/R), 30-pin Apple Dock Connector

Cable Type: USB Video Cable

Compatible Devices: iPod, iPhone (select models, generally 2008-up JVC receivers)

Color: Black

Item Weight: Approximately 6 pounds (Note: This weight seems unusually high for a cable and might be a data error, but it's taken from the provided spec.)

Product Dimensions: 6 x 11 x 9 inches (Note: These dimensions seem to describe packaging or a larger item, not just the cable itself, but it's taken from the provided spec.)

Warranty and Support

The JVC KS-U30 USB Video Cable comes with a one-year limited warranty from the manufacturer.
For warranty claims, technical support, or further assistance, please contact JVC customer service or visit the official JVC website. Keep your proof of purchase for warranty validation.
You can find more information and support resources on the official JVC website: www.jvc.com

© 2024 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B001PL5SU0

More documents and user manuals: **https://manuals.plus/**