Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Disney B001Q3KQ68

High School Musical 1-3 DVD Set Instruction Manual

Model: B001Q3KQ68

Product Overview

This manual provides instructions for the High School Musical 1-3 DVD set, featuring the complete trilogy of the popular musical films. The set includes three individual DVDs: *High School Musical: Encore Edition*, *High School Musical 2: Extended Edition*, and *High School Musical 3: Senior Year*.



Image: The High School Musical 1-3 DVD set, displaying the covers of the three individual DVD cases. From left to right: High School Musical Encore Edition, High School Musical 2 Extended Edition, and High School Musical 3 Senior Year.

Setup and System Requirements

To enjoy the High School Musical 1-3 DVD set, ensure your playback device meets the following requirements:

- **DVD Player:** A standard DVD player compatible with NTSC format discs.
- **Television/Monitor:** A display device with appropriate input connections for your DVD player.
- **Audio System:** For optimal audio experience, a system supporting Dolby Digital 5.1 is recommended.
- **Region Compatibility:** These DVDs are typically Region 1 (North America) encoded. Ensure your DVD player is compatible with this region or is region-free.

Installation: No complex installation is required. Simply insert the desired DVD into your compatible DVD player.

Operating Instructions

Each DVD in the High School Musical 1-3 set offers unique content and bonus features. Follow these general steps for playback:

1. **Power On:** Turn on your DVD player and television/monitor.
2. **Insert Disc:** Gently insert the desired High School Musical DVD into the disc tray of your DVD player with the label side facing up.
3. **Menu Navigation:** Once the disc loads, the main menu will appear. Use your DVD player's remote control (arrow keys, Enter/OK button) to navigate through options such as "Play Movie," "Scene Selection," "Bonus Features," and "Language Settings."
4. **Language and Subtitles:** Access the "Language" or "Audio" menu to select English (Dolby Digital 5.1) or German (Dolby Digital 5.1) audio tracks. Subtitles in German may also be available.
5. **Bonus Features:** Explore the "Bonus Features" section for additional content specific to each film.

Disc-Specific Content:

High School Musical: Encore Edition

This edition includes the original film and a sing-along version. It features Troy (Zac Efron) and Gabriella (Vanessa Anne Hudgens) auditioning for the school musical, challenging East High's social norms.
Bonus Features:

- Original & Sing-Along Versions Of The Movie
- Learning The Moves Featurette Led By Director/Choreographer Kenny Ortega
- Never-Before-Seen Music Video "I Can't Take My Eyes Off Of You"
- "We're All In This Together" Music Video
- Behind-The-Scenes Featurette

High School Musical 2: Extended Edition

The Wildcats take on summer jobs at the Lava Springs Country Club. This edition includes an extended version of the film.
Bonus Features:

- Bloopers

- Rehearsal Cam: Watch The Dance Rehearsal Footage Along With The Movie
- High School Karaoke: Sing The Lead Vocals With Help From Optional On-Screen Lyrics
- Music Videos

High School Musical 3: Senior Year

The senior year for the East High Wildcats, as they prepare for graduation and a spring musical reflecting their future hopes and fears.
Bonus Features:

- Extended Version: Bigger Than Ever With Additional Scenes
- Deleted Scenes With Introductions By Director Kenny Ortega
- HSM 3 Bloopers: Get Ready To LOL With The Cast!
- Night Of Nights Prom Scene Tell-All With The Cast
- It's All In The Dress: The Ladies Of East High Dish On Prom Dresses
- Sing-Along Mode: Get In Tune With The Wildcats!
- Cast Goodbyes: The Cast Of HSM 3 Bids An Emotional Farewell To East High
- DisneyFile Digital Download Copy Disc

Maintenance and Care

Proper care of your DVDs will ensure their longevity and optimal playback quality:

- **Handling:** Always hold discs by their edges or by placing a finger through the center hole. Avoid touching the playback surface.
- **Cleaning:** If a disc becomes dirty or smudged, gently wipe it with a soft, lint-free cloth (e.g., microfiber) from the center outwards in a straight line. Do not wipe in circular motions. Use a specialized disc cleaning solution if necessary, but avoid harsh chemicals.
- **Storage:** Store discs in their original cases in a cool, dry place away from direct sunlight, extreme temperatures, and humidity.
- **Avoid Scratches:** Do not place discs on rough surfaces or stack them without their cases.

Troubleshooting

If you encounter issues while playing your High School Musical DVDs, consider the following common solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Disc does not play or skips	Dirty or scratched disc; incompatible region code; DVD player malfunction.	Clean the disc gently. Inspect for deep scratches. Ensure your DVD player is region-compatible. Try the disc in another DVD player to rule out player issues.
No audio or distorted audio	Incorrect audio settings; loose audio cables; TV/receiver volume too low.	Check audio settings on the DVD menu and your player. Ensure all audio cables are securely connected. Increase volume on your TV or audio receiver.
No picture or distorted picture	Loose video cables; incorrect input selection on TV; TV/monitor malfunction.	Verify video cables are securely connected. Ensure your TV is set to the correct input source (e.g., HDMI 1, AV). Try another video source to check TV functionality.
Remote control not working	Dead batteries; obstructed sensor; remote malfunction.	Replace batteries. Ensure no objects are blocking the line of sight between the remote and the DVD player's sensor.

If problems persist after attempting these solutions, consult your DVD player's instruction manual or contact the manufacturer of your DVD player for further assistance.

Specifications

Product Title	High School Musical 1-3
Model Number	B001Q3KQ68
Brand	Walt Disney Video
Media Format	DVD, NTSC
Number of Discs	3
Total Run Time	4 hours and 54 minutes
Audio Languages	English (Dolby Digital 5.1), German (Dolby Digital 5.1)
Subtitles	German
Release Date	February 17, 2009
Actors	Zac Efron, Vanessa Hudgens, Ashley Tisdale, Corbin Bleu
Director	Kenny Ortega
Genre	Music Videos & Concerts, Musicals
Package Dimensions	7.4 x 5.4 x 1.7 inches
Package Weight	8 ounces

Warranty and Support

This product is a media item (DVD set). Specific warranty information for media content typically falls under the retailer's return policy for defective items rather than a manufacturer's warranty for electronic components.
For issues with defective discs (e.g., disc not playing due to manufacturing defect), please refer to the return and exchange policy of the retailer from whom you purchased the product. Keep your proof of purchase.
For general inquiries about the High School Musical series or Disney products, you may visit the official Disney website or contact their customer service department.
Note: This manual pertains to the DVD set itself. For technical support related to your DVD player or television, please consult their respective instruction manuals or manufacturer support.

© 2025 Disney. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B001Q3KQ68

More documents and user manuals: **https://manuals.plus/**