Conair 245WGN

Conair Mini Travel Hair Dryer Model 245WGN Instruction Manual

Your guide to on-the-go styling with ease.

1. Product Overview

The Conair Mini Travel Hair Dryer Model 245WGN is designed for convenient, on-the-go styling. This compact hair dryer delivers 1200 watts of drying power, featuring Tourmaline Ceramic Technology to help reduce frizz and enhance shine. Its dual voltage capability makes it suitable for worldwide travel. The set includes a concentrator, a diffuser, and a storage pouch for easy portability.



Image 1.1: The Conair Mini Travel Hair Dryer, a compact and powerful styling tool.

2. Important Safety Instructions

WARNING: To reduce the risk of electric shock, fire, or injury:

- Keep out of reach of children.
- Do not use while bathing or in a shower.
- Keep the power plug and cord away from heated surfaces.
- Always unplug the appliance immediately after using and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged.

- Do not block the air openings or place on a soft surface where the air openings may be blocked.

3. Setup and Assembly

3.1 Unpacking

Carefully remove the hair dryer and all accessories from the packaging. Ensure all components are present: the hair dryer unit, concentrator nozzle, diffuser, and storage pouch.

3.2 Attaching Accessories

The concentrator and diffuser attachments can be easily attached to the front nozzle of the hair dryer. Align the attachment with the nozzle and push firmly until it clicks into place. To remove, gently pull the attachment off.



Image 3.1: The hair dryer with the concentrator nozzle attached for precise airflow.



Image 3.2: The hair dryer with the diffuser attachment, ideal for enhancing natural curls and waves.

3.3 Dual Voltage Setting

This hair dryer features dual voltage for international travel. Before plugging in, ensure the voltage switch (usually located on the handle) is set to the correct voltage for your region (125V for North America, 250V for most other countries). A coin or small tool may be required to adjust the switch. Failure to set the correct voltage may damage the appliance.

4. Operating Instructions

4.1 Powering On and Off

Plug the hair dryer into an appropriate electrical outlet. Locate the ON/OFF switch on the handle. Slide the switch to the desired setting:

- **OFF:** Turns the appliance off.
- **LOW:** Provides a gentle airflow and lower heat.
- **HIGH:** Provides maximum airflow and heat for faster drying.

4.2 Drying Hair

1. Towel-dry hair to remove excess moisture.
2. Select the desired heat and speed setting.
3. For general drying, use the hair dryer without an attachment or with the concentrator for targeted airflow.
4. For curly or wavy hair, attach the diffuser and gently cup sections of hair, lifting towards the scalp to enhance natural texture.
5. Move the hair dryer continuously to prevent overheating any single section of hair.
6. Once styling is complete, slide the switch to OFF and unplug the appliance.

5. Care and Maintenance

5.1 Cleaning the Air Filter

For optimal performance, the air filter at the rear of the hair dryer should be cleaned regularly. Unplug the hair dryer. Gently twist or pull off the rear filter cover. Use a soft brush or vacuum cleaner to remove any accumulated dust or hair. Replace the filter cover securely.

5.2 General Cleaning

Wipe the exterior of the hair dryer with a damp cloth. Do not use abrasive cleaners or solvents. Ensure the hair dryer is completely dry before storing or using again.

5.3 Storage

When not in use, store the hair dryer in its provided storage pouch in a cool, dry place. Do not wrap the power cord around the hair dryer, as this can cause damage to the cord. Hang or coil the cord loosely.

6. Troubleshooting

Problem	Possible Cause	Solution
Hair dryer does not turn on.	Not plugged in; power outlet malfunction; internal safety cut-off activated.	Ensure plug is fully inserted. Test outlet with another appliance. Unplug, wait 5 minutes for reset, then try again.
Low airflow or overheating.	Blocked air intake filter.	Unplug the hair dryer and clean the rear air filter as described in Section 5.1.

Problem	Possible Cause	Solution
Hair dryer stops working during use.	Overheating protection activated.	Unplug the hair dryer and allow it to cool down for several minutes. Check and clean the air filter.
Unusual noise or smell.	Internal malfunction.	Immediately unplug the hair dryer. Do not attempt to repair. Contact customer support.

7. Product Specifications

Model Number: 245WGN

Wattage: 1200 watts

Power Source: Corded Electric

Voltage: Dual Voltage (125V/250V)

Number of Speeds: 2 (Low, High)

Number of Heat Settings: 2 (Low, High)

Hair Type Compatibility: All, Textured

Included Components: Hair Dryer, Concentrator, Diffuser, Storage Pouch

Dimensions: Approximately 5.51 x 2.67 x 7.7 inches (Product), 7.8"D x 4"W x 10.5"H (Item)

Weight: Approximately 0.68 Pounds (10.88 ounces)

Material Type: Ceramic

Manufacturer: Conair

8. Warranty and Support

8.1 Manufacturer's Warranty

This Conair Mini Travel Hair Dryer Model 245WGN comes with a**Limited Two-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal household use. It does not cover damage resulting from misuse, accidents, alterations, or commercial use. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, warranty service, or product inquiries, please contact Conair Customer Service. Refer to the contact information provided on the product packaging or visit the official Conair website for the most up-to-date support details.

Conair Website: www.conair.com

© 2023 Conair Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question