Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Swiffer

Swiffer Duster Heavy Duty 3 ft Extendable Handle Starter Kit User Manual

Model: 82074

Introduction

The Swiffer Duster Heavy Duty 3 ft Extendable Handle Starter Kit is designed to effectively trap and lock dust, dirt, and allergens from various surfaces. Its extendable handle allows for easy cleaning of hard-to-reach areas, promoting cleaner air in your home. This manual provides essential information for the proper assembly, use, and care of your Swiffer Duster.



Image: The Swiffer Duster Heavy Duty 3 ft Extendable Handle Starter Kit, including the handle and three duster refills.

Safety Information

Please read and understand all safety information before using this product.

- **Keep out of reach of children and pets:** To avoid accidental ingestion or misuse, store the product in a secure location away from children and pets.
- **For cleaning purposes only:** Do not use this product for any purpose other than its intended cleaning

function.

- **Use on cooled surfaces:** This product is not intended for use on hot surfaces. Ensure surfaces are cool before dusting.
- **Avoid anti-glass coated surfaces:** Do not use on wet or anti-glass coated surfaces, as this may affect performance or damage the surface.

Setup and Assembly

Follow these steps to assemble your Swiffer Duster:

1. **Activate or Fluff Dusters:** Hold each end of a duster refill pad and give it a shake to fluff up the fibers. This prepares the duster to effectively trap dust.
2. **Connect Handle:** Push the rounded ends of the handle sections together until you hear a distinct "click." This ensures the handle is securely extended.
3. **Slide Duster onto Handle:** With the 'non-fluffy' end of the duster facing you, slide the handle's forks into the white sleeves of the duster refill. Ensure the duster is fully seated on the handle.

Your Swiffer Duster is now ready for use.



Image: Visual guide for connecting the handle, fluffing the duster, inserting the duster onto the handle, and the final dusting action.

Operating Instructions

The Swiffer Duster is designed for efficient dust removal from various surfaces. Its unique fibers and extendable handle make cleaning easier.

- **Effective Dust Trapping:** The specially coated fibers of the Swiffer Heavy Duty Dusters are designed to reach deep into nooks and crannies, grabbing, trapping, and locking dust from all directions.
- **Allergen Removal:** This duster can remove up to 95% of common inanimate allergens, such as those from cat and dog dander and dust mite matter.

- **Extended Reach:** Utilize the 3-foot extendable handle to clean high or difficult-to-reach areas, including ceiling fans, light fixtures, vents, blinds, and the tops of bookcases.
- **Surface Compatibility:** Use on a variety of dry surfaces including furniture, electronics, blinds, and decorative items.



Image: Illustration of the duster's double-sided design, ability to clean tight spaces, and allergen removal capabilities.



Image: A Swiffer Duster being used to clean a television screen, demonstrating its dust pick-up efficiency.



Image: A Swiffer Duster inside a glass vase, illustrating its 360-degree dust trapping and locking design.



Image: A person using the extendable Swiffer Duster to clean a high shelf, showcasing the kit's components.

Maintenance

The Swiffer Duster is designed for convenience with disposable duster heads. No washing or complex maintenance is required for the duster heads.

- **Duster Refill Replacement:** When the duster head becomes saturated with dust and no longer picks up effectively, simply remove it from the handle and dispose of it. Replace with a new Swiffer Duster refill.
- **Handle Care:** The handle can be wiped clean with a damp cloth if needed. Ensure it is dry before storage.

Troubleshooting

If you encounter issues with your Swiffer Duster, consider the following:

- **Duster not picking up dust:** Ensure the duster head has been properly fluffed before use. If it is heavily

soiled, replace the duster head with a new one.

- **Handle not extending/retracting smoothly:** Check for any obstructions or debris in the handle mechanism. Ensure the sections are aligned correctly when extending or retracting.
- **Duster head detaching from handle:** Verify that the duster head is fully and securely inserted onto the handle's forks.

Specifications

Feature	Detail
Brand	Swiffer
Model Number	82074
Product Dimensions	3 x 5 x 11 inches; 6.4 ounces
Handle Material	Aluminum
Color	Yellow
Special Feature	Extendable Handle (up to 3 ft)
Country of Origin	Canada

Warranty and Support

Swiffer stands behind its products. If you are not completely satisfied with your purchase, please refer to Swiffer's money-back guarantee for details.
For additional information or online instructions, please visit the official Swiffer website:www.swiffer.com

© 2025 Swiffer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B001TQ6IHS

More documents and user manuals: **https://manuals.plus/**