Nespresso 3192-US

Nespresso Aeroccino Plus Milk Frother User Manual

Model: 3192-US

Important Safety Instructions

Please read all instructions carefully before using the Nespresso Aeroccino Plus milk frother. Retain this manual for future reference. Failure to follow these instructions may result in injury or damage to the appliance.

- Do not immerse the frother base, power cord, or plug in water or any other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep the appliance out of reach of children. Close supervision is necessary when used near children.
- Place the frother on a stable, flat, heat-resistant surface, away from hot surfaces or open flames.
- Unplug the appliance from the outlet when not in use, before cleaning, and before assembling or disassembling parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments and accessories recommended by the manufacturer.
- Avoid contact with moving parts.

Product Overview

The Nespresso Aeroccino Plus is an automatic milk frother designed to create light and creamy milk froth for various coffee recipes, as well as to heat milk for lattes. It operates quickly and quietly, providing perfect results in seconds.



Image: The Nespresso Aeroccino Plus milk frother, featuring a sleek chrome jug with a black handle and a clear lid, resting on its power base.

Components:

- **Frother Jug:** The main container for milk, with a non-stick coating.
- **Lid:** Transparent lid to cover the jug during operation.
- **Frothing Whisk:** A whisk with a spring, used for creating milk froth (hot or cold).
- **Heating Whisk:** A whisk without a spring, used for heating milk with minimal froth.
- **Power Base:** The electrical base that heats and spins the whisk.

Setup

Before first use, follow these steps:

1. **Unpack:** Carefully remove all packaging materials and dispose of them responsibly.
2. **Clean:** Wash the inside of the frother jug, the lid, and both whisks with warm water and a mild detergent. Rinse thoroughly and dry completely. Do not immerse the power base in water.
3. **Placement:** Place the power base on a clean, dry, and stable surface.
4. **Connect:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

Milk Preparation Guidelines:

- Always use cold, fresh milk for optimal frothing results.
- The quality of froth can vary depending on the type of milk (e.g., whole, skim, non-dairy alternatives).

Frothing Hot Milk (for Cappuccinos and Lattes):

1. Insert the **frothing whisk** (with the spring) into the bottom of the jug.
2. Pour cold milk into the jug, ensuring it does not exceed the **lower MAX line** (approximately 130 ml). Exceeding this line will cause overflow.
3. Place the lid on the jug.
4. Press the button once. The button will illuminate **red**, indicating hot frothing has started.
5. The frother will automatically stop when the milk reaches the optimal temperature and consistency (approximately 70 seconds).

Heating Milk (for Lattes and Hot Chocolate):

1. Insert the **heating whisk** (without the spring) into the bottom of the jug.
2. Pour cold milk into the jug, ensuring it does not exceed the **upper MAX line** (approximately 250 ml).
3. Place the lid on the jug.
4. Press the button once. The button will illuminate **red**, indicating heating has started.
5. The frother will automatically stop when the milk reaches the optimal temperature.

Frothing Cold Milk:

1. Insert the **frothing whisk** (with the spring) into the bottom of the jug.
2. Pour cold milk into the jug, ensuring it does not exceed the **lower MAX line** (approximately 130 ml).
3. Place the lid on the jug.
4. Press and hold the button for approximately 2 seconds. The button will illuminate **blue**, indicating cold frothing has started.
5. The frother will automatically stop when the cold froth is ready.



Image: A clear glass showing a perfectly layered coffee drink with distinct layers of coffee, milk, and a thick, creamy milk froth on top.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your Aeroccino Plus. Clean the frother immediately after each use.

1. **Unplug and Cool:** Always unplug the frother from the power outlet and allow it to cool down before cleaning.
2. **Remove Whisk:** Carefully remove the whisk from the jug.
3. **Rinse Interior:** Immediately rinse the inside of the frother jug with warm water to prevent milk residue from drying and sticking.
4. **Gentle Cleaning:** Use a soft, non-abrasive sponge or cloth with a small amount of mild dish soap to clean the interior and exterior of the jug and the whisks. Do not use abrasive materials or metal scourers, as these can damage the non-stick coating.
5. **Avoid Immersion:** *Never immerse the power base or the exterior bottom of the jug in water or any other liquid.* The electrical components are located in the base.
6. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing the frother.

Storage:

Store the Nespresso Aeroccino Plus in a clean, dry place when not in use. Ensure the whisks are properly stored inside the jug or in a safe place to prevent loss.

Troubleshooting

If you encounter issues with your Aeroccino Plus, consult the table below for common problems and solutions.

Problem	Possible Cause	Solution
Milk not frothing or heating.	Incorrect whisk inserted, milk level too low/high, power issue, frother not clean.	Ensure correct whisk is used for desired function. Check milk level against MAX lines. Verify power connection. Clean frother thoroughly.

Problem	Possible Cause	Solution
Milk overflowing during operation.	Milk filled above the indicated MAX line.	Always adhere to the MAX lines for frothing (lower line) and heating (upper line).
Burnt milk smell or residue at the bottom.	Frother not cleaned immediately after use, old milk used, or milk left to sit.	Clean the frother immediately after each use. Use fresh, cold milk. Do not reheat milk that has already been processed.
Frother does not start.	No power, whisk not properly placed, or sensor issue.	Check if the frother is plugged in. Ensure the whisk is correctly seated. If the problem persists, contact Nespresso customer support.

Specifications

- **Model:** 3192-US
- **Brand:** Nespresso
- **Capacity (Frothing):** Maximum 130 ml (4.4 fl oz)
- **Capacity (Heating):** Maximum 250 ml (8.5 fl oz)
- **Power Source:** Corded Electric
- **Dimensions:** 4.1 x 4.1 x 6.7 inches (10.4 x 10.4 x 17 cm)
- **Item Weight:** 2.65 pounds (1.2 kg)
- **Material:** Plastic (jug interior with non-stick coating)
- **Special Feature:** Detachable Base
- **Product Care:** Hand Wash Only

Warranty and Support

The Nespresso Aeroccino Plus is covered by a limited warranty from the date of purchase. Please refer to the warranty card included with your product for specific terms and conditions, including coverage duration and limitations.
For technical assistance, spare parts, or warranty claims, please contact Nespresso Customer Service. You can find contact information on the official Nespresso website or through your local Nespresso distributor.
When contacting support, please have your product model number (3192-US) and proof of purchase readily available.

© 2023 Nespresso. All rights reserved.