De'Longhi DLSC200

De'Longhi EcoDecalk Descaler Instruction Manual

Model: DLSC200

Product Overview

The De'Longhi EcoDecalk Descaler is an eco-friendly universal descaling solution designed for use with all coffee and espresso machines. Regular use helps to prevent premature breakdown due to scale build-up, improves energy efficiency, and maintains the optimal flavor and crema of your coffee. This solution is formulated with natural lactic acid, offering an effective and gentle descaling process.



Image: De'Longhi EcoDecalk Descaler in its packaging, showing two individual bottles and two espresso cups, illustrating the product's purpose.

Key Features:

- Eco-friendly universal descaling solution that's gentle on your coffee maker.
- Extends the life of your machine, preserves energy efficiency, and maintains coffee flavor.
- Faster and more effective than citric acid-based limescale removers.
- Made with natural, high-quality ingredients of plant origin.
- Contains 2 x 100ml bottles, each suitable for 1 use.

Important Safety Information

Before using the De'Longhi EcoDecalk Descaler, please read and understand all safety warnings and instructions provided with your coffee or espresso machine, as well as on the descaler packaging. Keep out of reach of children. Avoid contact with skin and eyes. In case of contact, rinse thoroughly with water. Do not ingest. Use in a well-ventilated area.

Setup and Preparation

Ensure your coffee or espresso machine is turned off and cooled down before beginning the descaling process. Refer to your machine's specific instruction manual for detailed descaling procedures, as steps may vary between models.

1. Empty the water tank of your coffee machine.
2. Pour one 100ml bottle of De'Longhi EcoDecalk Descaler into the water tank.
3. Fill the water tank with fresh water up to the level indicated in your machine's manual for descaling, or to the maximum level if no specific indication is given.
4. Place a large container under the coffee spout and/or steam wand to collect the descaling solution.

Quick and easy to use



Image: A user pouring the descaling solution into the water reservoir of a coffee machine, demonstrating the initial step of the descaling process.

Operating the Descaling Process

The descaling process is typically initiated through a specific function on your coffee machine. Follow your machine's instructions carefully.

1. Turn on your coffee machine and activate the descaling cycle as per your machine's manual. This often involves pressing and holding a specific button or navigating a menu.
2. The machine will begin to dispense the descaling solution through the coffee spout and/or steam wand. This process may involve pauses and repetitions.
3. Allow the machine to complete the entire descaling cycle. Do not interrupt the process.
4. Once the descaling cycle is complete, empty and thoroughly rinse the water tank.
5. Refill the water tank with fresh, clean water.
6. Run several rinse cycles (usually 2-3) with fresh water through the machine to ensure all descaling solution residue is

removed. Continue to collect the water in the container.

7. After the rinse cycles, your machine is ready for use.



Image: A close-up of a coffee machine's digital display, showing a "Descaling" message, which indicates the machine is actively undergoing the descaling procedure.

Maintenance and Storage

For optimal performance and longevity of your coffee machine, it is recommended to descale regularly, typically every 2-3 months, or as indicated by your machine's descaling alert. Store the unused descaler bottles in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the bottles are tightly sealed.



Image: Two bottles of De'Longhi EcoDecalk Descaler, accompanied by text emphasizing its natural composition and benefits for machine longevity and coffee taste.

Troubleshooting

If you encounter issues during the descaling process, consider the following:

- **Machine not starting descaling cycle:** Ensure the water tank is correctly filled with the solution and water, and that the machine is in the correct mode (e.g., descaling mode). Consult your machine's manual for specific button sequences.
- **Descaling light remains on:** Some machines require multiple rinse cycles or a specific reset procedure after descaling. Refer to your machine's manual for instructions on how to clear the descaling alert.
- **Solution not dispensing:** Check for any blockages in the water tank or dispensing paths. Ensure the machine is properly assembled.
- **Unusual taste after descaling:** This indicates residual descaling solution. Perform additional rinse cycles with fresh water until the taste is neutral.

For persistent issues, contact De'Longhi customer support or refer to your coffee machine's comprehensive troubleshooting guide.

Specifications

Brand:	De'Longhi
Model Number:	DLSC200
Product Dimensions:	4.13 x 1.4 x 5 inches
Item Weight:	7.1 ounces
Item Form:	Liquid
Specific Uses:	Coffee and Espresso Machines
Material Feature:	Natural (Lactic Acid)
Date First Available:	August 6, 2012

Warranty and Support

For information regarding product warranty or technical support, please visit the official De'Longhi website or contact their customer service directly. Keep your purchase receipt as proof of purchase.
Official De'Longhi Website: www.delonghi.com

© 2024 De'Longhi. All rights reserved.
This manual is for informational purposes only. Always refer to your specific coffee machine's manual for detailed descaling instructions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question