Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced KV-29K1R

User Manual

RemotesReplaced Compatible Remote Control for Sony KV-29K1R

Overview Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

This manual provides instructions for the RemotesReplaced Compatible Remote Control, designed as a direct replacement for the original Sony KV-29K1R television remote. This remote is specifically manufactured to offer all the functionalities of the original remote without the need for complex setup codes.





Figure 1: Front view of the RemotesReplaced remote control. This image displays the full layout of the remote, including the power button, channel and volume controls, numeric keypad, navigation buttons, and various function keys for TV, SAT, DVD, AUX, MENU, EXIT, SHIFT, SOURCE, GUIDE, SUB, SIZE, SETUP, TEXT, BACK, SLEEP, INFO, EPG, FAV, NET TV, and media playback controls. The "RemotesReplaced RRS41" branding is visible at the bottom.

Key features include:

- Direct replacement for the original remote control.
- No setup code required; ready to use upon battery insertion.
- Capable of accessing all functions of the original device.
- Specifically manufactured for the Sony KV-29K1R model, not a universal remote.

2. Setup and First Use

The RemotesReplaced remote control is designed for immediate use with your Sony KV-29K1R television. No

programming or code entry is required.

2.1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery cover by sliding it back into place until it clicks securely.



Figure 2: Side view of the RemotesReplaced remote control. This image provides a perspective of the remote's thickness and the location of the battery compartment on the rear side, near the bottom.

Once batteries are installed, the remote control is ready to operate your Sony KV-29K1R television.

3. Operating Instructions

This remote control replicates the functionality of your original Sony KV-29K1R remote. Refer to your television's user manual for specific functions if needed.

3.1. Basic Functions

- **POWER:** Turns the television on or off.
- **MUTE:** Mutes or unmutes the television sound.
- **VOL +/-:** Increases or decreases the volume.
- **CH +/- (P+/-):** Changes the television channel up or down.
- **Numeric Keypad (0-9):** Directly enters channel numbers.
- **SOURCE:** Cycles through input sources (TV, SAT, DVD, AUX).

3.2. Navigation and Menu Functions

- **MENU:** Opens the television's main menu.
- **EXIT:** Exits the current menu or on-screen display.
- **Arrow Buttons (Up, Down, Left, Right):** Navigates through menu options.
- **OK:** Confirms a selection in the menu.
- **BACK:** Returns to the previous screen or menu.

3.3. Advanced Functions

- **GUIDE** / **EPG:** Accesses the Electronic Program Guide.
- **INFO:** Displays information about the current program or input.

- **TEXT:** Activates or deactivates Teletext.
- **SUB:** Controls subtitles.
- **SLEEP:** Sets a sleep timer for the television.
- **Media Playback Controls:** Play, Pause, Stop, Fast Forward, Rewind, Next, Previous for compatible devices connected to the TV.

4. Maintenance

Proper care and maintenance will ensure the longevity of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Damage:** Do not drop the remote control, expose it to water or other liquids, or attempt to disassemble it.

5. Troubleshooting

If you experience issues with your remote control, try the following solutions:

Problem	Possible Cause / Solution
Remote control is not working.	Check if the batteries are inserted correctly with the correct polarity (+/-). Replace old batteries with new AAA batteries. Ensure there are no obstructions between the remote control and the television's infrared sensor. Make sure you are within the operating range and pointing the remote directly at the TV.
Some buttons are not responding.	The button might be stuck or dirty. Gently clean around the button. Ensure the remote is compatible with the specific function you are trying to use (e.g., some buttons might be for specific external devices).
Remote works intermittently.	Batteries may be low. Replace them. Infrared sensor on the TV might be partially obstructed or dirty.

If the problem persists after trying these solutions, please contact customer support.

6. Product Specifications

Feature	Detail
Brand	RemotesReplaced
Model Number	KV-29K1R
Compatible Devices	Television (Sony KV-29K1R)

Feature	Detail
Connectivity Technology	Infrared
Batteries Required	2 x AAA batteries
Item Weight	120 Grams
Manufacturer	Linkwebb
Date First Available	April 21, 2022

7. Warranty and Support

7.1. Warranty Information

This RemotesReplaced remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote control functions as described. Please retain your proof of purchase for warranty claims.

7.2. Customer Support

For any questions, troubleshooting assistance, or warranty claims, please contact RemotesReplaced customer support. Refer to the seller's information on your purchase platform for contact details.

© 2024 RemotesReplaced. All rights reserved.
Product Model: KV-29K1R

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00229KMOQ

More documents and user manuals: **https://manuals.plus/**