Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced 14PV354-39

RemotesReplaced Compatible Remote Control User Manual

Model: 14PV354-39 for Philips Televisions

1. Introduction

Thank you for choosing the RemotesReplaced compatible remote control. This remote is designed as a direct replacement for your original Philips 14PV354-39 television remote, offering full functionality without the need for complex programming. This manual provides essential information for setting up, operating, and maintaining your new remote control.

2. Safety Information

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Always remove exhausted batteries promptly to prevent leakage.
- Dispose of batteries according to local regulations.
- Keep the remote control away from moisture, direct sunlight, and extreme temperatures.
- Do not attempt to disassemble or modify the remote control.

3. Package Contents

Your package should contain the following item:

- 1 x RemotesReplaced Compatible Remote Control for Philips 14PV354-39

Note: Batteries are not included and must be purchased separately. This remote requires 2 AAA batteries.

4. Setup

4.1 Battery Installation

To begin using your remote control, you must first install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two (2) AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the

markings inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use with your Philips 14PV354-39 television. No programming or code entry is required.




V
P
OK
V
P
BACK
SLEEP
TV/DTV
INFO
EPG
FAV
NET TV
II
SMART
RemotesReplaced
RRS41



This image displays a side profile of the RemotesReplaced compatible remote control. The infrared (IR) emitter is visible at the front end, which transmits signals to the television. The top surface features numerous black buttons with white labels for various functions, including power, volume, channel, and menu controls.

5. Operating Instructions

This remote control is designed to replicate the functions of your original Philips 14PV354-39 remote. Point the remote control directly at your television's infrared receiver for optimal performance.

5.1 Basic Functions

- **POWER:** Turns the television on or off.
- **VOL +/-:** Increases or decreases the volume level.
- **CH +/-:** Changes the television channel up or down.
- **MUTE:** Silences the television audio.
- **Number Buttons (0-9):** Directly selects television channels.

5.2 Advanced Functions

Depending on your specific television model, other buttons such as MENU, INPUT/SOURCE, GUIDE, and playback controls (e.g., PLAY, PAUSE, STOP) will function identically to the original remote. Refer to your television's user manual for specific details on these functions.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage.

7. Troubleshooting

- **Remote not working:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the television's IR receiver.
  - Make sure you are pointing the remote directly at the television.
- **Limited range:**
  - Ensure batteries are fresh.
  - Check for strong light sources (like direct sunlight or bright fluorescent lights) that might interfere with the IR signal.

8. Specifications

Brand	RemotesReplaced
Model Number	14PV354-39
Connectivity Technology	Infrared (IR)
Compatible Devices	Television (Philips 14PV354-39)
Maximum Devices Supported	1
Maximum Range	10 Meters
Batteries Required	2 x AAA (not included)
Item Weight	120 Grams

9. Warranty and Support

This RemotesReplaced compatible remote control comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For technical support, warranty claims, or any questions regarding your remote control, please contact the seller directly through your purchase platform. Please have your order details ready when contacting support.

© 2024 RemotesReplaced. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00229ND9M

More documents and user manuals: **https://manuals.plus/**