RemotesReplaced P1690Y

RemotesReplaced Compatible Remote Control for Pilot P1690Y Instruction Manual

Model: P1690Y

Introduction

This manual provides instructions for the RemotesReplaced Compatible Remote Control, model P1690Y. This remote is designed as a direct replacement for the original Pilot P1690Y remote, offering full functionality without the need for complex programming or setup codes. It is compatible with televisions.

Key features include:

- Direct replacement for the original remote control.
- No installation codes required; simply insert batteries and begin use.
- Access to all original remote functions.

Setup

Battery Installation

The remote control requires two AAA batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back view of the remote control, highlighting the battery compartment cover. This is where the batteries are inserted.



Image: Bottom view of the remote control, showing the battery cover in detail. This cover protects the battery compartment.

Once batteries are installed, the remote is ready for immediate use with your compatible Pilot P1690Y device. No programming is required.

Operating Instructions

This remote control is designed to replicate the functions of your original Pilot P1690Y remote. Point the remote directly at the infrared receiver on your television or compatible device.



Image: Front view of the RemotesReplaced P1690Y remote control, displaying all buttons and their labels. This image shows the layout of the control interface.

Common Button Functions:

- **POWER (Red Button):** Turns the device on or off.
- **MUTE:** Silences or restores audio.
- **TV/SAT/DVD/AUX:** Selects input sources.
- **MENU/EXIT:** Accesses or exits the device's menu.
- **Number Pad (0-9):** Direct channel selection or data entry.
- **VOL +/-:** Adjusts volume up or down.
- **CH +/-:** Changes channels up or down.
- **Navigation Pad (Arrows & OK):** Navigates menus and confirms selections.
- **BACK/INFO/EPG/FAV:** Provides access to various device-specific functions.
- **Colored Buttons (Red, Green, Yellow, Blue):** Often used for specific functions within menus or interactive services.

For specific functions related to your device, refer to your television or compatible device's instruction manual.



Image: Top view of the remote control, showing the infrared (IR) emitter. This component sends signals to your device.

Maintenance

Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both AAA batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries, as this can lead to leakage or malfunction.

Storage

Store the remote control in a dry place, away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are correctly installed with proper polarity.
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote and the device's infrared receiver.
  - Ensure you are within the effective range and pointing the remote directly at the device.
- **Some functions not working:**
  - Verify that the device you are trying to control is compatible with the Pilot P1690Y remote functions.
  - Ensure the correct input source is selected on your device (e.g., TV, DVD, AUX).

Specifications

Brand	RemotesReplaced
Model Number	P1690Y
Connectivity Technology	Infrared
Compatible Devices	Television
Batteries Required	2 AAA batteries
Item Weight	120 Grams
Manufacturer	Linkwebb

Warranty Information

This RemotesReplaced product is covered by a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote control functions as intended. Please retain your proof of purchase for warranty claims.

The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

Support

For further assistance, technical support, or warranty inquiries regarding your RemotesReplaced Compatible Remote Control (Model P1690Y), please contact the seller or refer to the contact information provided with your purchase.

Manufacturer: Linkwebb

Brand: RemotesReplaced