Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool 8300811

Whirlpool W10183369 Burner Cap Instruction Manual

Introduction

This document provides essential instructions for the Whirlpool W10183369 Burner Cap. This component is an authorized aftermarket product designed to fit various Whirlpool brand cooktop models. The burner cap is crucial for proper flame distribution and efficient cooking on your appliance.
Part Number: W10183369 (OEM Part # 8300811)
Purpose: The burner cap covers the burner head, ensuring the gas flame is evenly distributed for optimal heating and cooking performance.

Setup and Installation

Follow these steps to correctly install or replace your Whirlpool W10183369 Burner Cap:

1. **Safety First:** Ensure your cooktop is completely turned off and cool to the touch before beginning any installation or replacement. Disconnect the appliance from its power source if possible.
2. **Remove Old Cap (if applicable):** Carefully lift off the existing burner cap from the burner head.
3. **Inspect Burner Head:** Check the burner head for any debris or food particles and clean if necessary to ensure a clear path for gas flow.
4. **Place New Cap:** Position the new Whirlpool W10183369 Burner Cap directly over the burner head. Ensure it sits flat and is centered. The cap should rest securely without wobbling.
5. **Verify Fit:** Gently try to rotate the cap to confirm it is properly seated. It should not move freely or be misaligned.



Image Description: A top-down view of the Whirlpool W10183369 Burner Cap. It is a circular, black-colored metal cap with a slightly raised, smaller circular center. The surface appears to have a matte or textured finish, typical of cast iron or enameled steel. This image illustrates the component to be installed.

Operating

Once the burner cap is correctly installed, it functions automatically as part of your cooktop's burner assembly. When the burner is ignited, the cap directs the flame evenly across the cooking surface, providing consistent heat for your cookware. Ensure the cap remains properly seated during operation for optimal performance.

Maintenance

Regular cleaning of your burner cap helps maintain its efficiency and appearance:

- **Daily Cleaning:** After the cooktop has cooled, wipe the burner cap with a damp cloth and mild dish soap to remove food spills and grease.
- **Stubborn Stains:** For baked-on food, you may soak the cap in warm, soapy water for a short period before scrubbing gently with a non-abrasive brush or sponge.
- **Drying:** Always ensure the burner cap is completely dry before placing it back on the burner head and operating the cooktop. Moisture can interfere with ignition and flame quality.
- **Avoid Abrasives:** Do not use harsh chemicals, abrasive cleaners, or steel wool, as these can damage the finish of the burner cap.

Troubleshooting

If you experience issues related to the burner cap, consider the following:

- **Uneven Flame:** If the flame appears uneven or weak, ensure the burner cap is correctly seated and not misaligned. Check for any food debris or blockages under or around the cap that might be obstructing gas flow.
- **Ignition Issues:** If the burner is not igniting, ensure the cap is dry and properly placed. Moisture or misalignment can sometimes prevent proper ignition.
- **Damage:** Inspect the burner cap for any signs of damage, such as cracks or warping. A damaged cap may need to be replaced to ensure safe and efficient operation.

Specifications

- **Brand:** Whirlpool
- **Model Info:** 8300811
- **Part Number:** 8300811 (also referred to as W10183369)
- **Item Weight:** Approximately 50 pounds (Note: This weight may refer to shipping weight or a larger package, not the individual cap.)
- **Package Dimensions:** Approximately 50 x 50 x 50 inches (Note: This dimension may refer to shipping package, not the individual cap.)
- **First Available:** March 31, 2009

Warranty and Support

As an O.E.M. Authorized part, this Whirlpool W10183369 Burner Cap is designed to meet the quality standards of Whirlpool appliances. For specific warranty information, please refer to the documentation provided with your original appliance or contact Whirlpool customer support directly.
For assistance with this part or other Whirlpool products, you may visit the officialWhirlpool Store on Amazon or contact Whirlpool customer service.
This product is returnable until January 31, 2026, through authorized channels, ensuring customer satisfaction.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0023RKUBM

More documents and user manuals: **https://manuals.plus/**