Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Altec Lansing VS2621

Altec Lansing VS2621 2.1 Channel Speaker System User Manual

Model: VS2621

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Altec Lansing VS2621 2.1 Channel Speaker System. Please read this guide thoroughly before using your speaker system to ensure proper functionality and to maximize your audio experience.

Safety Information

- Do not expose the speaker system to water or excessive moisture.
- Avoid placing the system near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Use only attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.

Package Contents

Verify that all components are present in your package:

- Two (2) Satellite Speakers
- One (1) Subwoofer
- Quick Connect Guide

Setup

Follow these steps to set up your Altec Lansing VS2621 speaker system:

1. **Positioning the Speakers:** Place the two satellite speakers on either side of your computer monitor or listening area. Position the subwoofer on the floor, preferably near a wall for enhanced bass response.

2. **Connecting Satellite Speakers to Subwoofer:** Connect the proprietary cable from the satellite speakers to the corresponding port on the back of the subwoofer. Ensure the connection is secure.
3. **Connecting to Audio Source:** Plug the 3.5mm audio input cable (attached to one of the satellite speakers) into the audio output jack of your computer, MP3 player, or other audio device.
4. **Power Connection:** Plug the power cord from the subwoofer into a standard electrical outlet.
5. **Power On:** Locate the power switch on the back of the subwoofer and turn it to the 'ON' position.



Image: The Altec Lansing VS2621 2.1 Channel Speaker System, featuring two angled satellite speakers with controls and a central subwoofer unit.



Image: A close-up view of one satellite speaker, highlighting the Volume and Tone control knobs, and the Auxiliary input jack.

Operating Instructions

Once your speaker system is set up and powered on, you can begin using it:

- **Volume Control:** Use the **VOLUME** knob located on the front of the right satellite speaker to adjust the overall sound level.
- **Tone Control:** The **TONE** knob, also on the right satellite speaker, allows you to adjust the treble and bass balance. Turn clockwise for brighter sound (more treble) and counter-clockwise for warmer sound (more bass).
- **Auxiliary Input:** To connect an additional audio device (e.g., an MP3 player or smartphone) without disconnecting your computer, plug its 3.5mm audio cable into the **AUX** input jack on the right satellite speaker. The system will automatically switch to the auxiliary input.
- **Power Off:** To turn off the system, switch the power button on the back of the subwoofer to the 'OFF' position.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the speakers and subwoofer. Do not use liquid cleaners or aerosols.
- **Ventilation:** Ensure that the subwoofer's ventilation ports are not blocked to prevent overheating.
- **Cable Care:** Avoid sharply bending or crimping the cables. Do not attempt to extend the proprietary speaker cables.

Troubleshooting

Problem	Possible Solution
No sound	◦ Ensure the power switch on the subwoofer is ON. ◦ Check all cable connections, especially the audio input and power cord. ◦ Increase the volume using the VOLUME knob on the satellite speaker and on your audio source device. ◦ Verify that the correct audio output is selected on your computer or device.
Distorted sound	◦ Reduce the volume on both the speaker system and your audio source. ◦ Adjust the TONE knob. ◦ Ensure audio cables are securely connected and not damaged.
Humming or buzzing noise	◦ Ensure all cables are properly connected. ◦ Try plugging the power cord into a different electrical outlet. ◦ Move the speakers away from other electronic devices that may cause interference.

Specifications

- **Model:** VS2621
- **Speaker Type:** 2.1 Channel Multimedia Speaker System
- **Total Peak Power:** 20 Watts

- **Connectivity:** Wired (3.5mm auxiliary input)
- **Subwoofer Diameter:** 3 Inches
- **Satellite Speaker Dimensions (WxHxD):** 5.1 x 5.2 x 4.7 inches
- **Subwoofer Dimensions (WxHxD):** 4.9 x 8.8 x 10.3 inches
- **Item Weight:** 8.5 Pounds
- **Signal-to-Noise Ratio:** 65 dB
- **Compatible Devices:** Desktop, Laptop, MP3 Player, Smartphone, Tablet, Television

Warranty and Support

The Altec Lansing VS2621 speaker system comes with a limited one-year warranty. For warranty claims or technical support, please refer to the contact information provided with your purchase documentation or visit the official Altec Lansing website.

© 2023 Altec Lansing. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0025VKUQQ

More documents and user manuals: **https://manuals.plus/**