Mr. Christmas Holiday Carousel

Mr. Christmas Holiday Carousel Instruction Manual

This manual provides detailed instructions for the setup, operation, and maintenance of your Mr. Christmas Holiday Carousel.

Product Overview

The Mr. Christmas Holiday Carousel is a decorative item featuring illuminated and animated carousel horses that move up and down. It plays a selection of 25 Christmas carols and 25 year-round classics in calliope style, designed to bring festive cheer to your home.



Image: The Mr. Christmas Holiday Carousel, showcasing the five illuminated carousel horses and the connected control box.

Safety Information

Warning: Handle with care to avoid breakage. This product is not a toy and should be kept out of reach of children.

Package Contents

- Five (5) hanging carousel horses (approximately 5 3/4-inches tall)
- One (1) control box (approximately 7-inches wide)
- One (1) A/C Adapter

Setup Instructions

1. Carefully unpack all components from the packaging, ensuring no parts are missing or damaged.
2. Identify the five carousel horses and the main control box.
3. Connect each of the five carousel horses to the designated ports on the control box. Ensure all connections are secure and firm.
4. Place the control box and connected horses on a stable, flat surface, or hang them as desired.
5. Plug the A/C adapter into the control box, then plug the adapter into a standard electrical outlet.

Operating Instructions

The Holiday Carousel features musical playback and animated horse movement once powered on.

Music and Animation

Once the unit is powered on, the carousel horses will begin to move up and down, and the integrated LED lights will illuminate. The carousel will automatically play a selection from its library of 25 Christmas carols and 25 year-round classics.

Controls

The control box typically includes switches or buttons to manage the music and animation. Refer to the labels on your specific control box for options such as power ON/OFF, music selection, or volume adjustment.

Maintenance

Cleaning

To clean the carousel, gently wipe all surfaces with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish and electronic components.

Storage

When not in use, store the carousel in its original packaging or a protective container. Keep it in a cool, dry place, away from direct sunlight and extreme temperatures, to prevent dust accumulation and potential damage.

Troubleshooting

No Power or Functionality

- Ensure the A/C adapter is securely plugged into both the control box and a functional electrical outlet.
- Verify that the power switch on the control box is in the "ON" position.

- Test the electrical outlet with another device to confirm it is supplying power.

No Music Playback

- Confirm the unit is powered on and the volume control (if available) is not set to minimum.
- If the issue persists, try disconnecting power for 30 seconds and then reconnecting it to reset the unit.

Specifications

Feature	Detail
Brand	Mr. Christmas
Model	Holiday Carousel
Item Dimensions	8 x 16 x 25 inches
Item Weight	5.3 pounds
Number of Pieces	5 (carousel horses)
Material Type	[POSSIBLE] Metal
Power Source	A/C Adapter (included)
Music	25 Christmas carols, 25 year-round classics
Illumination	LED lights
UPC	051053171018
ASIN	B00266Q3IY

Warranty and Support

For detailed warranty information, technical assistance, or customer support, please refer to any documentation included with your original purchase. You may also visit the official Mr. Christmas website or contact their customer service department directly for further assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question