Vidal Sassoon VSDR5524

Vidal Sassoon VSDR5524 1875W Hair Dryer Instruction Manual

Model: VSDR5524

1. Important Safety Information

Please read all instructions before using this appliance. When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** As with most electrical appliances, electrical parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:
  - Always unplug this appliance immediately after using.
  - Do not use while bathing or in a shower.
  - Do not place or store appliance where it can fall or be pulled into a tub or sink.
  - Do not place in or drop into water or other liquid.
  - If an appliance falls into water, unplug it immediately. Do not reach into the water.
- **WARNING:** To reduce the risk of burns, electrocution, fire, or injury to persons:
  - An appliance should never be left unattended when plugged in.
  - Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
  - Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
  - Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water.
  - Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
  - Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
  - Never use while sleeping.
  - Never drop or insert any object into any opening.
  - Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
  - Do not use an extension cord with this appliance.
  - Do not direct hot air towards eyes or other heat-sensitive areas.

- Attachments may be hot during use. Allow them to cool before handling.
- Do not place appliance on any surface while it is operating.
- While using the appliance, keep your hair away from the air inlets.

2. Product Overview

The Vidal Sassoon VSDR5524 is a lightweight and compact 1875W hair dryer designed for efficient hair styling. It features multiple heat and speed settings for versatile use.



Figure 2.1: Front view of the Vidal Sassoon VSDR5524 1875W Hair Dryer. This image shows the main body, nozzle, and handle with control switches.

Key Features:

- **1875W Power:** Provides strong airflow for quick drying.
- **Lightweight and Compact Design:** Easy to handle and store.
- **2 Temperature Settings:** Allows for customized heat levels.

- **2 Speed Settings:** Offers control over airflow intensity.
- **Removable Filter:** Facilitates easy cleaning and maintenance, extending product life.



Figure 2.2: Packaging illustration highlighting the 1875W power, lightweight design, and multiple heat/speed settings of the Vidal Sassoon VSDR5524 Hair Dryer.

3. Setup

Before first use, ensure the hair dryer is free from any packaging materials. Follow these steps for initial setup:

1. Uncoil the power cord completely.
2. Ensure your hands are dry before plugging the appliance into a suitable electrical outlet.
3. Verify that the voltage of your electrical outlet matches the voltage specified on the appliance.
4. Do not use an extension cord with this appliance.

4. Operating Instructions

To achieve desired styling results, follow these operating guidelines:

4.1 Power and Speed Settings

The hair dryer features a combined power and speed switch, typically located on the handle.

- **OFF:** Position the switch to 'OFF' to turn the appliance off.
- **LOW:** Select 'LOW' for gentle drying and styling.
- **HIGH:** Select 'HIGH' for fast drying.

4.2 Temperature Settings

The hair dryer offers two temperature settings to suit different hair types and styling needs.

- **Warm:** Provides a comfortable heat level for general drying.
- **Hot:** Delivers higher heat for faster drying and setting styles.

Note: The specific labels for temperature settings may vary slightly but generally correspond to warm and hot options.

4.3 Cool Shot Function

To set your style and add shine, press and hold the cool shot button (often marked with a snowflake icon) while drying. This delivers a burst of cool air.

5. Maintenance

Regular maintenance ensures optimal performance and extends the life of your hair dryer. Always unplug the appliance before cleaning.

5.1 Cleaning the Removable Filter

The hair dryer is equipped with a removable filter for easy cleaning. A clogged filter can reduce airflow and lead to overheating.

1. Ensure the hair dryer is turned off and unplugged from the power outlet.
2. Allow the appliance to cool down completely.
3. Locate the rear filter cover (usually at the back of the dryer).
4. Gently twist or pull the filter cover to remove it.
5. Remove any accumulated lint, dust, or hair from the filter using a soft brush or by hand.
6. Wipe the exterior of the appliance with a damp cloth. Do not use abrasive cleaners or solvents.
7. Replace the filter cover securely.

Perform this cleaning regularly, especially if you notice a decrease in airflow or increased noise.

5.2 Storage

When not in use, unplug the appliance. Allow it to cool and store it out of reach of children in a dry location. Do not wrap the cord around the appliance, as this can cause premature wear and breakage of the cord.

6. Troubleshooting

If you encounter issues with your Vidal Sassoon VSDR5524 Hair Dryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Hair dryer does not turn on.	Not plugged in; power outlet malfunction; internal fault.	Ensure the plug is fully inserted. Test the outlet with another appliance. If still not working, discontinue use and contact customer support.
Reduced airflow or overheating.	Clogged air filter; blocked air intake/outlet.	Unplug the dryer and allow it to cool. Clean the removable air filter as described in Section 5.1. Ensure air vents are clear.
Unusual noise during operation.	Debris in the motor; fan obstruction.	Unplug the dryer and check the air filter for debris. If the noise persists, discontinue use and contact customer support.
Appliance suddenly stops during use.	Overheat protection activated.	Unplug the dryer and allow it to cool for at least 10-15 minutes. Check and clean the air filter. Plug back in and try again.

If the problem persists after attempting these solutions, please contact customer support. Do not attempt to repair the appliance yourself.

7. Specifications

Feature	Detail
Brand	Vidal Sassoon
Model Number	VSDR5524
Wattage	1875 watts
Power Source	Corded Electric
Number of Speeds	2
Temperature Settings	2 (Warm, Hot)
Special Features	Lightweight, Compact Design, Removable Filter
Product Dimensions	8.59 x 23.83 x 18.42 cm
Item Weight	535.24 g
Color	Pink

8. Warranty and Support

For information regarding warranty coverage, please refer to the warranty card included with your product or contact Vidal Sassoon customer support. Keep your purchase receipt as proof of purchase.
If you require technical assistance or have questions not covered in this manual, please contact the manufacturer's customer service department. Do not attempt to repair the appliance yourself.

© 2023 Vidal Sassoon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question