Disney Interactive 005511

Disney Interactive G-Force Nintendo DS Game Instruction Manual

Model: 005511

1. Introduction

Welcome to the G-Force Nintendo DS game. This manual provides essential information for setting up, playing, and maintaining your game. G-Force is an action-platform game where players control Darwin, the guinea pig leader, and Mooch, the housefly surveillance sidekick, as they embark on a high-stakes government mission. Utilize high-tech gadgets and specialized talents to navigate environments, solve puzzles, and confront an army of altered household appliances.



Figure 1: G-Force Nintendo DS Game Cover

2. Setup and Installation

2.1 Compatible Consoles

The G-Force game cartridge is compatible with the following Nintendo DS console models:

- Nintendo DS
- Nintendo DS Lite
- Nintendo DSi
- Nintendo DSi XL

2.2 Inserting the Game Cartridge

1. Ensure your Nintendo DS console is powered off.
2. Locate the game card slot on your console.
3. Insert the G-Force game cartridge firmly into the slot until it clicks into place.
4. Power on your Nintendo DS console. The G-Force game icon should appear on the touch screen.

2.3 Starting the Game

From the Nintendo DS main menu, tap the G-Force game icon on the touch screen to begin playing.

3. Operating and Gameplay

G-Force offers a dynamic action-platforming experience. Players will primarily control Darwin, the guinea pig, and occasionally Mooch, the housefly, each with distinct abilities.

3.1 Key Features

- **Character Switching:** Seamlessly switch between Darwin and Mooch to utilize their unique skills for different challenges.
- **Darwin's Abilities:** Darwin is equipped with a hoverpack, allowing for rapid movement across areas and reaching higher altitudes. He also uses various weapons and gadgets.
- **Mooch's Abilities:** Mooch, the housefly, can slow down time, providing strategic advantages in combat and puzzle-solving.
- **Puzzle Solving:** Engage in innovative platform puzzles that require manipulating environments and interacting with objects to progress.
- **Combat:** Battle an array of robotic enemies using a variety of weapons and high-tech gadgets.



Figure 2: G-Force Nintendo DS Game Cartridge Case

3.2 Basic Controls (Standard Nintendo DS)

While specific in-game tutorials will guide you, general controls for Nintendo DS games typically include:

- **D-Pad/Control Pad:** Character movement.
- **A/B/X/Y Buttons:** Actions such as jump, attack, interact, or use special abilities.
- **L/R Buttons:** Often used for camera control, targeting, or secondary actions.
- **Start Button:** Pause menu, access options.
- **Select Button:** May be used for map or inventory.
- **Touch Screen:** Used for menu navigation, specific mini-games, or character switching.

4. Maintenance

To ensure the longevity and proper functioning of your G-Force Nintendo DS game cartridge, follow these simple maintenance guidelines:

- **Storage:** Store the game cartridge in its original case or a protective holder when not in use to prevent dust and physical damage.
- **Cleaning:** If the gold contacts on the back of the cartridge appear dirty, gently wipe them with a soft, dry, lint-free cloth. Avoid using liquids or abrasive materials.
- **Handling:** Always handle the cartridge by its edges. Avoid touching the gold contacts directly.
- **Temperature:** Do not expose the cartridge to extreme temperatures, direct sunlight, or high humidity.

5. Troubleshooting

If you encounter issues while playing G-Force, consider the following troubleshooting steps:

- **Game Not Starting:**
  - Ensure the game cartridge is fully and correctly inserted into the console's slot.
  - Clean the gold contacts on the cartridge as described in the Maintenance section.
  - Try the cartridge in a different compatible Nintendo DS console if available, to rule out a console issue.
- **Game Freezes or Crashes:**
  - Turn off your console, remove the cartridge, reinsert it, and restart the game.
  - Ensure your console's battery is sufficiently charged.
  - If the issue persists, there might be a rare defect with the cartridge.
- **Graphics or Sound Issues:**
  - Check your console's volume settings.
  - Ensure the console screens are clean.
  - Restarting the console often resolves minor graphical glitches.

If these steps do not resolve your issue, please refer to the Support section.

6. Specifications

Feature	Detail
Product Title	G-Force - Nintendo DS
Brand	Disney Interactive
Model Number	005511
UPC	712725005511
Platform	Nintendo DS
Compatible Consoles	Nintendo DS, Nintendo DS Lite, Nintendo DSi, Nintendo DSi XL
Number of Players	2
ESRB Rating	Everyone 10+
Release Date	July 21, 2009
Language	English

Item Weight	1.6 ounces
Product Dimensions	4.98 x 5.4 x 0.62 inches

7. Warranty and Support

7.1 Warranty Information

Specific warranty details for this product are typically provided at the point of purchase or within the original product packaging. Please retain your proof of purchase for any warranty claims. For general information regarding Disney Interactive products, please visit their official website.

7.2 Customer Support

For technical assistance or inquiries not covered in this manual, please refer to the official Disney Interactive support channels. You may find contact information or a support portal on the official Disney Interactive website or through the Nintendo customer support services for general console-related issues.

8. Official Product Videos

No official product videos from the seller are available for embedding at this time.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question