Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jaclo 819-PCH

Jaclo 819-PCH X Long Third Fin Touch Drain User Manual

Model: 819-PCH

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Jaclo 819-PCH X Long Third Fin Touch Drain. Please read this manual thoroughly before beginning installation to ensure proper function and longevity of the product. This drain is designed for use in standard bathroom sinks, featuring a 1-1/4 inch diameter and an 8-inch length, finished in polished chrome.

Safety Information

Always observe basic safety precautions when installing or maintaining plumbing fixtures. Failure to follow these instructions could result in property damage or personal injury.

- Turn off the water supply to the sink before beginning any installation or maintenance.
- Wear appropriate personal protective equipment, such as safety glasses and gloves.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any step, consult a qualified plumber.

Package Contents

Verify that all components are present before starting installation.

- Jaclo 819-PCH X Long Third Fin Touch Drain Assembly (Polished Chrome)
- Upper and Lower Gaskets
- Lock Nut
- Tailpiece

Tools Required

- Adjustable Wrench or Basin Wrench
- Plumber's Putty or Silicone Sealant
- Rag or Towel

- Bucket (for catching water)

Setup and Installation

Follow these steps carefully to install your new drain assembly.







Image: Jaclo 819-PCH X Long Third Fin Touch Drain, Polished Chrome. This image displays the main drain assembly, highlighting its polished chrome finish and overall structure.

1. **Prepare the Sink Opening:** Clean the drain opening in the sink thoroughly, removing any old plumber's putty or sealant. Ensure the surface is dry and smooth.
2. **Apply Sealant to Drain Flange:** Apply a thin bead of plumber's putty or silicone sealant around the underside of the drain flange (the top part that sits inside the sink).
3. **Insert Drain into Sink:** From the top of the sink, insert the drain assembly through the opening, pressing firmly to create a seal with the putty/sealant.
4. **Install Gaskets and Lock Nut:** From underneath the sink, slide the first gasket (usually rubber or foam) onto the drain body, followed by the lock nut. Hand-tighten the lock nut.
5. **Align and Tighten:** Ensure the drain assembly is properly aligned in the sink. Use an adjustable wrench or basin wrench to firmly tighten the lock nut. Do not overtighten, as this can crack the sink or damage the drain. Wipe away any excess plumber's putty or sealant from the sink surface.
6. **Attach Tailpiece:** Thread the tailpiece onto the bottom of the drain body. Ensure a washer is in place for a watertight seal. Hand-tighten, then use a wrench for a final snug turn.
7. **Connect to P-Trap:** Connect the tailpiece to your existing P-trap assembly. Ensure all connections are secure and properly sealed.
8. **Test for Leaks:** Turn on the water supply and fill the sink. Observe all connections (drain flange, lock nut, tailpiece, P-trap) for any signs of leaks. If leaks occur, tighten connections slightly or reapply sealant as needed.

Operating the Third Fin Touch Drain

The Jaclo 819-PCH drain features a "Third Fin Touch" mechanism for opening and closing the drain. This is a push-pop style drain stopper.

- **To Close the Drain:** Gently press down on the top of the drain stopper. It will click into the closed position, sealing the sink.
- **To Open the Drain:** Gently press down on the top of the drain stopper again. It will click and pop up, allowing water to drain.

Maintenance

Regular cleaning and maintenance will help preserve the finish and functionality of your drain.

- **Cleaning the Finish:** Clean the polished chrome finish with a soft, damp cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish. Rinse thoroughly and dry with a soft cloth to prevent water spots.
- **Cleaning the Drain Stopper:** Periodically remove the drain stopper by unscrewing it (if applicable, or by pulling firmly if it's a simple push-in type) to clear any hair or debris that may accumulate. Clean the stopper and the inside of the drain body with a brush and mild cleaner.
- **Check for Leaks:** Occasionally inspect the connections underneath the sink for any signs of leaks or drips. Tighten connections if necessary.

Troubleshooting

Problem	Possible Cause	Solution
Slow Draining	Hair or debris accumulation in the drain or P-trap.	Remove the drain stopper and clean out any obstructions. If the issue persists, clean the P-trap.
Water Leaks from Connections	Loose connections or improperly sealed gaskets.	Ensure all nuts are tightened securely. Check gaskets for proper seating and condition. Reapply plumber's putty or silicone sealant if necessary.
Drain Stopper Not Sealing	Debris under the stopper or stopper mechanism malfunction.	Remove the stopper and clean any debris from its seating area. Inspect the stopper mechanism for damage.

Specifications

- **Model:** 819-PCH
- **Type:** X Long Third Fin Touch Drain
- **Size:** 1-1/4" x 8"
- **Finish:** Polished Chrome
- **Material:** Metal (specific alloy not provided, but typical for plumbing fixtures)
- **Product Dimensions:** Approximately 2.12 x 2.12 x 10 inches (as per product data)
- **Item Weight:** Approximately 1.05 pounds (as per product data)

Warranty and Support

For warranty information or technical support, please contact Jaclo customer service directly. Refer to the official Jaclo website or your purchase documentation for specific warranty terms and contact details.
Jaclo Official Website: www.jaclo.com

© 2023 Jaclo. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0028BTAK0

More documents and user manuals: **https://manuals.plus/**