Calvin Klein K9814220

Calvin Klein K9814220 Men's Quartz Chronograph Watch

Instruction Manual

Model: K9814220 | Brand: Calvin Klein

Introduction

This manual provides detailed instructions for the proper use and care of your Calvin Klein K9814220 Men's Quartz Chronograph Watch. Please read this manual thoroughly before using your watch to ensure optimal performance and longevity.

Watch Components

Familiarize yourself with the main components of your watch:

- **Crown:** Used for setting time.
- **Pushers:** Used for operating the chronograph functions.
- **Dial:** Displays time and chronograph sub-dials.
- **Hands:** Hour, minute, second, and chronograph hands.
- **Strap:** Leather strap with buckle closure.
- **Case Back:** Contains model and manufacturing information.



Image: Front view of the Calvin Klein K9814220 watch, showcasing the silver dial, chronograph sub-dials, and black leather strap.

Setup and Initial Adjustment

Setting the Time

1. Pull the crown out to position 2 (fully extended). The second hand will stop.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time.
3. Push the crown back into position 1 (normal operating position). The second hand will resume movement.

Strap Adjustment

The watch features a leather strap with a tang buckle closure. Adjust the strap by inserting the pin into the desired hole for a comfortable and secure fit on your wrist.



Image: The Calvin Klein K9814220 watch worn on a wrist, illustrating how the strap fits and can be adjusted.

Operating the Chronograph

Your Calvin Klein K9814220 watch is equipped with a chronograph function for measuring elapsed time.



Image: Side view of the watch, highlighting the crown and the two pushers used for chronograph operation.

1. **Start/Stop:** Press the upper pusher to start the chronograph. Press it again to stop.
2. **Reset:** While the chronograph is stopped, press the lower pusher to reset all chronograph hands to their zero positions.
3. **Reading the Chronograph:** The sub-dials indicate elapsed seconds, minutes, and hours (if applicable to the specific movement). The large central second hand typically functions as the chronograph second hand when activated.

Note: Ensure the crown is fully pushed in (position 1) before operating the chronograph pushers to prevent damage and maintain water resistance.

Care and Maintenance

Cleaning

- Wipe the watch case and crystal with a soft, dry cloth.
- For the leather strap, avoid excessive moisture and harsh chemicals. Clean with a damp cloth and mild soap if necessary, then dry thoroughly.

Water Resistance

Your watch has a water resistance rating of 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, but not for diving or snorkeling. Do not operate the crown or pushers when the watch is wet or submerged.

Battery Replacement

The watch is powered by a quartz movement and requires a battery. When the watch stops or the second hand begins to jump irregularly (if applicable), the battery may need replacement. It is recommended to have the battery replaced by an authorized Calvin Klein service center or a qualified watchmaker to ensure proper sealing and maintain water resistance.





Image: Rear view of the watch, displaying the stainless steel case back with engraved Calvin Klein logo and model information.

Troubleshooting

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Incorrect time:** Reset the time as described in the "Setting the Time" section.
- **Chronograph hands not resetting to zero:** This may indicate a need for calibration or service. Consult an authorized service center.

For issues not resolved by these steps, please contact an authorized Calvin Klein service center.

Specifications

Model Number	K9814220
Brand	Calvin Klein
Movement Type	Quartz
Case Diameter	42 Millimetres
Case Thickness	1 Millimetres

Band Material Type	Synthetic (Leather)
Band Width	20 Millimetres
Dial Colour	Silver (multi-colour)
Crystal Material	Mineral
Water Resistance Depth	50 Metres (5 ATM)
Special Feature	Chronograph
Item Weight	68 Grams

Warranty Information

Your Calvin Klein K9814220 watch is covered by a manufacturer's warranty. For specific terms, conditions, and duration of the warranty, please refer to the official Calvin Klein website or the warranty card included with your purchase. The warranty typically covers manufacturing defects but generally excludes damage caused by improper use, accidents, or unauthorized repairs.

Customer Support

Should you require assistance, service, or have questions regarding your Calvin Klein watch, please contact Calvin Klein customer service or visit an authorized service center. You can find contact information and service center locations on the official Calvin Klein website.
For more information, you may visit theCalvin Klein Store on Amazon.

© 2023 Calvin Klein. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question