PlayStation 98058

PlayStation Move Motion Controller (Model 98058) Instruction Manual

Introduction

The PlayStation Move Motion Controller redefines motion gaming by offering an immersive and realistic gaming experience exclusively on the PlayStation 3 system. This easy-to-use controller accurately captures a full range of motion, providing ultimate control over gameplay. With a diverse selection of games, users can enjoy hours of entertainment with friends and family.

Features

- Accurately tracks your every movement, precisely capturing both fast and subtle actions.
- The sphere's light provides visual feedback during gameplay, enhancing immersion.
- Vibration feedback is felt during specific in-game actions, adding to the realism.
- Can be paired with a navigation controller (sold separately) for expanded control in compatible games.
- Charge the controller and automatically pair it with the PS3 system via a USB cable.

Setup

1. **Charging the Controller:** Connect the PlayStation Move Motion Controller to your PlayStation 3 system using a USB cable. The controller will begin charging automatically. Ensure the controller is fully charged before initial use for optimal performance.
2. **Pairing with PS3 System:** While connected via USB, press the PS button on the controller. This will automatically pair the controller with your PS3 system. Once paired, you can disconnect the USB cable for wireless play.
3. **Connecting PlayStation Eye Camera:** For motion tracking functionality, ensure your PlayStation Eye camera is properly connected to your PS3 system and positioned correctly according to its own instruction manual. The camera is essential for the controller's precise motion tracking.

Operating the Controller

The PlayStation Move Motion Controller is designed for intuitive interaction within games. Its advanced sensors and the PlayStation Eye camera work in tandem to provide highly accurate motion tracking.

- **Motion Tracking:** The controller's internal sensors and the PlayStation Eye camera track its precise position and orientation in 3D space, allowing for 1:1 movement translation in compatible games.
- **Sphere Light:** The glowing sphere at the top of the controller changes color to provide visual feedback, often indicating player assignment, in-game status, or specific actions.
- **Vibration Feedback:** The controller features haptic feedback, which provides tactile sensations (vibrations) to enhance immersion during gameplay, such as when hitting an object or performing an action.
- **Button Functions:** Utilize the various buttons on the controller (PS button, Move button, Trigger, Action buttons) for in-game commands and system navigation. Refer to individual game manuals for specific button assignments.
- **Using with Navigation Controller:** For games that support it, pair a PlayStation Move Navigation Controller (sold separately) to gain additional control options, typically for character movement or menu navigation, complementing the Motion Controller's actions.

Maintenance

- Keep the controller clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the controller in a dry place, away from direct sunlight and extreme temperatures.
- Avoid dropping or subjecting the controller to strong impacts, as this may damage internal components.
- Ensure the wrist strap is securely attached and used during active gameplay to prevent accidental drops.

Troubleshooting

- **Controller Not Responding:** Ensure the controller is fully charged. Reconnect it via USB to re-establish the connection and re-pair if necessary.
- **Inaccurate Tracking:** Verify that the PlayStation Eye camera is properly positioned and that the play area is well-lit, but without excessive glare. Ensure there are no obstructions between the camera and the controller.
- **Vibration Not Working:** Check in-game settings to ensure vibration feedback is enabled. If the issue persists, try resetting the controller by pressing the reset button (usually a small pinhole on the back) with a thin object.
- For further assistance, refer to the PlayStation 3 system manual or visit the official PlayStation support website.

Specifications

Item Model Number	98058
Manufacturer	Sony Computer Entertainment
Product Dimensions	7.5 x 5.3 x 0.6 inches

Item Weight	5.3 ounces
Batteries	1 Lithium Ion batteries required
Release Date	September 17, 2010

Warranty and Support

For detailed warranty information, product registration, and customer support, please visit the official PlayStation website or contact PlayStation customer service directly. Keep your proof of purchase for any warranty claims.

Product Images





Front view of the PlayStation Move Motion Controller in its packaging.



User holding the PlayStation Move Motion Controller with the wrist strap attached.





Another view of a user holding the PlayStation Move Motion Controller with the wrist strap.



Close-up of the PlayStation Move Motion Controller with a blue glowing sphere.

Product Videos

Official product video showcasing the PlayStation 3 Move Motion Controller.

An overview video detailing the features and capabilities of the PlayStation Move.

A video showcasing the PlayStation Move's advanced motion tracking capabilities.

Developer Anton Mikhailov discusses the technical aspects and potential of PlayStation Move.