Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CalExotics 1831-04-3

CalExotics Triple Clit Flicker Ring

Instruction Manual - Model 1831-04-3

Brand: CalExotics

1. Introduction

The CalExotics Triple Clit Flicker Ring, Model 1831-04-3, is designed to provide simultaneous stimulation. It features a flexible enhancer ring with triple prongs and a removable micro vibrator. This manual provides essential information for the proper and safe use of your product.

2. Important Safety Information

- **Age Restriction:** This product is intended for adult use only. Purchasers must be at least 18 years of age or older.
- **Body-Safe Materials:** The enhancer ring is made from PVC, and the stimulator from ABS plastic with silver plating. These materials are phthalate-free and non-toxic.
- **Cleaning:** Always clean the product thoroughly before and after each use. Refer to the 'Maintenance and Care' section for detailed cleaning instructions.
- **Lubrication:** A water-based lubricant is recommended for comfortable use. Avoid oil-based lubricants, as they may damage the product materials.
- **Battery Safety:** Ensure batteries are inserted correctly. Remove batteries if the product will not be used for an extended period to prevent leakage.
- **Medical Disclaimer:** Statements regarding this product have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. Consult a healthcare professional if you have any concerns.

3. Package Contents

Your CalExotics Triple Clit Flicker Ring package should contain the following items:

- 1 x Triple Clit Flicker Enhancer Ring (PVC)
- 1 x Removable Micro Vibrator (ABS plastic with silver plating)

- 6 x LR44 Watch Batteries (3 for immediate use, 3 spares)

4. Setup

Follow these steps to prepare your Triple Clit Flicker Ring for first use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before initial use, clean the enhancer ring and vibrator according to the 'Maintenance and Care' instructions.
3. **Install Batteries:** The micro vibrator requires 3 LR44 watch batteries. Locate the battery compartment on the vibrator. Unscrew the cap, insert the batteries with the correct polarity (+/-), and securely screw the cap back on. The vibrator should activate upon battery insertion.
4. **Insert Vibrator:** Gently insert the activated micro vibrator into the designated opening on the enhancer ring. Ensure it is seated firmly.



Image 1: CalExotics Triple Clit Flicker Ring. This image highlights key features: soft teasing triple prongs, a powerful wireless 3-speed removable stimulator, and stretchy, comfortable support for the wearer. The text also notes that vibration resonates throughout, it's sized for comfort and intensity, body-safe, unscented, phthalate-free, and may be used in or out of water.

5. Operating Instructions

To use your CalExotics Triple Clit Flicker Ring:

1. **Lubricate:** Apply a generous amount of water-based lubricant to the enhancer ring and the area of application for comfortable placement.
2. **Placement:** Position the stretchy enhancer ring at the base. The triple prongs, with the inserted vibrator, should be oriented to provide desired external stimulation.
3. **Activate Vibrator:** The micro vibrator typically activates upon battery insertion. If it has a power button, press it to cycle through vibration modes (if applicable).
4. **Adjust:** Adjust the position of the ring and prongs as needed to achieve optimal comfort and stimulation.
5. **After Use:** After use, carefully remove the product and proceed with cleaning as described in the 'Maintenance and Care' section.

6. Maintenance and Care

Proper care will extend the life of your product:

- **Cleaning:** Always clean the product before and after each use. Separate the vibrator from the enhancer ring. Wash both components with warm water and a mild, toy-safe soap. Rinse thoroughly.
- **Drying:** Pat dry with a lint-free cloth or allow to air dry completely before storage.
- **Storage:** Store the product in a clean, dry place, away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent potential reactions.
- **Battery Replacement:** When vibrations weaken, replace the LR44 batteries in the micro vibrator. Ensure proper disposal of used batteries.

7. Troubleshooting

If you encounter issues with your Triple Clit Flicker Ring, refer to the following:

- **Vibrator Not Working:**
  - Check battery orientation: Ensure the LR44 batteries are inserted with the correct polarity.
  - Replace batteries: The batteries may be depleted. Replace all three LR44 batteries with new ones.
  - Check connections: Ensure the battery cap is screwed on tightly to ensure proper contact.
- **Discomfort During Use:**
  - Apply more lubricant: Ensure sufficient water-based lubricant is used.
  - Adjust position: Experiment with different placements of the ring and prongs to find the most comfortable and effective position.

8. Specifications

Model Number	1831-04-3
Brand	CalExotics
Enhancer Ring Material	PVC (Polyvinyl Chloride)

Stimulator Material	ABS (Acrylonitrile Butadiene Styrene) plastic with silver plating
Color	Multi
Enhancer Ring Dimensions	Approximately 3 inches (8 cm) long x 2 inches (5 cm) wide
Stimulator Dimensions	Approximately 1.5 inches (4 cm) long x 0.6 inches (2 cm) wide
Product Dimensions (Overall)	2 x 4 x 8.5 inches; 3.8 ounces
Batteries Required	3 x LR44 watch batteries (included)

9. Support

For further assistance or inquiries regarding your CalExotics Triple Clit Flicker Ring, please contact CalExotics customer support. Refer to the product packaging or the official CalExotics website for contact information.

© 2024 CalExotics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002JINQQQ

More documents and user manuals: **https://manuals.plus/**