Hasbro 63453

G.I. Joe Ninja Storm Shadow Comic Series Action Figure User Manual

Model: 63453

Introduction

This manual provides instructions for the Hasbro G.I. Joe Ninja Storm Shadow Comic Series action figure. Please read this guide carefully to ensure proper handling and enjoyment of your product. This action figure is designed for collectors and enthusiasts aged 5 years and up.



Image: The G.I. Joe Ninja Storm Shadow Comic Series action figure, typically shown in its original packaging, highlighting its design and accessories.

Setup

1. **Unboxing:** Carefully remove the action figure and any accessories from its packaging. Retain packaging for future storage if desired.
2. **Accessory Identification:** Identify all included accessories, such as weapons or interchangeable parts. Refer to the product image on the packaging for a complete list.
3. **Initial Inspection:** Inspect the figure for any manufacturing defects or damage. Contact customer

support if any issues are found.

Operating

The G.I. Joe Ninja Storm Shadow action figure features multiple points of articulation for dynamic posing.

- **Posing:** Gently manipulate the joints (shoulders, elbows, hips, knees, neck) to achieve desired poses. Avoid excessive force to prevent breakage.
- **Accessory Attachment:** Attach accessories by carefully inserting them into the figure's hands or designated slots. Ensure a snug fit without forcing.
- **Display:** The figure can be displayed on a flat surface or with a compatible action figure stand (not included).

Maintenance

- **Cleaning:** To clean the figure, gently wipe it with a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap can be used, followed by immediate drying. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the action figure away from direct sunlight, extreme temperatures, and high humidity to prevent discoloration or material degradation.
- **Joint Care:** If joints become stiff, gently warm the area with a hairdryer on a low setting for a few seconds to loosen the plastic, then carefully articulate the joint. Do not apply excessive heat.

Troubleshooting

Problem	Solution
Stiff joints	Gently warm the joint area with a hairdryer on a low setting for a few seconds to soften the plastic, then carefully move the joint.
Accessories do not fit	Ensure the accessory is oriented correctly. Do not force. If still an issue, check for any plastic molding imperfections.
Paint chipping	This can occur with heavy play or friction. Handle with care. Minor touch-ups may be possible with appropriate model paints, but this is not recommended by the manufacturer.

Specifications

- **Product Dimensions:** 4.8 x 2.5 x 1.1 inches
- **Item Weight:** 2.4 ounces
- **Model Number:** 63453
- **Manufacturer Recommended Age:** 5 years and up
- **Manufacturer:** HASBRO

Warranty and Support

Specific warranty information for this product is not detailed in this manual. For warranty claims, product support, or further inquiries, please visit the official Hasbro website or contact their customer service

department. You can find more information at the Hasbro Store on Amazon or their official corporate website.

© 2024 Hasbro. All rights reserved. G.I. Joe and all related characters are trademarks of Hasbro.