Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi KG89

De'Longhi KG89 Stainless Steel Burr Coffee Grinder Instruction Manual

Model: KG89

Product Overview

The De'Longhi KG89 Burr Coffee Grinder is designed to provide fresh, aromatic coffee grounds from whole beans. It features a sleek stainless steel exterior and a burr grinding wheel for consistent results. This grinder is suitable for preparing grounds for various coffee types, from coarse to fine, and can process enough coffee for 2 to 12 cups at a time.



Figure 1: De'Longhi KG89 Stainless Steel Burr Coffee Grinder.

Setup

Before first use, ensure all packaging materials are removed and the appliance is placed on a stable, flat surface. Clean

all removable parts with warm, soapy water and dry thoroughly.

Filling the Bean Hopper

Open the lid of the bean hopper located at the top of the grinder. Pour whole coffee beans into the hopper. Do not overfill beyond the 'MAX' indicator. Close the lid securely.



Figure 2: Close-up of the bean hopper with 'MAX' indicator.

Operating Instructions

Selecting Grind Setting

The De'Longhi KG89 offers a range of grind settings from fine to coarse. Rotate the grind selector dial on the front of the unit to choose your desired fineness. Refer to the table below for recommended settings based on brewing method:



Figure 3: Grind selector dial with Fine, Medium, and Coarse indicators.

Recommended Grind Settings

Brewing Method	Grind Setting
Espresso	Fine
Drip Coffee	Medium
French Press	Coarse

Selecting Coffee Quantity

Use the quantity control knob to select the number of cups you wish to grind for (from 2 to 12 cups). The grinder will automatically shut off once the selected quantity is ground.



Figure 4: Quantity control knob for 2-12 cups.

Grinding Coffee

Ensure the ground coffee container is properly inserted into its compartment. Press the ON/OFF switch to begin grinding. The grinder will stop automatically when the selected quantity is reached.



Figure 5: Ground coffee container.

Maintenance

Cleaning the Grinder

Regular cleaning is essential for maintaining the performance and lifespan of your grinder. Always unplug the appliance before cleaning.

1. Remove the bean hopper and ground coffee container.
2. Use a soft brush or cloth to remove any residual coffee grounds from the grinding chamber and burrs.
3. Wash the bean hopper lid, ground coffee container, and its lid with warm, soapy water. Rinse thoroughly and dry completely before reassembling.
4. Wipe the exterior of the grinder with a damp cloth. Do not immerse the main unit in water.

Troubleshooting

If your grinder is not functioning as expected, please check the following common issues:

- **Grinder does not turn on:** Ensure the power cord is securely plugged into a working outlet. Check that the bean hopper lid and ground coffee container are correctly and securely in place, as the unit has safety interlocks.
- **Coffee is not grinding:** Verify that there are enough whole beans in the hopper. Check for any blockages in the grinding chamber or dispensing chute.
- **Inconsistent grind:** Ensure the burrs are clean and free of old coffee residue. Adjust the grind setting as needed for your desired consistency.

Specifications

Model: KG89

Brand: De'Longhi

Color: Silver

Product Dimensions: 6.3"L x 5.1"W x 10.2"H

Item Weight: 3.5 pounds

Voltage: 110 Volts

Grinding Mechanism: Burr Grinder

Capacity: Grinds for 2-12 cups

Warranty & Support

For warranty information and customer support, please refer to the warranty card included in your product packaging or

visit the official De'Longhi website. Keep your purchase receipt as proof of purchase.

© 2023 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002OHDBQ2

More documents and user manuals: **https://manuals.plus/**