Equinox 506664

Equinox Electric Gravity Pepper Grinder

Model: 506664

Introduction

Thank you for purchasing the Equinox Electric Gravity Pepper Grinder. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and retain them for future reference.

Important Safety Instructions

- Keep the appliance out of reach of children.
- Do not immerse the grinder in water or any other liquid.
- Use only the specified type and number of batteries.
- Remove batteries if the grinder will not be used for an extended period.
- Do not attempt to grind substances other than whole peppercorns or similar dry spices.
- Avoid contact with moving parts during operation.
- Do not operate if the appliance appears damaged.

Product Components

The Equinox Electric Gravity Pepper Grinder consists of a main body, a battery compartment, a spice chamber, and an adjustable grinding mechanism.



Image: A tall, sleek electric pepper grinder with a silver-colored body and a black top section. The transparent window

near the top allows visibility of the contents. The design is ergonomic for easy handling.

Setup and First Use

Battery Installation

1. Locate the battery compartment, typically at the top or bottom of the grinder.
2. Twist or pull to open the battery compartment cover.
3. Insert the required number of batteries (e.g., 6 x AAA, not included) according to the polarity indicators (+/-).
4. Securely close the battery compartment cover.

Filling the Grinder

1. Twist or pull to open the spice chamber, usually located below the battery compartment or at the base.
2. Fill the chamber with whole peppercorns or other dry spices. Do not overfill.
3. Securely close the spice chamber cover.

Operating Instructions

This electric gravity grinder operates automatically. Simply tilt the grinder downwards to activate the grinding mechanism. The grinder will stop automatically when returned to an upright position.

Adjusting Grind Coarseness

To adjust the coarseness of the grind, locate the adjustment knob or ring, typically at the bottom of the grinder near the ceramic grinding mechanism. Turn the knob clockwise for a finer grind and counter-clockwise for a coarser grind.

Care and Maintenance

Cleaning

- Ensure the grinder is empty and batteries are removed before cleaning.
- Wipe the exterior of the grinder with a soft, damp cloth. Do not use abrasive cleaners.
- The grinding mechanism can be cleaned with a small brush to remove residual spices.
- Do not wash any part of the grinder in a dishwasher or immerse it in water.

Storage

Store the grinder in a dry place, away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries.

Troubleshooting

Problem	Possible Cause	Solution
Grinder does not operate.	Batteries are dead or incorrectly installed.	Check battery polarity or replace with new batteries.

Problem	Possible Cause	Solution
Grinder produces inconsistent grind.	Grinding mechanism is clogged or adjustment is loose.	Clean the grinding mechanism or adjust the coarseness setting.
No spice is dispensed.	Spice chamber is empty or clogged.	Refill the spice chamber or clear any blockages.

Product Specifications

- **Model:** 506664
- **Material:** Metal
- **Color:** Silver
- **Operation Mode:** Automatic (Gravity-activated)
- **Dimensions:** 8 x 8 x 25 cm
- **Weight:** 270 g

Warranty Information

This Equinox product comes with a 1-year limited warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accident, alteration, or unauthorized repair. Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact Equinox customer support through the retailer where the product was purchased or refer to the official Equinox website for contact details.