Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Elta 4567N

Elta 4567N Light'n Wake Alarm Clock User Manual

Model: 4567N

1. Introduction

Thank you for purchasing the Elta 4567N Light'n Wake Alarm Clock. This device combines a digital alarm clock with a PLL synthesizer tuner and a selection of wellness sounds to enhance your waking experience. Please read this manual carefully before using the product to ensure proper operation and to maintain its longevity.

1.1 Safety Instructions

- Do not expose the unit to rain or moisture to prevent fire or electric shock.
- Do not expose the unit to direct sunlight, extreme temperatures, or high humidity.
- Ensure the unit is placed on a stable, flat surface.
- Do not open the casing. Refer all servicing to qualified personnel.
- Clean the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the unit away from strong magnetic fields.

2. Package Contents

Please check that all items are present upon unpacking:

- Elta 4567N Light'n Wake Alarm Clock Unit
- Power Adapter (AC)
- User Manual (this document)

3. Product Overview

Familiarize yourself with the various parts and controls of your alarm clock.



Figure 1: Front view of the Elta 4567N Light'n Wake Alarm Clock. This image shows the round, silver-colored unit with a central digital display and various control buttons arranged around it. The display is illuminated with a blue backlight.

3.1 Front Panel Controls

- **Display:** Dimmable LCD with blue backlight, showing time and settings.
- **Time Set Button:** Used to enter time setting mode.
- **Alarm 1 Set Button:** Used to set the first alarm time.
- **Alarm 2 Set Button:** Used to set the second alarm time.

- **Up/Down Buttons:** Used to adjust time, alarm, and radio frequencies.
- **Mode/Function Button:** Toggles between different modes (e.g., Radio, Alarm Sound, Wellness Sound).
- **Snooze/Sleep Button:** Activates snooze function or sets sleep timer.
- **Volume +/- Buttons:** Adjusts the audio output volume.
- **Light/Dimmer Button:** Adjusts the brightness of the LCD display.

3.2 Rear Panel Connections

- **DC In Jack:** For connecting the power adapter.
- **FM Antenna:** For improved radio reception.

4. Setup

4.1 Power Connection

1. Insert the DC plug of the power adapter into the DC In jack on the rear of the alarm clock.
2. Plug the power adapter into a standard AC wall outlet.
3. The display will light up, and the clock will be ready for initial setup.

4.2 Setting the Current Time

1. Press and hold the **Time Set** button until the hour digits begin to flash on the display.
2. Use the **Up** or **Down** buttons to adjust the hour.
3. Press the **Time Set** button again. The minute digits will begin to flash.
4. Use the **Up** or **Down** buttons to adjust the minutes.
5. Press the **Time Set** button one more time to confirm and exit time setting mode. The time is now set.

5. Operating Instructions

5.1 Setting Alarms (Alarm 1 and Alarm 2)

The Elta 4567N allows you to set two independent alarm times.

1. Press and hold the **Alarm 1 Set** button (or **Alarm 2 Set** button) until the alarm hour digits begin to flash.
2. Use the **Up** or **Down** buttons to set the desired alarm hour.
3. Press the **Alarm 1 Set** button (or **Alarm 2 Set** button) again. The alarm minute digits will flash.
4. Use the **Up** or **Down** buttons to set the desired alarm minutes.
5. Press the **Alarm 1 Set** button (or **Alarm 2 Set** button) again to select the wake-up source. Options typically include:
    - **Buzzer:** Standard alarm sound.
    - **Radio:** Wakes you to the last tuned radio station.
    - **Wellness Sounds:** Cycles through available nature sounds.

    Use the **Up** or **Down** buttons to select your preferred wake-up source.
6. Press the **Alarm 1 Set** button (or **Alarm 2 Set** button) one more time to confirm and activate the alarm. An alarm icon (e.g., "AL1" or "AL2") will appear on the display.

5.2 Disabling/Enabling Alarms

To toggle an alarm on or off, briefly press the corresponding **Alarm 1 Set** or **Alarm 2 Set** button. The alarm icon will appear (on) or disappear (off) from the display.

5.3 Snooze Function

When an alarm sounds, press the **Snooze/Sleep** button to temporarily silence it. The alarm will sound again after approximately 9 minutes.

5.4 Stopping an Alarm

To stop an alarm completely after it sounds, press any button other than the **Snooze/Sleep** button. The alarm will reset for the next day.

5.5 Radio Operation (PLL Synthesizer Tuner)

1. Press the **Mode/Function** button repeatedly until "FM" or the radio frequency appears on the display.
2. Extend the FM antenna for better reception.
3. Use the **Up** or **Down** buttons to manually tune to a desired radio station. Press and hold these buttons for automatic station scanning.
4. Adjust the volume using the **Volume +/-** buttons.

5.6 Wellness Sounds

The alarm clock features various wellness sounds such as sea sounds and summer forest sounds.

1. To listen to wellness sounds, press the **Mode/Function** button until the wellness sound mode is active (indicated by a specific icon or text).
2. Use the **Up** or **Down** buttons to cycle through the available wellness sounds.
3. Adjust the volume using the **Volume +/-** buttons.

5.7 Display Brightness (Dimmer)

Press the **Light/Dimmer** button repeatedly to cycle through different brightness levels for the LCD display, or to turn the backlight off.

5.8 Sleep Timer

The sleep timer allows you to fall asleep to radio or wellness sounds, which will automatically turn off after a set period.

1. While listening to the radio or wellness sounds, press the **Snooze/Sleep** button repeatedly.
2. Each press will cycle through available sleep timer durations (e.g., 90, 60, 30, 15 minutes, OFF).
3. Select your desired duration. The unit will automatically turn off after the selected time.

6. Maintenance

6.1 Cleaning

- Unplug the unit from the power outlet before cleaning.
- Use a soft, dry, lint-free cloth to wipe the exterior surfaces.
- Do not use liquid cleaners, aerosol sprays, or abrasive cleaning agents, as these may damage the finish or internal components.

6.2 Storage

If you plan not to use the alarm clock for an extended period, unplug it from the power outlet and store it in a cool, dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
No power/Display off	Power adapter not connected or faulty outlet.	Ensure power adapter is securely plugged into the unit and a working wall outlet. Try a different outlet.
Alarm does not sound	Alarm not set or disabled. Volume too low.	Verify alarm time is set correctly and the alarm is enabled (icon visible). Increase volume.
Poor radio reception	Antenna not extended or poor signal area.	Fully extend the FM antenna. Reposition the unit for better reception.
Buttons unresponsive	Temporary software glitch.	Unplug the unit from power for a few minutes, then plug it back in to reset.

8. Specifications

Model:	Elta 4567N
Display Type:	Digital LCD with blue backlight
Tuner:	PLL Synthesizer
Wake-up Options:	Buzzer, Radio, Wellness Sounds (Sea, Summer Forest, etc.)
Alarm Settings:	Two independent alarms
Power Source:	AC Power Adapter (specific voltage/current not provided, refer to adapter label)
Dimensions (Approx.):	28.2 x 26.2 x 16.8 cm (Package dimensions, actual unit may vary slightly)
Weight (Approx.):	1.46 kg (Package weight, actual unit may vary slightly)
Material:	Aluminium, Acrylonitrile Butadiene Styrene (ABS)

9. Warranty and Support

Elta products are designed and manufactured to the highest quality standards. For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Elta website. Please retain your proof of purchase for any warranty claims.
For technical assistance or service inquiries, please contact Elta customer support through their official channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002TOKX1G

More documents and user manuals: **https://manuals.plus/**