EMSA 507267

Emsa Multi-Grater Instruction Manual

Model: 507267

Introduction

The Emsa Multi-Grater (Model 507267) is a versatile kitchen tool designed for convenient and safe grating, shredding, and slicing of various fruits and vegetables. Its smart design includes a closed container to keep your kitchen tidy during use. This manual provides instructions for the proper setup, operation, maintenance, and troubleshooting of your Emsa Multi-Grater.



Image: The Emsa Multi-Grater, showing its main components: the white grating surface with a green insert, a green food holder, and a clear collection container.

Product Components

Your Emsa Multi-Grater comes with the following components:

- Main Grater Unit (white frame with integrated blade slot)
- Clear Collection Container
- Food Holder with Finger Guard (green top)
- Three Interchangeable Inserts:
    - Fine Grating Insert
    - Coarse Grating Insert
    - Slicing Insert



Image: The three distinct interchangeable inserts for the Emsa Multi-Grater, showing their different blade patterns for fine grating, coarse grating, and slicing.

Setup and Assembly

1. **Unpack Components:** Carefully remove all parts from the packaging. Inspect for any damage.
2. **Wash Before First Use:** Before initial use, wash all components (main grater unit, collection container, food holder, and inserts) with warm soapy water. Rinse thoroughly and dry. All parts are dishwasher safe.
3. **Assemble Container:** Place the main grater unit securely onto the clear collection container. Ensure it sits firmly to prevent movement during use.
4. **Insert Grating Blade:** Select the desired grating or slicing insert. Slide the chosen insert into the slot on the main grater unit until it clicks into place. Ensure it is fully seated and stable.



Image: A person's hands demonstrating how to insert one of the green grating blades into the white main grater unit, showing the secure fit.



Image: The Emsa Multi-Grater fully assembled and ready for use, with the chosen insert in place and the food holder positioned on top.

Operating Instructions

Follow these steps for safe and effective use of your Emsa Multi-Grater:

1. **Prepare Food:** Wash and peel the fruit or vegetable you intend to grate or slice. Cut it into pieces that fit comfortably into the food holder.
2. **Secure Grater:** Place the assembled grater on a stable, flat surface. The non-slip base of the collection container helps keep it steady.
3. **Use Food Holder:** Place the food item into the food holder. Position the food holder over the chosen grating insert.
4. **Grating/Slicing:** Apply gentle, even pressure to the food holder and move it back and forth over the grating insert. The sharp blades will quickly process the food, and the grated or sliced pieces will fall directly into the collection container below. Always use the food holder to protect your fingers.
5. **Empty Container:** Once you have grated the desired amount or the container is full, carefully lift the main grater unit off the collection container and empty the contents.



Image: A person demonstrating the use of the Emsa Multi-Grater, actively grating carrots into the clear collection container using the green food holder for safety.

Safety Precautions:

- Always use the food holder to protect your fingers from the sharp blades.
- Keep out of reach of children.
- Handle inserts with care as blades are very sharp.
- Do not attempt to grate extremely hard foods that may damage the blades.

Maintenance and Cleaning

Proper cleaning and maintenance will ensure the longevity and performance of your Emsa Multi-Grater.

- **Disassembly:** After each use, disassemble the grater by removing the food holder, the grating insert, and separating the main grater unit from the collection container.
- **Washing:** All components are dishwasher safe. For hand washing, use warm soapy water and a brush to remove any food particles from the blades. Rinse thoroughly.
- **Drying:** Allow all parts to air dry completely before reassembling or storing.
- **Storage:** Store all components together in a safe place to prevent loss and protect the blades.

Troubleshooting

Problem	Possible Cause	Solution
Food not grating effectively.	Blade is dull or incorrect insert used for food type.	Ensure the correct insert is used (e.g., coarse for harder vegetables). Blades are designed to be sharp; if performance significantly degrades, consider replacement.
Grater slides during use.	Surface is wet or oily; non-slip base is dirty.	Ensure the countertop is clean and dry. Clean the non-slip base of the collection container.
Food gets stuck in blades.	Food pieces are too large or too soft.	Cut food into smaller, manageable pieces. For softer foods, use a firmer, consistent pressure. Clean blades immediately after use.

Specifications

Feature	Detail
Brand	EMSA
Model Number	507267
Color	White / Green
Product Dimensions (L x W x H)	27.5 x 11 x 8 cm
Weight	400 g
Material	Plastic
Dishwasher Safe	Yes
Included Inserts	3 (Fine, Coarse, Slicing)

Warranty and Support

For information regarding warranty coverage and customer support, please refer to the official Emsa website or contact their customer service department. Keep your purchase receipt as proof of purchase.
Emsa Official Website: www.emsa.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question