**Taylor 1523**

# Taylor #1523 Indoor/Outdoor Thermometer & Humidity Guide User Manual

Model: 1523

## 1. INTRODUCTION

Thank you for choosing the Taylor #1523 Indoor/Outdoor Thermometer & Humidity Guide. This device is designed to provide accurate indoor and outdoor temperature readings, along with indoor humidity levels. Please read this manual carefully to ensure proper setup, operation, and maintenance of your thermometer.



*Image 1: Taylor #1523 Indoor/Outdoor Thermometer and Humidity Guide. This image shows the front view of the thermometer unit, displaying temperature and humidity readings.*

## 2. PRODUCT FEATURES

- Simultaneous display of indoor and outdoor temperature.
- Displays indoor humidity levels.
- Switchable temperature units (Celsius or Fahrenheit).
- Records and displays minimum and maximum temperature/humidity readings.
- Backlight for easy reading in low light conditions.
- Versatile placement: desktop stand or wall-mountable.

# 3. Package Contents

- Taylor #1523 Thermometer Unit
- Outdoor Temperature Sensor (wired)
- User Manual

*Note: One AAA battery is required for operation and is not typically included.*

# 4. Setup

## 4.1 Battery Installation

1. Locate the battery compartment on the back of the unit.
2. Remove the battery compartment cover.
3. Insert one (1) AAA battery, ensuring correct polarity (+ and -).
4. Replace the battery compartment cover.

## 4.2 Sensor Placement

- **Indoor Unit:** Place the main thermometer unit indoors in a location away from direct sunlight, heat sources, or drafts that could affect temperature and humidity readings. It can be placed on a desktop using its integrated stand or mounted on a wall using the keyhole slot on the back.
- **Outdoor Sensor:** Route the wired outdoor temperature sensor outside. For accurate readings, place the sensor in a shaded area, protected from direct sunlight and precipitation. Ensure the cable is not pinched or damaged.

# 5. Operation

The control buttons are located on the back of the unit, except for the backlight button which is on the top.

## 5.1 Display Readings

- The display will show the current indoor temperature, outdoor temperature, and indoor humidity.

## 5.2 Changing Temperature Units (C/F)

- Press the **C/F** button on the back of the unit to toggle between Celsius and Fahrenheit temperature displays.

## 5.3 Viewing Minimum/Maximum Readings (MIN/MAX)

- Press the **MIN/MAX** button on the back of the unit to cycle through current, minimum, and maximum recorded values for temperature and humidity.

## 5.4 Clearing Minimum/Maximum Readings (CLEAR)

- While viewing the MIN/MAX readings, press the **CLEAR** button on the back of the unit to reset the recorded minimum and maximum values.

## 5.5 Backlight

- Press the button located on the top of the unit to activate the backlight for a few seconds, improving visibility in dark environments.

# 6. MAINTENANCE

- **Cleaning:** To clean the unit, wipe it with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the plastic casing or display.
- **Battery Replacement:** Replace the AAA battery when the display becomes dim or stops functioning. Ensure proper polarity during installation.
- **Storage:** If storing the unit for an extended period, remove the battery to prevent leakage.

# 7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
| --- | --- | --- |
| No display or dim display | Low or dead battery; incorrect battery installation. | Replace the AAA battery, ensuring correct polarity. |
| Inaccurate temperature/humidity readings | Unit or sensor placed in direct sunlight, near heat/cold sources, or in drafts. | Relocate the unit and/or outdoor sensor to a more appropriate, stable environment. Ensure the outdoor sensor is in shade. |
| Outdoor temperature not displayed | Outdoor sensor cable is disconnected or damaged. | Check the connection of the outdoor sensor cable to the main unit. Inspect the cable for any visible damage. |

# 8. SPECIFICATIONS

- **Model:** #1523
- **Dimensions:** 6.5 x 5.9 x 1.8 inches (Item Package)
- **Weight:** 4 ounces (Package Weight)
- **Material:** Plastic
- **Power Source:** 1 x AAA Battery (not included)
- **UPC:** 077784015230
- **Care Instructions:** Wipe Clean

# 9. WARRANTY AND SUPPORT

Taylor provides a limited warranty for its products. For specific warranty details, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Taylor website. You may also contact Taylor customer service directly for assistance.

**Taylor Customer Service:** www.taylorusa.com/support