## Zeppelin LZ127 GRAF Automatic 7656

# Zeppelin Men's Watch LZ127 GRAF Automatic 7656 Instruction Manual

Model: LZ127 GRAF Automatic 7656

## Introduction

This manual provides essential instructions for the proper use, setup, and maintenance of your Zeppelin Men's Watch LZ127 GRAF Automatic 7656. This timepiece combines traditional craftsmanship with modern automatic movement technology, offering reliability and classic design.






**Figure 1:** Front view of the Zeppelin LZ127 GRAF Automatic 7656 watch. This image displays the watch face with its black dial, distinct copper-colored Arabic numerals, and the Zeppelin logo. The watch features a polished stainless steel case and a black leather strap with white stitching.

## Setup and Initial Operation

### 1. Winding the Watch

The Zeppelin LZ127 GRAF Automatic 7656 features a Citizen/Miyota 821A automatic movement. This movement is powered by the natural motion of your wrist. For initial startup or after the watch has stopped due to lack of wear, it is recommended to manually wind the watch:

1. Ensure the crown is in position 1 (fully pushed in).
2. Rotate the crown clockwise approximately 20-30 times. This will build up a power reserve to start the movement.
3. Wear the watch regularly. Continuous wrist movement will keep the watch wound. The power reserve is approximately 35 hours when fully wound.

### 2. Setting the Time and Date

To set the correct time and date:

1. **Setting the Date:** Gently pull the crown out to position 2. Rotate the crown counter-clockwise to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the automatic date change mechanism. Once the correct date is displayed, push the crown back to position 1.
2. **Setting the Time:** Pull the crown out further to position 3. Rotate the crown in either direction to move the hour and

minute hands. Advance the hands past 12 o'clock to ensure the date changes if you are setting the time for the next day. Once the correct time is set, push the crown back to position 1.




**Figure 2:** Angled view of the watch, highlighting the crown. The crown is used for manual winding, setting the date, and setting the time.

## Maintenance

### 1. Cleaning

To maintain the appearance of your watch:

- Wipe the case and crystal with a soft, dry cloth.
- For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.

- Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish.

### 2. Leather Strap Care

The watch features a high-quality leather strap. To prolong its life:

- **Avoid Water Exposure:** Remove the watch before showering, swimming, or engaging in activities where it might get wet. Water significantly reduces the lifespan of leather straps.
- **Cleaning:** If the strap becomes dirty, clean it with a damp cloth and a specialized leather cleaner. Allow it to air dry completely away from direct sunlight or heat.
- **Avoid Chemicals:** Do not expose the leather strap to perfumes, solvents, or other chemicals.

### 3. Water Resistance

This watch is water resistant up to 5 ATM (50 meters). This rating means it is suitable for everyday use and can withstand splashes or brief immersion in water. However, it is **not** suitable for showering, swimming, diving, or any water sports. Always ensure the crown is fully pushed in to maintain water resistance.

## Troubleshooting

### 1. Watch Has Stopped

If your automatic watch has stopped, it likely needs to be wound. Follow these steps:

- Manually wind the watch by rotating the crown clockwise 20-30 times while it is in position 1 (fully pushed in).
- Wear the watch for several hours to allow the automatic movement to build up its power reserve.
- If the watch still does not operate, contact customer support.

### 2. Inaccurate Timekeeping

Automatic movements are mechanical and may exhibit slight variations in timekeeping. A deviation of 10-40 seconds per day is considered normal for this type of movement. Factors such as wearing habits, temperature, and magnetic fields can influence accuracy.

- Ensure the watch is sufficiently wound by wearing it regularly or manually winding it.
- Avoid exposing the watch to strong magnetic fields (e.g., speakers, certain electronic devices).
- If the inaccuracy is significantly outside the normal range, professional servicing may be required.

## Specifications

| | |
|---|---|
| **Model Number** | LZ127 GRAF Zeppelin |
| **Movement** | Citizen/Miyota 821A Automatic (Japanese) |
| **Case Material** | Polished Stainless Steel |
| **Crystal** | Hardened K1 Safety Glass |
| **Case Diameter** | 40 mm |
| **Case Height** | 12 mm |
| **Water Resistance** | 5 ATM (50 meters) |

| | |
|---|---|
| **Strap Material** | Handmade Leather (Made in Germany) with Crocodile Embossing |
| **Features** | Date Display, Glass Case Back |
| **Manufacturer** | POINT tec Electronic GmbH, Ismaning |


ALL STAINLESS STEEL
WR
1656-2/02109/TP
AUTOMATIC
21 JEWELS
FINE GERMAN
WRISTWATCHES
ZEPPELIN

**Figure 3:** Rear view of the watch, featuring a transparent case back that reveals the Citizen/Miyota 821A automatic movement. Engravings around the case back indicate "ALL STAINLESS STEEL" and "WR 5 ATM".

## Warranty and Support

For warranty information, service, or support inquiries, please refer to the official documentation provided with your purchase or contact the manufacturer directly. The manufacturer of this timepiece is POINT tec Electronic GmbH, Ismaning.
It is recommended to keep your proof of purchase for any warranty claims.

© 2023 Zeppelin. All rights reserved.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question