Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beurer 637.92

Beurer FB50 Foot Spa User Manual

Model: FB50 (637.92)

Introduction

Thank you for choosing the Beurer FB50 Foot Spa. This device is designed to provide a relaxing and therapeutic foot bath experience with features such as water heating, vibration and bubble massage, infrared light, magnetic therapy, and interchangeable pedicure attachments. Please read this manual carefully before first use to ensure safe and proper operation.

Important Safety Information

For safe and effective use, please observe the following precautions:

- Ensure the massager is not immersed in water beyond the specified fill line.
- Do not use the foot spa with wet feet before placing them into the unit.
- If you have a medical condition, a pacemaker, or are pregnant, consult your doctor before using this massager.
- Always unplug the device from the power outlet after use and before cleaning.
- Keep the device out of reach of children.
- Do not use the device if it or its power cord is damaged.

Package Contents

Upon unpacking, please verify that all items are present and undamaged:

- 1 x Beurer FB50 Relax Foot Bath
- 3 x Changeable Pedicure Attachments
- 1 x Instruction Manual (this document)

Setup

1. Place the foot spa on a firm, level surface.
2. Fill the foot spa with warm or cold water up to the indicated maximum fill line. Do not overfill.
3. Plug the power cord into a suitable electrical outlet.

4. Ensure your feet are clean before placing them into the foot spa.



Image: The Beurer FB50 Foot Spa, showing its main unit with rollers and control panel, ready for use.

Operating Instructions

The Beurer FB50 offers multiple functions for a personalized foot spa experience. All functions are controlled via the intuitive LED display.

Basic Operation

1. Press the **ON/OFF** button to power on the device. The LED display will illuminate.
2. Place your feet comfortably into the foot spa.



Image: A detailed view of the Beurer FB50's digital control panel, showing the temperature display and function buttons.

Water Heating and Temperature Control

The foot spa features a 5-level water heater to maintain your desired water temperature between 35°C and 48°C.

- Press the **Temperature** button (thermometer icon) to cycle through the available temperature settings.
- The current temperature will be displayed on the LED screen.
- The heating function will automatically activate to reach and maintain the selected temperature.



Image: A woman relaxing, with an overlay indicating the 5-level water heating feature (35-48°C) of the Beurer FB50 foot spa.

Vibration and Bubble Massage

Enjoy a soothing massage with the integrated vibration and bubble functions.

- Press the **Vibration** button (wavy lines icon) to activate the vibration massage.
- Press the **Bubble** button (bubbles icon) to activate the bubble massage.
- Both functions can be used simultaneously for an enhanced experience.



Image: The Beurer FB50 foot spa, illustrating the bubble and vibration massage functions with a person's feet in the spa.

Infrared Light and Magnetic Therapy

The foot spa includes integrated infrared light spots and magnetic therapy points for additional relaxation and well-being.

- The infrared light function is typically activated automatically when the device is on. Refer to the display for specific indicators.
- Magnetic therapy points are integrated into the base of the foot spa.

Reflexology Rollers

The removable reflexology rollers provide a deeper massage for the soles of your feet, targeting reflex zones.

- To use, gently move your feet back and forth over the rollers.
- The rollers can be removed if a less intense massage is desired.



Image: An annotated diagram of the Beurer FB50, pointing out features such as removable rolling massagers, infrared light spots, and the digital timer/temperature setting.

Pedicure Attachments

The Beurer FB50 includes three interchangeable pedicure attachments for comprehensive foot care:

- **Corn and Callus Remover:** Designed to gently remove dead skin.
- **Brush Attachment:** Stimulates reflex zones and cleanses the skin.
- **Massage Attachment:** Provides a targeted massage for specific areas of your feet.

To use, simply attach the desired accessory to the central rotating spindle. Apply gentle pressure with your foot to activate the rotation.



Image: A visual representation of the three interchangeable pedicure attachments: a pink corn and callus remover, a black brush attachment, and a grey massage attachment, with descriptions of their functions.

Maintenance and Cleaning

Regular cleaning ensures the longevity and hygienic operation of your foot spa.

1. Always unplug the device before cleaning.
2. Empty the water from the foot spa after each use.
3. Clean the unit with a damp cloth and a mild detergent. Do not use abrasive cleaners.
4. Rinse the interior thoroughly with clean water.
5. Allow the foot spa to air dry completely before storing.
6. Store the device in a cool, dry place, away from direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device does not turn on.	Not plugged in; Power outlet fault; Device fault.	Ensure power cord is securely plugged in. Test with another outlet. If problem persists, contact customer support.
Water is not heating.	Heating function not activated; Temperature setting too low; Device fault.	Press the Temperature button to activate heating. Increase temperature setting. If problem persists, contact customer support.
Vibration/Bubble function not working.	Function not activated; Water level too low/high; Device fault.	Press the respective function button. Ensure water level is within recommended range. If problem persists, contact customer support.
Pedicure attachment not rotating.	Insufficient pressure; Attachment not properly seated; Device fault.	Apply gentle pressure to the attachment with your foot. Ensure the attachment is securely placed on the spindle. If problem persists, contact customer support.

Specifications

Model: FB50 (637.92)

Brand: Beurer

Product Dimensions: 47L x 40W x 24H centimetres

Item Weight: 3.93 Kilograms

Material: Plastic, Rubber

Power Source: Corded Electric

Water Heating: 5-level, 35-48°C

Features: Vibration massage, Bubble massage, Infrared light, Magnetic therapy, Reflexology rollers, 3 interchangeable pedicure attachments.

Suitable for shoe size: Up to 51/52 (UK)

Country of Origin: China

Warranty and Support

The Beurer FB50 Foot Spa comes with a**3-year guarantee** from the date of purchase. Please retain your proof of purchase for warranty claims.
For technical support, warranty service, or general inquiries, please contact Beurer customer service through their official website or the contact information provided with your product packaging.
For more information about Beurer products, visit the official Beurer Store:Beurer Store on Amazon.

© 2024 Beurer GmbH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00336I460

More documents and user manuals: **https://manuals.plus/**