Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fujifilm FinePix S1600

Fujifilm FinePix S1600 Digital Camera User Manual

Your comprehensive guide to operating and maintaining your camera.

1. Introduction

Welcome to the user manual for your Fujifilm FinePix S1600 digital camera. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your camera to ensure you get the best possible experience. The FinePix S1600 is designed for high-resolution photo and video shooting, featuring dual image stabilization and intelligent scene recognition for excellent results in various conditions.

Please read this manual thoroughly before using your camera and keep it in a safe place for future reference.

2. What's in the Box

Before you begin, please ensure all the following items are included in your package:

- Fujifilm FinePix S1600 Digital Camera
- 4 AA Alkaline Batteries
- Shoulder Strap
- Lens Cap
- USB Cable
- AV Cable
- CD-ROM (containing software and full manual)
- Quick Start Guide

3. Setup

3.1. Installing Batteries

1. Open the battery compartment cover located on the bottom of the camera.
2. Insert four AA alkaline batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
3. Close the battery compartment cover securely.

3.2. Inserting a Memory Card

The FinePix S1600 uses SD/SDHC memory cards (not included). A memory card is required to save photos and videos.

1. Open the memory card slot cover, usually located near the battery compartment.
2. Insert the SD/SDHC card with the label facing the front of the camera until it clicks into place.
3. Close the memory card slot cover securely.

3.3. Attaching the Shoulder Strap

Attach the provided shoulder strap to the camera's strap lugs to prevent accidental drops.

3.4. Initial Power On and Date/Time Setting

1. Press the power button to turn on the camera.
2. If prompted, follow the on-screen instructions to set the date, time, and language. Use the directional buttons and the MENU/OK button to navigate and confirm.

4. Operating Your Camera

4.1. Camera Controls Overview



Figure 1: Front view of the Fujifilm FinePix S1600, showing the lens, flash, and grip.



Figure 2: Rear view of the Fujifilm FinePix S1600, displaying the LCD screen, electronic viewfinder, and control buttons.

Familiarize yourself with the main controls:

- **Power Button:** Turns the camera on/off.
- **Shutter Button:** Press halfway to focus, fully to take a picture.
- **Zoom Lever:** Controls the 15x optical zoom.
- **Mode Dial:** Selects shooting modes (e.g., Auto, Program, Manual, Scene Position).
- **MENU/OK Button:** Accesses menus and confirms selections.
- **Directional Buttons:** Navigates menus and adjusts settings.
- **Playback Button:** Switches to playback mode to view photos/videos.
- **Display/Back Button:** Changes display information or returns to the previous screen.

4.2. Basic Photography

1. **Turn On:** Press the power button.
2. **Select Mode:** Rotate the mode dial to your desired shooting mode (e.g., **AUTO** for automatic settings).
3. **Frame Your Shot:** Use the LCD monitor or electronic viewfinder to compose your image.
4. **Zoom:** Use the zoom lever to adjust the focal length.
5. **Focus:** Press the shutter button halfway down. The camera will focus, and the focus indicator will light up.
6. **Shoot:** Press the shutter button fully to take the picture.

4.3. Video Recording

The FinePix S1600 can record videos at 1280 x 720 resolution.

1. Rotate the mode dial to the video recording mode (indicated by a movie camera icon).
2. Press the shutter button to start recording.

3. Press the shutter button again to stop recording.

4.4. Playback

To view your captured photos and videos:

1. Press the playback button (usually indicated by a play icon).
2. Use the directional buttons to scroll through your images and videos.
3. Press the MENU/OK button to view options for the selected item (e.g., delete, rotate).
4. Press the playback button again or the shutter button to return to shooting mode.

4.5. Special Features

- **Dual IS Mode:** This mechanical image stabilization system helps reduce blur caused by camera shake, especially in low light or with long zoom.
- **Panorama Mode:** Allows you to stitch multiple photos together to create a wide panoramic image.
- **Scene Recognition:** Automatically detects the type of scene you are shooting and optimizes camera settings for the best results.

5. Maintenance

5.1. Cleaning the Camera

- **Camera Body:** Wipe gently with a soft, dry cloth. For stubborn dirt, use a cloth lightly dampened with water, then wipe dry.
- **Lens:** Use a lens brush to remove dust, then gently wipe with a lens cleaning cloth. Avoid touching the lens surface with your fingers.
- **LCD Monitor:** Use a soft, dry cloth. Avoid pressing hard on the screen.

5.2. Battery Care

- Remove batteries when the camera will not be used for an extended period.
- Store batteries in a cool, dry place.
- Do not mix old and new batteries, or different types of batteries.

5.3. Storage

When storing the camera, ensure it is turned off, the lens cap is on, and it is placed in a protective case or bag to prevent dust and scratches.

6. Troubleshooting

If you encounter issues with your FinePix S1600, refer to the common problems and solutions below:

- **Camera does not turn on:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace with fresh batteries.
- **Images are blurry:**
  - Ensure the lens is clean.
  - Check if the camera is properly focused (press shutter halfway).

- Use Dual IS Mode to minimize camera shake.
- Increase shutter speed or use flash in low light conditions.

- **Memory card error:**
  - Ensure the memory card is inserted correctly.
  - Try formatting the memory card (this will erase all data).
  - Try a different, compatible memory card.

- **Flash does not fire:**
  - Check flash settings; ensure it's not set to "Flash Off" or "Red-eye Reduction" in bright conditions.
  - Allow time for the flash to recharge.

For more detailed troubleshooting, refer to the full manual on the included CD-ROM or visit the Fujifilm support website.

7. Specifications

Feature	Specification
Model Name	FinePix S1600
Image Sensor	1/2.3-inch CCD with 12.2 Megapixels effective resolution
Lens	Fujinon 15x Optical Zoom (28-420mm equivalent), f/5.6 maximum aperture
Digital Zoom	Approx. 6.3x
Image Stabilization	Optical (Dual IS Mode)
LCD Monitor	3.0-inch (7.6 cm) TFT color LCD, approx. 230,000 dots
Viewfinder	Electronic Viewfinder
Storage Media	SD/SDHC memory card
File Formats	Still images: JPEG (Exif Ver 2.2); Video: MOV/AVI
Video Recording Resolution	1280 x 720 pixels
Sensitivity	Auto, ISO 64/100/200/400/800/1600/3200/6400 (Standard Output Sensitivity)
Shutter Speed	1/4 sec. to 1/2000 sec. (Auto mode), 8 sec. to 1/2000 sec. (other modes)
Power Supply	4 AA alkaline batteries (included) or 4 AA Ni-MH rechargeable batteries (sold separately)
Connectivity	USB 2.0 High-Speed, AV output
Dimensions (W x H x D)	Approx. 110.2 x 73.4 x 81.4 mm (4.3 x 2.9 x 3.2 in.)
Weight	Approx. 337g (excluding batteries and memory card)

8. Warranty and Support

Your Fujifilm FinePix S1600 camera is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the warranty period and coverage details.

For technical support, service, or additional information, please visit the official Fujifilm website or contact their customer service department in your region. Contact details can typically be found on the Fujifilm website or in the documentation provided with your camera.

Please retain your proof of purchase for warranty claims.

© 2023 Fujifilm Corporation. All rights reserved.
Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00342UTPC

More documents and user manuals: **https://manuals.plus/**