Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coby DP1052

Coby DP1052 10.4-Inch Digital Photo Frame User Manual

Model: DP1052

1. Introduction

The Coby DP1052 is a versatile 10.4-inch digital photo frame designed to display your digital photos, play music, and video files. It features a classic wooden frame design and a vibrant LCD screen. This manual provides detailed instructions for setting up, operating, and maintaining your digital photo frame.

2. Package Contents

Please check the package for the following items:

- Coby DP1052 10.4-Inch Digital Photo Frame
- AC Power Adapter
- Remote Control (with battery)
- User Manual (this document)

3. Product Overview

Familiarize yourself with the components of your Coby DP1052 digital photo frame.



Image 3.1: Front view of the Coby DP1052 Digital Photo Frame, showcasing its 10.4-inch screen and classic wooden frame.

3.1 Front Panel

- **10.4-Inch TFT LCD Screen:** Displays photos, videos, and menu options.
- **Wooden Frame:** Decorative housing for the display.

3.2 Rear Panel / Side Panel

- **Power Input:** Connects to the AC power adapter.
- **Memory Card Slots:** Supports SD, MMC, MS, xD, and CF cards. *Note: Does not support SDHC flash drive cards.*
- **USB Port:** For connecting USB flash memory drives.
- **Control Buttons:** Basic navigation and menu access buttons (typically on the back or side).
- **Speakers:** For audio playback.

3.3 Remote Control

The included remote control provides convenient access to all functions and settings. It is the primary method for

navigating menus and controlling playback.

4. Setup

Follow these steps to set up your digital photo frame:

1. **Connect Power:** Plug the AC power adapter into the DC IN port on the frame, then plug the adapter into a standard electrical outlet. The frame should power on automatically or enter standby mode.
2. **Insert Media:** Insert a compatible memory card (SD, MMC, MS, xD, CF) into the appropriate slot, or connect a USB flash drive to the USB port. Ensure the media contains supported photo, music, or video files.
3. **Power On:** If the frame is in standby, press the Power button on the frame or the remote control to turn it on.
4. **Initial Settings:** Upon first use, you may be prompted to set the language, date, and time. Use the remote control to navigate and confirm selections.

5. Operating Instructions

The Coby DP1052 offers various modes for enjoying your digital content.

5.1 Basic Navigation

- Use the directional buttons (Up, Down, Left, Right) on the remote to navigate through menus.
- Press the **OK**/**Enter** button to confirm a selection.
- Press the **Menu**/**Exit** button to return to the previous menu or exit the current function.

5.2 Photo Playback

The frame supports JPEG photo files.

1. From the main menu, select the 'Photo' option.
2. Choose your desired memory source (e.g., SD card, USB).
3. Select a photo or folder to begin a slideshow.
4. **Slideshow Mode:** The frame will automatically cycle through photos. You can customize slideshow intervals and transition effects in the settings menu.
5. **Photo with Music:** You can set a background music track to play during your photo slideshow. Access this option in the photo settings.

5.3 Music Playback

The frame plays MP3 and WMA music files.

1. From the main menu, select the 'Music' option.
2. Choose your desired memory source.
3. Select a music file or folder to start playback.
4. Use the remote control for Play/Pause, Skip, and Volume adjustments.

5.4 Video Playback

The frame supports MPEG-4, H.264, and Motion JPEG video files.

1. From the main menu, select the 'Video' option.

2. Choose your desired memory source.
3. Select a video file to begin playback.
4. Use the remote control for Play/Pause, Fast Forward, Rewind, and Volume adjustments.

5.5 Calendar and Clock

The frame includes a calendar and clock function with an alarm timer.

- Access the 'Calendar' option from the main menu.
- You can display the calendar with a large image alongside it.
- Set the current date and time in the system settings.
- Configure alarm timers as needed.

5.6 System Settings

Access the 'Settings' menu to customize various aspects of your frame:

- **Display Settings:** Adjust brightness, contrast, and display mode.
- **Slideshow Settings:** Configure transition effects, display time per photo, and background music.
- **Date & Time:** Set the current date, time, and alarm.
- **Language:** Select your preferred language.
- **Auto On/Off:** Schedule specific times for the frame to power on and off automatically.

6. Media Compatibility

The Coby DP1052 supports a range of digital media formats and storage devices:

- **Photo Files:** JPEG
- **Music Files:** MP3, WMA
- **Video Files:** MPEG-4, H.264, Motion JPEG
- **Memory Cards:** SD (Secure Digital), MMC (MultiMediaCard), MS (Memory Stick), xD (xD-Picture Card), CF (CompactFlash). **Important: SDHC (Secure Digital High Capacity) cards are NOT supported.**
- **USB Flash Drives:** Full-size USB port for use with compatible flash memory drives.

7. Maintenance

Proper care ensures the longevity of your digital photo frame.

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a non-abrasive screen cleaner. Avoid harsh chemicals.
- **Cleaning the Frame:** Use a soft, dry cloth to wipe the wooden frame.
- **Storage:** When not in use for extended periods, store the frame in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Power:** Always disconnect the power adapter before cleaning or moving the frame.

8. Troubleshooting

If you encounter issues with your Coby DP1052, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Frame does not power on.	Power adapter not connected or faulty.	Ensure the power adapter is securely connected to the frame and a working electrical outlet. Try a different outlet.
No image or sound.	No media inserted, unsupported file format, or media error.	Insert a compatible memory card or USB drive with supported files. Verify file formats (JPEG, MP3, WMA, MPEG-4, H.264, Motion JPEG). Try a different memory card/USB drive.
Memory card/USB drive not recognized.	Incompatible card type (e.g., SDHC), improper insertion, or corrupted media.	Ensure the card is fully inserted and is not an SDHC type. Try reinserting or using a different card/drive. Check if the media works on a computer.
Remote control not working.	Battery depleted or obstructed signal.	Replace the remote control battery. Ensure there are no obstructions between the remote and the frame's IR receiver.
Poor video/audio quality from SD card.	Data transfer rate limitations of the SD card.	Try playing the same file from a USB flash drive, which may offer better performance. Ensure the video file is not excessively large or high bitrate for the frame's capabilities.

9. Specifications

Detailed technical specifications for the Coby DP1052 Digital Photo Frame:

Feature	Detail
Brand	Coby
Model Number	DP1052
Display Size	10.4 Inches
Resolution	800 x 600 pixels
Colour	Brown (Wooden Frame)
Supported Photo Formats	JPEG
Supported Music Formats	MP3, WMA
Supported Video Formats	MPEG-4, H.264, Motion JPEG
Compatible Memory Cards	SD, MMC, MS, xD, CF (Does not support SDHC)
Connectivity Technology	Wired (USB port for flash drives)
Control Method	Remote Control, Touchscreen (basic input)

Feature	Detail
Power Source	AC Power Adapter
Product Dimensions (L x W)	25.7L x 31W centimetres
Item Weight	3.06 kg

10. Warranty and Support

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact Coby customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

© 2023 Coby. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0036MDUO2

More documents and user manuals: **https://manuals.plus/**