Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Brother WT300CL

Brother WT300CL Waste Toner Box Instruction Manual

Model: WT300CL

1. Introduction

This instruction manual provides essential information for the proper handling, installation, and maintenance of your Brother WT300CL Waste Toner Box. The waste toner box is a crucial component designed to collect excess toner during the printing process, ensuring clean and consistent print quality.

The Brother WT300CL Waste Toner Box has an approximate yield of 50,000 pages (A4 or letter size, single-sided). It is compatible with the following Brother printer models:

- HL-4150CDN
- HL-4570CDW
- HL-4570CDWT
- MFC-9460CDN
- MFC-9560CDW
- MFC-9970CDW



Figure 1: The Brother WT300CL Waste Toner Box unit. This component collects excess toner during printing.

2. Safety Information

Please read and follow these safety guidelines to prevent injury or damage to your printer and the waste toner box:

- **Do not** open the waste toner box. Toner powder can be harmful if inhaled or ingested.
- Keep the waste toner box out of reach of children.
- If toner powder spills, wipe it immediately with a dry cloth. Avoid using water, as it can fix the toner to surfaces.
- **Always** turn off and unplug your printer before installing or removing the waste toner box.
- Handle the waste toner box carefully to avoid dropping it, which could cause toner leakage.

3. Installation and Replacement

Replace the waste toner box when your printer displays a message indicating it is full or needs replacement. Follow these steps:

1. **Power Off Printer:** Turn off the printer and unplug it from the power outlet to prevent electrical hazards.
2. **Open Front Cover:** Open the front cover of your Brother laser printer.
3. **Remove Old Waste Toner Box:** Carefully pull out the used waste toner box from the printer. Place it in a plastic bag to prevent toner leakage and prepare for proper disposal.



Figure 2: The Brother WT300CL Waste Toner Box, ready for installation.

4. **Unpack New Waste Toner Box:** Remove the new Brother WT300CL Waste Toner Box from its packaging. Do not touch the green roller or electrical contacts.



Figure 3: Retail packaging of the Brother WT300CL Waste Toner Box.

5. **Insert New Waste Toner Box:** Slide the new waste toner box firmly into the printer until it clicks into place. Ensure it is seated correctly.
6. **Close Front Cover:** Close the front cover of the printer.
7. **Power On Printer:** Plug the printer back in and turn it on. The printer should recognize the new waste toner box and clear any related error messages.

4. Operation

The Brother WT300CL Waste Toner Box operates automatically once installed. It collects excess toner that is not transferred to the paper during the printing process. No user intervention is required during normal operation.

5. Maintenance

The only maintenance required for the waste toner box is its replacement when indicated by your printer. Do not attempt to empty or clean the waste toner box, as this can lead to toner spills and potential damage to the printer or health hazards.

6. Troubleshooting

- **"Waste Toner Box Full" message persists after replacement:**Ensure the new waste toner box is correctly installed and fully seated. Close the front cover firmly. If the message persists, turn the printer off, wait a few minutes, and then turn it back on.
- **Toner leakage:** If you observe toner leakage, immediately turn off the printer and unplug it. Carefully remove the waste toner box and place it in a sealed bag. Clean any spilled toner with a dry cloth. Do not use a vacuum cleaner not specifically designed for toner, as this can spread toner particles and damage the vacuum.
- **Poor print quality after replacement:** While unlikely to be directly caused by the waste toner box, ensure all other consumables (toner cartridges, drum unit) are correctly installed and not near end-of-life. Refer to your printer's main manual for print quality troubleshooting.

7. Specifications

Feature	Specification
Model Number	WT300CL
Product Type	Waste Toner Box
Approximate Page Yield	50,000 pages (A4 or letter size, single-sided)
Compatible Printer Models	HL-4150CDN, HL-4570CDW, HL-4570CDWT, MFC-9460CDN, MFC-9560CDW, MFC-9970CDW
Product Dimensions (L x W x H)	14.96 x 12.6 x 5.12 inches
Item Weight	2.01 pounds
Manufacturer	Brother

8. Recycling and Disposal

The used Brother WT300CL Waste Toner Box contains residual toner and should be disposed of responsibly. Brother offers recycling programs for their consumables. Please visit the official Brother website or contact your local recycling facility for information on proper disposal methods in your area.
Do not dispose of the waste toner box in regular household waste.

9. Customer Support

For further assistance, technical support, or warranty information regarding your Brother WT300CL Waste Toner Box or compatible printer, please visit the official Brother support website or contact their customer service department.
Official Brother Website: www.brother-usa.com/support

© 2023 Brother International Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0041H9YQ4

More documents and user manuals: **https://manuals.plus/**