Archos 501562

Archos 28 Internet Tablet User Manual

Model: 501562

Introduction

The Archos 28 Internet Tablet is a compact, Wi-Fi enabled device designed for multimedia playback, internet browsing, and application use. Featuring a 2.8-inch touchscreen and running on the Android platform, it offers a portable solution for digital entertainment and connectivity.



Image: The Archos 28 Internet Tablet, showcasing its compact design and user interface.

What's in the Box

Verify that all items are present in the packaging:

- Archos 28 Internet Tablet
- Earphones
- Standard USB Cable
- Quick Start Guide
- Legal and Safety Notice

Setup

Initial Charging

Before first use, connect the Archos 28 to a power source using the provided USB cable and a compatible USB power adapter (not always included) or a computer's USB port. Allow the device to charge fully.

Powering On/Off

- To power on: Press and hold the power button until the Archos logo appears.
- To power off: Press and hold the power button, then select 'Power off' from the options on the screen.

Wi-Fi Connection

The Archos 28 is Wi-Fi enabled. To connect to a wireless network:

1. Go to the Settings menu.
2. Select 'Wireless & networks'.
3. Turn on Wi-Fi.
4. Select your desired network from the list and enter the password if prompted.

Operating Instructions

User Interface

The device operates on the Android platform, featuring five customizable home screens. Icons can be arranged, moved, or removed by touch. The device includes an accelerometer for screen orientation and a graphical accelerator (3D OpenGL ES 2.0) for enhanced visual effects and 3D applications.

Touchscreen Navigation

The 2.8-inch QVGA (320 x 240 pixel) touchscreen allows for navigation and interaction with applications. Use finger gestures such as tapping, swiping, and pinching (if supported by the application) to control the device.

Multimedia Playback

The Archos 28 supports various multimedia formats:

- **Music:** Utilize the dedicated music application with features like 3D cover animation and a mini music widget. Supported audio formats include MP3 (CBR & VBR), WMA, WMA-Pro 5.1, WAV (PCM/ADPCM), AAC, AAC+ 5.13, OGG Vorbis, FLAC, and AC3 5.1.
- **Video:** The video player supports MPEG-4, H.264, WMV/VC1, Motion JPEG, and MPEG 2 codecs with AVI, MP4, MOV, 3GP, MPG, PS, TS, VOB, MKV, FLV, RM, RMVB, ASF, and WMV extensions.
- **Photos:** View images using the Gallery application. Supported image formats include JPEG, BMP, PNG, and GIF.

Internet Browsing and Email

Access the internet using the built-in web browser and manage emails with the pre-installed email application. A Wi-Fi connection is required for these functions.

Applications

Download additional applications from the AppsLib store. This marketplace offers a variety of apps, including games, online music players, and communication tools, to enhance device functionality.

Maintenance

Firmware and OS Updates

The Archos 28 is designed to automatically download the latest firmware and operating system updates when connected to Wi-Fi. Ensure your device is connected to a stable Wi-Fi network to receive these updates, which provide performance improvements and new features.

Cleaning

To clean the device, use a soft, lint-free cloth. Avoid using abrasive cleaners or solvents, which can damage the screen or casing.

Troubleshooting

If you encounter issues with your Archos 28, consider the following:

- **Device Unresponsive:** If the device freezes, press and hold the power button for approximately 10 seconds to force a restart.
- **Wi-Fi Connectivity Issues:** Ensure Wi-Fi is enabled and you are within range of a known network. Verify the network password. Restarting the device or the Wi-Fi router may resolve connection problems.
- **Application Performance:** Close unused applications to free up system resources. If an app is consistently crashing, try uninstalling and reinstalling it.
- **Battery Life:** Reduce screen brightness, disable Wi-Fi when not in use, and close background applications to conserve battery power.

Specifications

Feature	Detail
Brand	Archos
Model Name	Touch
Model Number	501562
Memory Storage Capacity	4 GB
Screen Size	2.8 Inches
Display Resolution Maximum	320 x 240 (QVGA)
Processor Speed	0.8 GHz
Operating System	Android (version may vary with updates)
Connectivity Technology	Wi-Fi (802.11b, 802.11g, 802.11n)
Hardware Interface	USB
Battery Average Life (Audio)	16 hours

Feature	Detail
Battery Average Life (Video)	4 hours
Battery Average Life (Web Browsing)	6 hours
Item Weight	2.4 ounces
Human-Interface Input	Touchscreen
Color	Black
UPC	690590515628

Warranty and Support

Warranty Information

The Archos 28 Internet Tablet comes with a one-year limited warranty. Please refer to the Legal and Safety Notice included in your product packaging for full details regarding warranty terms and conditions.

Customer Support

For technical assistance, troubleshooting, or warranty claims, please visit the official Archos support website or contact their customer service department. Contact information can typically be found in the Quick Start Guide or on the manufacturer's website.

© 2026 Archos. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question