RIDGID 45765

RIDGID 45765 Crank, Feed Screw 820 Instruction Manual

Model: 45765

1. Introduction

This manual provides essential information for the proper use, installation, and maintenance of the RIDGID 45765 Crank, Feed Screw 820. This component is designed for use within pneumatic systems, specifically as a part of pneumatic fasteners and accessories. Adherence to these instructions will ensure optimal performance and longevity of the product.

2. Product Overview

The RIDGID 45765 is a specialized crank and feed screw assembly, integral to the operation of certain pneumatic tools. It facilitates the controlled advancement or retraction of a mechanism, crucial for precision and efficiency in its intended application.




Figure 1: An illustration of the RIDGID 45765 Crank, Feed Screw 820, showing its elongated body with a central rotating mechanism and rounded ends for grip or attachment.

3. Setup and Installation

Installation of the 45765 Crank, Feed Screw 820 should be performed by qualified personnel following the specific instructions provided with the pneumatic tool it is intended for. Ensure the tool is disconnected from its power source before beginning any installation or replacement procedures.

1. Identify the correct mounting location for the crank and feed screw assembly on your pneumatic equipment.
2. Carefully align the feed screw with its corresponding threaded receiver.

3. Secure the crank mechanism according to the tool's specific assembly instructions, ensuring all fasteners are tightened to the manufacturer's specifications.
4. Verify that the crank rotates freely and engages the feed screw mechanism without obstruction.

4. Operating Instructions

The 45765 Crank, Feed Screw 820 is operated manually to control the movement of a component within the pneumatic system. Its function is typically to adjust depth, position, or tension.

- Grasp the crank handle firmly.
- Rotate the crank clockwise to advance the feed screw, or counter-clockwise to retract it, as required by the specific application.
- Apply steady, controlled force. Avoid excessive force, which can damage the feed screw or the associated mechanism.
- Refer to your pneumatic tool's primary instruction manual for specific operational parameters and safety guidelines related to the feed screw adjustment.

5. Maintenance

Regular maintenance ensures the smooth operation and extends the lifespan of the 45765 Crank, Feed Screw 820.

- **Cleaning:** Periodically clean the crank and feed screw threads to remove debris, dust, and grime that may impede smooth operation. Use a soft cloth and a suitable cleaning agent that will not damage the material.
- **Lubrication:** Apply a thin layer of appropriate lubricant to the feed screw threads as recommended by the pneumatic tool's manufacturer to reduce friction and wear.
- **Inspection:** Regularly inspect the crank and feed screw for signs of wear, damage, or deformation. Pay close attention to the threads and the connection points. Replace the component if any significant damage is observed.

6. Troubleshooting

This section addresses common issues that may arise during the use of the 45765 Crank, Feed Screw 820.

- **Crank is stiff or difficult to turn:**
  - Check for debris or foreign objects obstructing the feed screw threads. Clean thoroughly.
  - Apply lubricant to the feed screw threads.
  - Inspect for damage or bending of the feed screw or crank mechanism.
- **Crank does not engage or move the mechanism:**
  - Ensure the crank is properly installed and secured to the pneumatic tool.
  - Inspect the threads of both the feed screw and its mating part for stripping or excessive wear.

If issues persist after attempting these troubleshooting steps, contact RIDGID customer support or a qualified service technician.

7. Specifications

Feature	Detail
Model Number	45765
Product Name	Crank, Feed Screw 820
Brand	RIDGID
Item Weight	14.4 ounces
Product Dimensions	7.5 x 1.25 x 1.25 inches
Manufacturer	StandardPlumbing: Kohler
Application	Pneumatics, Pneumatic Fasteners & Accessories
Country of Manufacture	United States

8. Warranty and Support

For information regarding the warranty of your RIDGID 45765 Crank, Feed Screw 820, please refer to the warranty documentation provided with your original pneumatic tool or visit the official RIDGID website. For technical support, replacement parts, or service inquiries, please contact RIDGID customer service directly.
RIDGID Official Website: www.ridgid.com