Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Warner Home Video WHV1000167766DVD

Warner Home Video Presents: 10 (DVD) Instruction Manual

Model: WHV1000167766DVD

Introduction

This manual provides essential information for the proper use and care of your "10" DVD. Directed by Blake Edwards and starring Dudley Moore, Julie Andrews, and Bo Derek, this romantic comedy offers an engaging viewing experience. Please read these instructions carefully to ensure optimal enjoyment and longevity of your product.



Figure 1: Front cover of the "10" DVD. The primary visual is a woman, Bo Derek, running on a sandy beach. Above her are the names 'DUDLEY MOORE JULIE ANDREWS BO DEREK'. Below these names, the title 'BLAKE EDWARDS' '10" is prominently displayed. A smaller inset image shows a smiling man, Dudley Moore. Text at the bottom left reads 'A temptingly tasteful comedy for adults who can count.' A portion of the silver DVD disc is visible on the right side, extending beyond the case.

Setup

To play your "10" DVD, you will need a compatible DVD player and a television or display device. Ensure all components are connected correctly according to their respective manufacturer's instructions.

1. **Connect your DVD player:** Use appropriate cables (e.g., HDMI, RCA) to connect your DVD player to your television or display.
2. **Power on devices:** Turn on your television and DVD player.
3. **Select input:** Switch your television's input source to the corresponding input where your DVD player is connected.

Operating Instructions

Follow these steps to play the DVD and access its features:

1. **Insert the DVD:** Gently place the "10" DVD into the disc tray of your DVD player with the label side facing up. Close the tray.
2. **Start playback:** The DVD should begin playing automatically or display a main menu. If a menu appears, use your DVD player's remote control to navigate and select "Play Movie."
3. **Language and Subtitles:** From the main menu or during playback (using your remote's "Audio" or "Subtitle" button), you can select audio languages (English Mono) and subtitle options (English, French, Spanish).
4. **Bonus Content:** This DVD includes "Full Screen Version: Side A" as bonus content. Access this feature through the main menu if available, or by flipping the disc if it is a double-sided DVD.
5. **Pause, Fast Forward, Rewind:** Use the standard controls on your DVD player's remote for playback manipulation.

Maintenance and Care

Proper care will extend the life of your DVD and ensure consistent playback quality.

- **Handling:** Always hold the DVD by its edges or by placing a finger through the center hole. Avoid touching the shiny playback surface.
- **Cleaning:** If the disc becomes dirty, gently wipe it with a soft, lint-free cloth from the center outwards. Do not use abrasive cleaners or solvents.
- **Storage:** Store the DVD in its original case, away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Scratches:** Do not bend the disc or place heavy objects on it. Scratches can impair playback.

Troubleshooting

If you encounter issues, try the following solutions:

- **Disc not playing:**
  - Ensure the disc is inserted correctly (label side up).
  - Check if the disc is clean and free of scratches.
  - Verify your DVD player is powered on and connected to the correct TV input.
  - Try playing another DVD to confirm the player is functioning.
- **No audio or video:**
  - Check all cable connections between the DVD player and TV.
  - Ensure the TV's volume is up and not muted.
  - Confirm the correct input source is selected on your TV.
- **Skipping or freezing:**

- Clean the disc carefully as described in the Maintenance section.
- Ensure the disc is not warped or severely damaged.

Specifications

Title	10
Brand	Warner Home Video
Model Number	WHV1000167766DVD
ASIN	B0045HCIYU
Format	DVD, NTSC, Subtitled
Run Time	2 hours and 1 minute
Release Date	November 9, 2010
Director	Blake Edwards
Actors	Bo Derek, Dee Wallace, Dudley Moore, Julie Andrews, Robert Webber
Subtitles	English, French, Spanish
Audio Language	English (Mono)
MPAA Rating	R (Restricted)
Number of Discs	1
Product Dimensions	0.7 x 7.5 x 5.4 inches; 0.01 ounces

Warranty and Support

This DVD is manufactured to high-quality standards. In the unlikely event of a manufacturing defect, please contact the retailer from whom you purchased the product for assistance. For general inquiries regarding Warner Home Video products, please refer to their official support channels.
Note: Damage due to improper handling or storage is not covered.

© 2026 Warner Home Video. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0045HCIYU

More documents and user manuals: **https://manuals.plus/**