Kitchen Selectives SK-6

Kitchen Selectives SK-6 6-inch Electric Skillet Instruction Manual

Model: SK-6

Introduction

Thank you for purchasing the Kitchen Selectives 6-inch Electric Skillet. This compact appliance is designed for individual servings and quick meals, offering convenience and versatility. Please read this manual thoroughly before use to ensure safe and efficient operation.

Key Features:

- Compact 6-inch cooking surface, ideal for small portions.
- Adjustable temperature control for precise cooking.
- Non-stick cooking surface for easy food release and cleaning.
- Removable locking handle for convenient storage and cleaning.
- Tempered glass lid with a cool-touch knob for safe monitoring of cooking progress.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

1. Read all instructions before operating the appliance.
2. Do not touch hot surfaces. Use handles or knobs. Always use oven mitts or pot holders when handling hot materials.
3. To protect against electrical shock, do not immerse the temperature control probe, cord, or plug in water or other liquids.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has

been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.

7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
12. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'OFF', then remove plug from wall outlet.
13. Do not use appliance for other than intended household use.
14. A short power-supply cord is provided to reduce the risks resulting from entanglement or tripping over a longer cord. Extension cords may be used if care is exercised in their use. If an extension cord is used, the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance. The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over.

Product Components

Your Kitchen Selectives Electric Skillet includes the following parts:

- Electric Skillet Base with Non-Stick Surface
- Tempered Glass Lid with Cool-Touch Knob
- Removable Locking Handle
- Temperature Control Probe



Image: The Kitchen Selectives 6-inch Electric Skillet, showing the main skillet body, the clear tempered glass lid with a black knob, and the black handle with the temperature control unit attached. The skillet rests on four black legs.



Image: A close-up view of the removable locking handle mechanism. It shows the 'LOCK' indicator with an arrow, indicating how to secure the handle to the skillet base. The temperature control dial is visible on the right.

Setup and First Use

1. **Unpack:** Carefully remove all packaging materials and labels from the skillet.
2. **Clean:** Before first use, wash the skillet, lid, and handle in warm, soapy water. Rinse thoroughly and dry completely. *Do not immerse the temperature control probe in water.*Wipe the probe with a damp cloth.
3. **Attach Handle:** Align the removable handle with the slot on the skillet base. Slide the handle into place until it locks securely. Refer to the image in the 'Product Components' section for visual guidance on the locking mechanism.
4. **Insert Temperature Control:** Insert the temperature control probe firmly into the receptacle on the side of the skillet. Ensure it is fully seated.
5. **Placement:** Place the assembled skillet on a stable, heat-resistant, and dry surface, away from the edge of the counter.

Operating Your Electric Skillet

1. **Prepare Food:** Add desired ingredients to the skillet. The non-stick surface allows for cooking with minimal oil, but a small amount can be used if preferred.
2. **Connect Power:** Plug the power cord into a standard electrical outlet. The indicator light on the temperature control will illuminate, indicating the unit is heating.

3. **Set Temperature:** Turn the temperature control dial to your desired setting. The skillet will begin to heat. The indicator light may cycle on and off as the skillet maintains the set temperature.
4. **Cooking:** Allow the skillet to preheat for a few minutes before adding food. Cook food according to your recipe or preference. Use the tempered glass lid to retain heat and moisture, if needed.
5. **Adjusting Temperature:** Adjust the temperature dial as necessary during cooking.
6. **Finish Cooking:** Once cooking is complete, turn the temperature control dial to the 'OFF' position.
7. **Disconnect Power:** Unplug the power cord from the wall outlet. Allow the skillet to cool completely before cleaning or storing.

Note: *The temperature control dial does not have specific temperature markings. Adjust gradually to find the optimal heat setting for your cooking needs. Initial use may produce a slight odor, which is normal and will dissipate.*

Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your electric skillet.

1. **Cool Down:** Always ensure the skillet is completely cool before cleaning.
2. **Remove Temperature Control:** Carefully remove the temperature control probe from the skillet.*Never immerse the temperature control probe, cord, or plug in water or any other liquid.* Wipe the probe with a damp cloth and dry thoroughly.
3. **Detach Handle:** Unlock and remove the handle from the skillet base.
4. **Wash Skillet and Lid:** Wash the skillet base and tempered glass lid in warm, soapy water. Use a soft sponge or cloth to avoid scratching the non-stick surface. For stubborn food residue, soak the skillet in warm water before cleaning. Rinse thoroughly.
5. **Dry:** Dry all parts completely before reassembling or storing.
6. **Storage:** Store the skillet, lid, and handle in a dry place. The removable handle allows for more compact storage.

Caution: *Do not use abrasive cleaners, metal scouring pads, or harsh detergents on any part of the skillet, as this may damage the non-stick coating or other components.*

Troubleshooting

If you encounter issues with your Kitchen Selectives Electric Skillet, please refer to the following common problems and solutions:

- **Skillet does not heat:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Verify the temperature control probe is fully inserted into the skillet receptacle.
  - Check if the temperature dial is set to an 'ON' position (not 'OFF').
- **Food sticks to the cooking surface:**
  - Ensure the non-stick surface is clean and free of residue from previous use.
  - Use a small amount of cooking oil or spray, even with non-stick surfaces, for best results.
  - Avoid using metal utensils that can scratch and damage the non-stick coating. Use plastic, nylon, or wooden utensils.
- **Skillet heats unevenly:**
  - Ensure the skillet is placed on a flat, level surface.

- Allow sufficient preheating time before adding food.

If the problem persists after trying these solutions, please contact customer support.

Product Specifications

Feature	Detail
Brand	Kitchen Selectives
Model Number	SK-6
Product Dimensions	9.1 x 6.5 x 7.1 inches
Item Weight	2.4 Pounds
Material	Aluminum
Special Features	Compact, Non-Stick Coating, Adjustable Temperature Control
Included Components	Skillet, Lid, Removable Handle, Temperature Control Probe
UPC	655772007209, 735343203848

Warranty and Customer Support

For warranty information or customer support inquiries regarding your Kitchen Selectives SK-6 Electric Skillet, please refer to the documentation included with your purchase or visit the official Kitchen Selectives website. Keep your purchase receipt as proof of purchase.

Manufacturer: Select Brands, Inc.