Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vitamix 5200

Vitamix 5200 Professional-Grade Blender

INSTRUCTION MANUAL

INTRODUCTION

The Vitamix 5200 is a professional-grade blender designed for versatile kitchen tasks, from creating smooth purees and hot soups to crushing ice and nuts. This manual provides essential information for the safe and effective operation, maintenance, and care of your Vitamix 5200 blender.



Image: The Vitamix 5200 blender filled with fresh ingredients, ready for blending.

Important Safety Information

Please read all instructions before operating your Vitamix blender. Failure to follow these instructions may result in serious injury or damage to the appliance.

- **Electrical Safety:** Always unplug the blender from the outlet when not in use, before assembling or disassembling parts, and before cleaning. Do not operate any appliance with a damaged cord or plug.
- **Blade Safety:** Blades are sharp. Handle the container and blades with care. Never place hands or other utensils into the container while the motor is running.
- **Lid and Tamper:** Always operate the blender with the lid securely in place. Use only the provided tamper through the lid plug opening when processing thick mixtures.
- **Overheating Protection:** The motor is equipped with a thermal protection system. If the blender overheats, it will automatically shut off. Allow it to cool down for 20-45 minutes before resuming operation.

- **Placement:** Ensure the blender is placed on a stable, level surface away from the edge of the countertop.
- **Children:** Keep the appliance out of reach of children. Close supervision is necessary when any appliance is used by or near children.

Components

Your Vitamix 5200 blender includes the following components:

- Motor Base
- Classic 64-ounce Container
- Tamper
- Lid with Lid Plug



Image: Diagram illustrating the key components of the Vitamix 5200 blender.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or shipping.
2. **Clean:** Before first use, wash the container, lid, and tamper with warm, soapy water. Rinse thoroughly and dry.
3. **Placement:** Place the motor base on a dry, level, and stable surface. Ensure the power cord is not obstructed.
4. **Assemble:** Place the container onto the motor base, ensuring it is seated correctly. The container can be placed in any direction.
5. **Plug In:** Plug the power cord into a grounded electrical outlet.

Setup Video Guide

Your browser does not support the video tag.

Video: A detailed walkthrough for beginners, explaining the setup and basic operation of the Vitamix 5200 blender.

Operating Instructions

The Vitamix 5200 offers precise control over blending textures with its variable speed dial and high-speed switch.

1. Loading Ingredients

- Always add liquids first, then soft ingredients, followed by hard ingredients, and finally ice or frozen items.
- Do not overfill the container. Ensure the lid can be securely fastened.

2. Variable Speed Control

The variable speed dial (1-10) allows you to achieve a range of textures, from coarse chops to smooth purees. You can adjust the speed at any point during blending.

1. Ensure the Variable/High switch is set to **Variable**.
2. Turn the On/Off switch to **On**.
3. Start with the speed dial set to **1** and slowly increase to the desired speed.



Image: The variable speed dial for precise texture control.

3. High-Speed Setting

The High-Speed switch provides maximum power and motor cooling, ideal for achieving the smoothest possible results for smoothies, soups, and frozen drinks.

1. Start blending on the Variable setting, gradually increasing the speed to **10**.
2. Flip the Variable/High switch to **High** for maximum power.
3. To stop, flip the switch back to **Variable**, turn the speed dial to **1**, then turn the On/Off switch to **Off**.



Image: Operating the High/Variable switch for maximum blending power.

4. Using the Tamper

The tamper is designed to push thick or frozen ingredients into the blades without interfering with their operation. Use it when ingredients are not circulating freely.

- Remove the lid plug from the lid.
- Insert the tamper through the opening.
- Move the tamper around the container to push ingredients towards the blades. Do not force it.

- Never use the tamper if the lid plug is not in place.



Image: Using the tamper to assist blending of thick mixtures.

5. Blending Examples

- **Smoothies:** Combine fruits, vegetables, and liquid. Start on low, gradually increase to high, and blend until smooth.
- **Hot Soups:** Add fresh ingredients and blend on high for approximately 5-6 minutes. The friction from the blades will heat the soup to serving temperature.
- **Nut Butters:** Process nuts on high speed, using the tamper to keep ingredients moving into the blades until desired consistency is reached.



Image: Examples of various preparations possible with the Vitamix 5200.

Green Smoothie Blending Video

Your browser does not support the video tag.

Video: Demonstration of blending a green smoothie in the Vitamix 5200.

Maintenance & Cleaning

Self-Cleaning Function

The Vitamix 5200 features a convenient self-cleaning function for quick and easy cleanup.

1. After use, rinse the container.
2. Fill the container halfway with warm water and add a drop of dish soap.
3. Secure the lid with the lid plug in place.

4. Set the Variable/High switch to **Variable** and the speed dial to **1**.
5. Turn the On/Off switch to **On**, then slowly increase the speed to **10**.
6. Run for 30-60 seconds.
7. Turn off the blender, rinse the container thoroughly, and allow it to air dry.



Image: The self-cleaning process in action.

Self-Cleaning Video

Your browser does not support the video tag.

Video: A demonstration of how to clean the Vitamix blender using its self-cleaning function.

General Cleaning

- Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
- The container, lid, and tamper are top-rack dishwasher safe, though hand washing is recommended for longevity.

- For stubborn residue, soak the container in warm, soapy water before cleaning.

Troubleshooting

If you encounter issues with your Vitamix 5200, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power switch off; circuit breaker tripped.	Ensure unit is plugged in. Turn On/Off switch to On. Check household circuit breaker.
Motor stops during operation.	Overheating due to heavy load or prolonged use.	Unplug the unit and allow it to cool for 20-45 minutes. Reduce load or use tamper for thick mixtures.
Ingredients not blending smoothly or circulating.	Too little liquid; ingredients too large; air pocket around blades.	Add more liquid. Cut ingredients into smaller pieces. Use the tamper to push ingredients into blades.
Loud noise or unusual odor.	Foreign object in container; motor strain.	Immediately turn off and unplug. Inspect container for foreign objects. If odor persists, contact customer support.

Specifications

Feature	Detail
Model Number	5200
Motor	2 HP
Capacity	64 fluid ounces (Classic Container)
Dimensions (D x W x H)	8.75"D x 7.25"W x 20.5"H
Weight	10.9 pounds
Blades	Laser-cut, Stainless-Steel
Speed Settings	10 Variable Speeds + High-Speed Switch
Material	BPA-free Eastman Tritan® copolyester (Container)
Power Source	AC
Wattage	1380 watts
Voltage	120 volts
UPC	703113013713

Warranty & Support

Your Vitamix 5200 blender is backed by a **7-Year Limited Warranty**. This warranty covers parts, performance, and more, ensuring reliable operation for years to come.

For warranty claims, technical support, or any questions regarding your product, please visit the official Vitamix website or contact their customer service directly.

You can find additional resources and support on the Vitamix Store on Amazon.

© 2026 Vitamix. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004F9L4EI

More documents and user manuals: **https://manuals.plus/**