Intex 68638E

Intex Quick-Fill Battery Air Pump User Manual

Model: 68638E

Introduction

The Intex Quick-Fill Battery Air Pump is designed for efficient inflation and deflation of various inflatable products, suitable for both indoor and outdoor use. Its battery-operated design provides portability, eliminating the need for a power outlet. This manual provides essential information for safe and effective operation, maintenance, and troubleshooting.

Safety Information

- **WARNING:** This pump is designed for inflating and deflating air mattresses and other inflatable items. Do not use it for inflating tires or other high-pressure items.
- Keep out of reach of children.
- Do not operate the pump near water or in wet conditions.
- Ensure proper battery installation and polarity.
- Do not block air vents during operation. Overheating may occur.
- Remove batteries when the pump is not in use for extended periods.
- Use only the specified type and number of batteries (6 C-cell batteries).

Package Contents

- 1 x Intex Quick-Fill Battery Air Pump
- 3 x Interconnecting Nozzles (various sizes)
- User Manual

Setup

1. Battery Installation

1. Locate the battery compartment on the pump.

2. Open the battery compartment cover.
3. Insert 6 C-cell batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

2. Attaching Nozzles

1. Select the appropriate nozzle size for the valve of the item you wish to inflate or deflate.
2. For inflation, firmly insert the selected nozzle into the "Inflate" port (usually on top of the pump).
3. For deflation, firmly insert the selected nozzle into the "Deflate" port (usually on the side of the pump).



Figure 1: The Intex Quick-Fill Battery Air Pump, highlighting its compact design and air ports for inflation and deflation.

Operation

Inflating Items

1. Ensure batteries are correctly installed and the appropriate nozzle is attached to the "Inflate" port.
2. Insert the nozzle firmly into the valve of the item to be inflated.
3. Press the ON/OFF switch to the "ON" position to start the pump.
4. Inflate the item to the desired firmness. Do not overinflate.
5. Once inflated, press the ON/OFF switch to the "OFF" position.
6. Remove the nozzle from the item's valve.

Deflating Items

1. Attach the appropriate nozzle to the "Deflate" port of the pump.
2. Insert the nozzle firmly into the valve of the item to be deflated.
3. Press the ON/OFF switch to the "ON" position to start the pump.
4. Allow the pump to extract air until the item is fully deflated.
5. Once deflated, press the ON/OFF switch to the "OFF" position.
6. Remove the nozzle from the item's valve.



Figure 2: The Intex Quick-Fill Battery Air Pump being used to inflate an air mattress, demonstrating its practical application.

Maintenance

- **Cleaning:** Wipe the pump exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the pump in a cool, dry place, away from direct sunlight and extreme temperatures. Remove batteries before long-term storage.
- **Nozzles:** Keep nozzles clean and free from debris to ensure efficient airflow.

Troubleshooting

Problem	Possible Cause	Solution
Pump does not turn on.	Batteries are dead or incorrectly installed.	Check battery polarity; replace with fresh C-cell batteries.

Problem	Possible Cause	Solution
Low airflow or slow inflation.	Low battery power; incorrect nozzle size; blocked air intake/output.	Replace batteries; ensure correct nozzle is used and ports are clear.
Battery compartment cover opens.	Latch not secure.	Ensure the latch is fully engaged. If it persists, consider securing with tape during use.

Specifications

Feature	Detail
Model Name	68638E
Power Source	6 C-cell Batteries
Air Flow Capacity	13.4 Cubic Feet Per Minute (CFM)
Operation Mode	Manual Switch
Color	Black
Material	Neoprene
Item Weight	350 Grams
Dimensions (LxWxH)	5.87 x 4.37 x 5.12 inches

Warranty & Support

For warranty information and customer support, please refer to the official Intex website or contact their customer service directly. The warranty description for this model is 68638E.
Manufacturer: Intex Recreation Corp.
For further assistance, visit the Intex Store on Amazon.

© 2023 Intex Recreation Corp. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question